




YSS-V 2

FTPLCG-0114
FTPLCG-0115
FTPLCG-0116












10X10 FT HARDTOP GAZEBO





























1. Must use ground nails, ropes, and expansions screws for whichever ground you install on for stability to avoid devastating injuries for people inside or nearby and property damage caused by a collapsing gazebo.
2. Do not use this gazebo in high winds, heavy snow, or inclement weather. It is not designed to withstand strong gusts of wind, heavy snow accumulation, or other inclement weather. Must take precautions when the wind speed exceeds 25Mph, and clear snow when it accumulates more than 2 inches.
3. Before use, thoroughly inspect the gazebo to make sure all bolts, nuts, and buckles have been completely tightened and securely fastened.
4. Warranty does not cover damages, losses, or injuries resulting from improper installation, misuse, not using stability accessories mentioned above, non snow cleaning, failure to take precautionary measures, etc.

















1. Two or more people are required for assembly.
2. A ladder and electric drill may be necessary.
3. Do not erect the structure in heavy winds or inclement weather.
4. Do not leave up this unit for extended periods of time, as it is not a permanent structure or designed to withstand sustained wind or rain. It is a temporary, portable shelter that shields you from sunlight and rain. The screens also block flying insects.
5. Do not use candles, matches, or any open flames near the tent.
6. To better align the screws for practical situations, do not fully tighten screws initially.
7. Professional installation is highly recommended.

Item no.	Reference Image	Qty.
A		X4
B		X4
B1		X4
D1		X4
D2		X4
E		X4
E1		X4
F1		X4
F2		X4

Item no.	Reference Image	Qty.
G1		X4
G2		X4
G5		X4
H1		X4
H2		X4
J		X4
K		X4
K1		X4
L		X1
M		X1
N		X8
N1		X4
N3		X4

Item no.	Reference Image	Qty.
N4		X4
P		X4
Q1		X4
Q2		X4
Q3		X4
Q4		X4
S1		X4
S2		X4
T		X4
T1		X4+X1
U		X96
V		X4
Y		X80


Item no.	Reference Image	Qty.
Z		X48
Za		X1
1	 M6X15mm	X96
2	  M6X23mm	9X+56X
3	 M5X12mm	X48
4	 ST4.8X12mm	X24
5		X1
6	 M6X42mm	X16
7	 M6X10mm	X32
8		X12
9		X12
		X1
		X1

1


X4





Ⓐ 4pcs



Ⓙ 4pcs



③ 12pcs



2


X4



Ⓑ 4pcs



Ⓑ1 4pcs




Ⓟ 4pcs



① 40pcs


When connecting B and B1 via P, make sure that 3 holes on part P (as shown in the picture) should be facing upwards. Do not install it upside down.




3




⑦ 32pcs



4




ⓗ1 4pcs




ⓗ2 4pcs



③ 32pcs



5




(K) 4pcs




(K1) 4pcs




(U) 96pcs




(V) 4pcs



(3) 4pcs




(4) 24pcs



6




Ⓔ 4pcs





Ⓕ 1pc




① 12pcs




1



2






7




Ⓔ1 4pcs

① 12pcs



8



Ⓜ1pc







ⓐ1pc



②1pc



⑤1pc



9






G5 4pcs




N 4pcs




1 8pcs






10








Ⓢ1 4pcs








Ⓢ2 4pcs



11







12




13





X4




Attach Z by lightly tapping with a screwdriver.



14




15



16




Ⓢ 80pcs



② 8+56pcs




⑥ 16pcs




Notes:


1. When installing the ceiling, fix the screws on the central beam first to prevent the iron sheet from falling and causing injury.
2. Do not fully secure the screw until all screws are properly in position.
3. Two persons are needed when installing Part Y. One should secure Part Y's position from inside the gazebo, while the other inserts screws into Part Y from outside the gazebo.




1



2












3



4

17





 G1 4pcs
  G2 4pcs
  N 4pcs
  N1 4pcs
  1 8pcs






18




Ⓣ4pcs




19







Pay attention to the sidewall curtain's installation position.





20





Ⓣ14+1pcs




21




Note:
Attach 1 to 2 to secure parts T1 and T (curtains) together.
Attach 1 to 3 to secure the back curtain (T).
Attach 1 to 3 to secure the front curtain (T1).




Pay attention to the sidewall netting's installation position.



1



Hang the hook attached to the netting on Part A.




2


22



⑧12pcs




⑨12pcs





To improve wind resistance, **be sure to complete this installation step. If expansion screws or ground nails are not installed, strong winds may topple the gazebo.**


Expansion screws are essential for stability on cement surfaces, and ground nails are for grassy surfaces. All are included in the accessories package.




Cement surfaces



Grassy surfaces



23



Installation Completed



Pure & Easy

CONTACT US:

If you have any questions about the installation of YITAHOME products, just contact us at +1 (888) 717-8084 from Mon-Fri 8:00 AM-4:30 PM PST / Sat. 8:00 AM-12:00 PM PST or e-mail us at after-sale.cs@hotmail.com

Alternative method to contact us (amazon.com orders only)

1. Log into your Amazon account
2. Go to "Your Orders" and find the purchase
3. Click on "Contact Seller"