

YYK-Q92

Bluetooth 5.3 Earbuds Product Manuals



If you have a question that is not listed here,
please do not hesitate to contact us by email.
Customer Service Department email address:

vipservice@amazonteam.work

Customer Service

✉ Email: vipservice@amazonteam.work

☎ Phone Call: (+1) 8135920888

🌐 Web: wirelessearbuds.vip



Email



Web

Packing List



Charging Case ×1



Earbuds ×1 Pair




User Manual ×1



Type-C Cable ×1

Product Overview



Note:

1. Please dry the sweat of the headset before putting it back into the headset.
2. Please be careful to align the speaker part of the headset to the inside of your ear.

Earbuds Charging

To Charge Earbuds

Insert the Earbuds into charging case properly, they will power off get charged.

Charging Case Charging

(There is a Type-C charging cable in the small black paper box inside the packing box.)

Please use the provided Type-C cable with a 5V/1A adapter (not included) to charge the charging case.



During charging, the charging case power display when they are fully charged. The number will be 100%.

Tips:

If the earbuds are not able to be charged or turned on, that may be because there is an oxidized layer or something else on the charging connector or charging pin. You can solve this problem by cleaning the magnet connector on earbuds and charging pin on the charging case with alcohol wipes.

Power On/Off

Automatically Power On/Off

Take the earbuds out from the charging case, and they will power on automatically and enter pairing mode.

Put the earbuds back into the charging case, they will disconnect power automatically.

Manually Power On/Off

If the earbud is out of the charging case and powered off, then press hold it for 5s, it will power on.

Disconnect the Bluetooth with your device, press hold either earbud for 5s, both earbuds will power off at the same time.

How to wear?

1. Clip it on your ear and adjust it to the most comfortable angle.



Charging Contacts



Speakers



Specifications

- Bluetooth Version: V5.3
- Support: A2DP/HFP/AVRCP/SPP/PBAP/BDR/BLE
- Transmission Range: 33 feet (without obstacle)
- Charging Port: Type-C
- Music Time: 6H
- Phone Call Time: 6H
- Standby time: 80 hours
- Charging Time: about 1H
- Headphones Battery Capacity: 40mAh
- Charging Case Battery Capacity: 300mAh
- Frequency characteristic: 2.40ghz-2.48-ghz

Bluetooth Connection

Prior to first use (or not in use for long time), please charge both earbuds and charging case fully.

First Time Pairing

Step 1 Take twin earbuds out of charging case, they will automatically power on and enter pairing mode.

At this time, led indicator of master earbud will flash Blue Red light alternately, and the vice earbud led indicator flashes Blue light quickly.

Step 2-Activate the Bluetooth setting on your phone, search and connect "YYK-Q92".

Once connected, the led light of both earbuds goes off.



Note: If the earbuds are not connected to your device over 5 minutes, the earbuds will power off automatically.

Factory Restore Setting

When should I reset?

- When only one side play music.
- When you can't find "YYK-Q92" on the device.
- When both earbuds fail to pair with each other or occur connection related issues.

How to reset?

- Delete "YYK-Q92" record from the Bluetooth menu on your device and deactivate the Bluetooth setting.
- Make sure the charging case has power or being plugged into a power supply.
- Insert both earbuds into the charging case to get charged.
- Press and hold both earbuds for 8 secs at the same time to clean the pairing record with the last device.

(*During this period, both earbuds' LED will flash Red Blue light once, then turn to Red light to get charge again.)

- Now turn on the Bluetooth setting on your device, search and connect the earbuds, they will work properly.

Note: If it still doesn't work, please repeat the steps to try again.

Operation



Play/Pause



Switch Song



Adjust Volume



reset



Answer



Reject Call




Voice Assistant
(In standby mode)



Hang up

x1: Click Once 2S: Press and hold for 2 seconds
x2: Click 2 Times

Battery Indicator




No Power



Full Power

Battery Indicator



Pairing	Connected	Charging
● Flashing	No Light	● Red



Wipe and dry charging contacts if earbuds can't be charge.

Safety Instruction

1. Using earphones at high to moderate volumes for extended periods of time will result in permanent hearing damage. It is advised you keep volume levels moderate to low at times for your safety.
2. Do not use it while driving a car, cycling, operating machinery, or performing other activities that require hearing surrounding sounds.
3. Do not use earphones in thunderstorm weather, the earphone may not work properly in the condition, and increase the risk of being hit by lightning.
4. Earphones may not work properly under high temperature or high humidity conditions. Do not use any corrosive cleaner/oil to clean the earphone.
5. If the earphone comes in contact with liquids, quickly wipe them away.
6. If submersed in water, do not turn the earphone on until completely dried. (Tips: liquid submersion voids the warranty.)
7. Keep the earphone and packaging out of reach of children.
8. Please use the original charging cable provided by the earphone manufacturer for charging and choose the right adapter.

FAQ

Q: Why these earbuds can not pair with my mobile phones?

- A:
1. Please make sure the earbuds are fully charged and powered on.
 2. Please make sure the Bluetooth of your phone is turned on.
 3. If the above 2 points have no problem, please put earbuds into the case again and close the case, hold on for 1min, then open the charging case and reconnect the earbuds with your phone.

Q: Why does the music cut in or cut out?

- A:
- First, please do not let the distance between these earbuds and your phone more than 33 feet (without obstacle). If the distance is less than 33 feet, Please note 2 tips below:
1. Please make sure there is no obstacle between the earbuds and your device.
 2. Please make sure there is no Microwave oven/Wifi transmitter around you, which is more likely to produce electromagnetic interference and result in a signal interruption.

Q: Why do the earbuds can not be charged and not disconnected from my phone even earbuds are put into the case and I have dosed the case.

- A:
- Please make sure the charging case is not in low battery, if the charging case is in low battery, earbuds can not be charged and not disconnected even though they are in the case. So, please use the type-c cable to charge the case fully.

Q: How to contact our customer service?

- A:
- We offer a one-year replacement warranty if there is any issue with your YYK-Q92, please don't hesitate to contact us, we will reply within 24 hours and resolve it 100%.

YYK-Q92

取扱説明書



ここに記載されていない問題がある場合は、遠慮なく電子メールでお問い合わせください。

カスタマー・サービスのEメールアドレス:

vipservice@amazonteam.work

カスタマーサービス

✉ 電子メール: vipservice@amazonteam.work

☎ 電話番号: (+1) 8135920888

🌐 Webサイト: wirelessearbuds.vip



Eメール



メッシュ

付属品




充電ケース*1



イヤホン本体*1






取扱説明書*1



USBケーブル*1

各部の名称



- 注:
- 1.イヤホンの汗を拭いてから、イヤホンに戻してください。
 - 2.イヤホンのスピーカー部分を耳の内側に合わせて注意してください。

イヤホン充電

イヤホンを充電する

イヤホンを充電ケースに正しく差し込み、電源を切って充電します。

充電ボックス充電

(黒い小さな紙にC型充電ケーブルが付いている梱包箱内の箱。)

提供されているCケーブルと5 V/1 Aアダプタを使用してください(含まない)
充電ボックスを充電します。



充電中、充電ケースの電源表示
充電されています。この数値は100%になります。

ヒント:

耳栓が充電できない場合や電源を入れられない場合は、充電コネクタや充電針に酸化層や他のものがあるからかもしれません。この問題は、耳栓のマグネットジョイントと充電ケースの充電針をアルコールで拭くことで解決できます。

電源オン/オフ

電源の自動オン/オフ

イヤホンを充電ケースから取り出すと、自動的に電源が入り、ペアリングモードに入ります。

イヤホンを充電ケースに戻すと、接続は自動的に再充電されます。

電源の手動オン/オフ

耳栓が充電ケースから取り出され、電源がオフになっている場合は、5秒間押し続けると、電源が入ります。

Bluetoothとデバイスの接続を解除し、いずれかを押したままにします5秒以内に、2つの耳栓が同時に電源をオフにします。

イヤホンの装着

1. 耳に挟んで、最も快適な角度に調整します。



じゅうでんせってん



スピーカ



仕様

- Bluetooth/バージョン:V 5.3
- サポート:A 2 DP/HFP/AVRCP/SPP/PBAP/BDR/BLE
- 変速機範囲:33フィート(バリアフリー)
- 充電ポート:Type-C
- 音楽時間:6時間
- 通話時間:6時間
- 待機時間:80時間
- 充電時間:約1 H
- イヤホン電池容量:40mAh
- 充電ケース電池容量:300 mAh
- 周波数特性:2.40 ghz-2.48-ghz

ペアリング

初回登録前(または長時間使用しない場合)には、イヤホンと充電ケースを同時に充電してください。

ペアリング(初期登録)のしかた

1. 充電ケースから2つの耳栓を取り出し、自動的に電源が入り、ペアリングモードになります。
このとき、プライマリ耳栓のLEDが青赤で点滅します交互に、副耳栓LEDがすばやく青色光を点滅します。

2. 携帯電話のBluetooth設定をアクティブ化し、検索し、「YYK-Q92」に接続します。
接続すると、両方のイヤホンのLED がオフになります。



注:イヤホンがデバイスに5分以上接続されていない場合は、イヤホンは自動的に電源をオフにします。

出荷時のリカバリ設定

いつリセットすればいいですか。

- 一方だけが音楽を再生する場合。
- デバイスに「YYK-Q92」が見つからない場合。
- 2つの耳栓がペアにならないか、接続に関連する問題が発生した場合。

リセット方法

- デバイスのBluetoothメニューから「YYK-Q92」レコードを削除するBluetooth設定を無効にします。
- 充電ケースに電源が入っているか、挿入されていることを確認します電源装置。
- 2つの耳栓を充電ケースに差し込むと充電できます。
- 2つの耳栓を同時に8秒間押し続ける最後のデバイスとのペアレコードをクリアします。

(*その間、2本の耳栓のLEDは1回赤色と青色の光を点滅させ、そして赤信号に向けて再び充電します)

- デバイスのBluetooth設定を開き、検索し、イヤホンを接続すると、正常に動作します。

注:まだ機能していない場合は、これらの手順を繰り返して再試行してください。

アクティビティ



再生/一時停止




歌を切り替えて



音量を調整する



リセット



受信



コールの拒否



音声アシスタント
(待機状態)





切断

×1: 1回クリック

⌚2S: 2秒間押し続ける

×2: クリック2回

バッテリーランプ



電源なし



フルパワー

バッテリーランプ



じゅうでん
連絡先

ペア	接続済み	じゅうでん
● きらめき	ライトなし	● 赤



充電点を拭き乾燥するイヤホンが
充電できない場合。

セキュリティの説明

- イヤホンを長時間から中程度の音量で使用する時間の経過は永久的な聴力障害を引き起こす。推奨安全のために、音量を適度に低く保つことがあります。
- 自動車を運転したり、自転車に乗ったり、機械を操作したりしないでください。他にも周囲の声を聞く必要がある活動を行う。
- 雷雨の日はイヤホンを使用しないでください、イヤホンは可能ですがこの場合は正常に動作せず、撃たれるリスクを高める稲妻に打たれる。
- イヤホンは高温または高温で動作しない可能性があります湿度条件。
腐食性洗剤/油を使用して洗淨しないイヤホン。
- イヤホンが液体に触れた場合は、速やかに拭き取ってください。
- 水に浸かったら、イヤホンを全開にするまで開けない乾燥する。
(ヒント:液体浸漬は保証を無効にします。)
- 子供の手の届かない場所にイヤホンとパッケージを置く。
- イヤホンから供給されるオリジナル充電ケーブルを使用してくださいメーカーは充電して正しいアダプタを選択します。

よくある質問

Q: なぜこれらの耳栓は私の携帯電話とペアリングできないのですか？

- A: 1. イヤホンが充電され、電源が入っていることを確認してください。
2. 携帯電話のBluetoothがオンになっていることを確認してください。
3. 上記2点に問題がなければ、イヤホンをイヤホンケースに入れてください再び充電ボックスを閉じ、1分間保持してから、充電ボックスを開けますイヤホンと携帯電話を再接続します。

Q: なぜ音楽は割り込みなのか、割り込みなのか。

- A: まず、これらの耳栓とあなたの電話は33フィートを超過しています（バリアフリー）。距離が33未満の場合、次の2つのヒントに注意してください。
1. イヤホンとあなたのそうじ
2. 電子レンジ/Wifiエミッタが周囲にないことを確認してくださいあなた、これは電磁妨害と信号が途切れる。

Q: なぜイヤホンは充電できないのか私の携帯電話から切断され、イヤホンまで挿入されましたこの事件はもう解決した。

- A: 充電をする場合は、充電ケースのバッテリー容量が低くないことを確認してください携帯ケースの電池容量が不足しているため、イヤホンは充電できず、接続も切断できない事実は確かだが。したがって、cケーブルを使用してください事件をすべて起訴する。

Q: どのようにしてカスタマーサービスに連絡しますか。

- A: お客様の製品に問題があれば、交換保証を1年間提供します。
YYK-Q92、いつでもご連絡ください、24時間以内に返信いたしますそして100%解決します。

边缘角度 10°

75x100mm