





Toying with Great Ideas™

Distributed by KIDdesigns, Inc. • 1299 Main Street, Rahway, NJ 07065 • www.kiddesigns.com

CONSUMER INFORMATION • PRODUCT: Walkie Talkies. **AGE GRADE:** Ages 3 and over. **CONTENTS:** 2 Walkie Talkies. **REQUIRES:** 2 x "9V" (6LR61) batteries (not included). • Do not mix old and new batteries, and do not mix alkaline, carbon-zinc, or rechargeable nickel-cadmium batteries. • Insert batteries with correct polarity (+/-) as indicated. • Do not attempt to recharge non-rechargeable batteries. • To prevent battery leakage or damage, remove batteries from product if it will not be used for a month or longer. • Use extreme caution handling leaking batteries (avoid direct contact with eyes and skin). If battery leakage comes in contact with eyes, IMMEDIATELY flush the eyes gently with flowing, lukewarm water for at least 30 minutes. If skin contact occurs, wash skin with clean water for at least 15 minutes. Seek medical attention if any symptoms occur. • Follow applicable laws and local regulations for the disposal and transportation of batteries. **DO NOT DISPOSE OF BATTERIES IN A FIRE; BATTERIES MAY EXPLODE OR LEAK.** • Packaging should be kept as it contains important information. • Product specifications and colors may vary from photo.



Battery Installation

Note: Batteries should only be installed by an adult.

1. Use a Phillips screwdriver to open the battery compartment door located on the back of the unit.
2. Install 1 "9V" (6LR61) battery into each Walkie Talkie with + and - terminals as indicated in the compartment.
3. Replace the compartment door and tighten the screw with a Phillips screwdriver. Do not over-tighten the screw.

MARVEL

© MARVEL

**DON'T FORGET
THE BATTERIES!**



**2 x "9V" (6LR61) BATTERIES
REQUIRED (NOT INCLUDED)**

SM-205VM.EXv25



MANUFACTURED IN CHINA.

Back Panel