

Operation Tips

1. Please refer to the instructions or the signs inside the battery bin to correctly install the battery polarity, and don't install the reverse battery.



2. When using the product, please press the middle position of the top button to make the product work better.



3. If the speed is too slow or the wheel swings too large during the use of the product, please replace the battery in time.

4. How to remove the battery?

Method 1: Please remove the battery by using the strap.



Method 2: If the battery cannot be removed by using the strap, please remove the battery by tapping the machine body.



5. The product needs to be powered by 2 AA alkaline batteries of good quality produced by regular manufacturers.