


User Manual



1. When the numbers stop flashing, it means the heating is complete.



2. For better curling effect, do not clip too much hair at one time.



3. Press the left or right buttons quickly twice to reset the clip cover to the middle of the button.



Scan the QR code for more details about the tutorial!