


# INSTRUCTION MANUAL



## Portable Lock Box User Manual

### Product Overview

Thank you for purchasing the Temracha Portable Lock Box. This lock box is designed to provide secure storage for your valuables while on the go. Please read this manual carefully before use to ensure proper operation and maintenance of your lock box.

### Key Features

- \* **Water Resistant:** The lock box offers water resistance to prevent damage from splashes. Please note that the lock box is not waterproof and should not be submerged in water. Avoid exposing the lock box to heavy rain or direct contact with large amounts of water.
- \* **Durable Construction:** Constructed from high-grade ABS material, the lock box is built to last. However, it is important to handle the lock box with care as it is not designed to withstand violent impacts or being dropped. Avoid subjecting the lock box to extreme force to maintain its integrity.
- \* **Internal Silicone Pad:** A soft silicone pad is included inside the lock box to cushion your belongings and protect them from impact during movement. If you do not need this additional protection, the silicone pad can be easily removed by lifting it out of the lock box.

### Maintenance and Care

- Keep the lock box clean and dry. Wipe it down with a damp cloth if necessary, but avoid soaking it.
- Store the lock box in a cool, dry place when not in use.
- Regularly check the combination lock mechanism for smooth operation. Lubricate if needed according to manufacturer recommendations.



### Troubleshooting

- **Lock Not Opening:** Double-check the entered combination. Ensure that each digit is correctly aligned.
- **Issues with Durability:** Contact customer support if you experience any issues with the structural integrity of the lock box.

### Contact Us


For any questions or concerns regarding your portable lock box, please contact our customer service team.

# INSTRUCTION MANUAL





## Reset the password:

Reset the password for initial use and think of a default password first!

Toggle the password wheel 0-0-0-0 (factory password) to aim at the scale mark, turn the knob to the unlocking position  and pull open the pinch plate, then it will be open.

1. Set the lever toggling from A to B.
2. Toggle the password wheel to the password you want and aim at the scale mark.
3. Restore the setting lever from B to A to



## Regular use:

Unlock: Toggle the right password, turn the knob to the unlock position and pull open the pinch plate, then it will be open.

Lock: Buckle the pinch plate, turn the knob to lock position and disorder the password, then it will be closed.

More functions depend on your exploration!