

# NUXX

STOMPBOX

New Generation Pedal Effects

Full Aluminum Alloy Casing

Core Deluxe MKII

# LOOP CORE

STEREO

## Quick Start Guide




**Core Deluxe MKII**  
Core deluxe series upgraded version

**Loop  
Pedal**

Thanks for choosing the NUX LOOP CORE STEREO pedal!

The NUX LOOP CORE STEREO features a high-definition color LCD display, stereo inputs/outputs, and a MIDI control input. It allows you to create music phrases and play back as stereo loops! Whether you practice, compose, or play live gigs, you will get inspired by this well-designed loop pedal!

## Panel & Connection



① Power jack

② TFT LCD

③ VALUE / VOL knob

④ DRUM STYLE button

⑤ TAP / TEMPO button

⑥ SAVE / DEL button

⑦ SETTING button

⑧ OUTPUT jacks

⑨ INPUT jacks

⑩ MIDI OUT / IN

⑪ USB port

⑫ Footswitch

- This picture shows a normal STEREO IN/OUT connection for most musicians.
- It also provides SPLIT IN/OUT mode(Audio Path) for musicians to connect it with two amplifiers: one for the loop, one for the drum.
- It also provides SPLIT TO MIXER mode (Audio Path) for musicians to connect it with a mixer.

## How to use the Loop Core Stereo pedal

Power on the Loop Core Stereo pedal, rotate the VALUE knob to select an empty memory from 01 ~ 99, then you can press the footswitch to record/play/dub your phrases. You can also hold the footswitch to UNDO/REDO/CLEAR your phrases.



### Buttons and functions

|  |  |
|--|--|
|  | <b>DRUM STYLE button</b><br>Press it to turn ON/OFF the drum. Hold it to select drum style.                      |
|  | <b>TAP / TEMPO button</b><br>Press it to TAP. Hold it to adjust the tempo.                                       |
|  | <b>SAVE / DEL button</b><br>Press it to save the current phrases to a memory. Hold it to delete an exist memory. |
|  | <b>SETTING button</b><br>Press it to enter to the system setting.  |


### VALUE/VOL knob



- 1.To select the current memory from 01~99 or adjust parameters.



2. When you are working on phrases or practicing, press it once/twice to adjust the volume of Loop/Drum.



## Customize your own Boot-up picture

The Loop Core Stereo allows users to customize their own boot-up picture with a GIF.

- Connect the Loop Core Stereo to your computer, and download a GIF picture to the folder: NUX LOOPER > NUX\_LOOP > GIF.
- Disconnect and reboot the Loop Core Stereo, and then enter to the DISPLAY setting and set the BOOT-UP PICTURE option to USER.
- Reboot the Loop Core Stereo again. Enjoy your own customized GIF interface!



 **SCAN FOR THE USER'S MANUAL & MORE AT [WWW.NUXAUDIO.COM](http://WWW.NUXAUDIO.COM)**



©Cherub Technology Co., Ltd.

All Rights Reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Cherub Technology Co., Ltd.



Made in China