




MCombo®



# OWNER'S MANUAL

## 3-PERSON SWING CHAIR



v1.2.0

Newacme LLC, 2808 Vail Ave, Commerce, CA, 90040  
sales@mcombo.com  
1-323-597-1109 (8:00 a.m. - 4:00 p.m. (Monday - Friday) TIME ZONE: PST)

Hello,  
Thank you for choosing MCombo  
Let's get started

○ PURCHASER’S AGREEMENT

By accepting delivery of this product, you promise that you will not change, alter, or modify this product or remove or render inoperable or unsafe any guards, shields or other safety features of this product.  
You will not refuse or neglect any retrofit kits that MCombo may provide to enhance and preserve the safe use of this product.

# CONTENTS

I	SAFETY GUIDELINES	- 01
II	MAINTENANCE	- 01
III	ASSEMBLY INSTRUCTIONS <ul style="list-style-type: none"><li>• Product Parameters</li><li>• Preparation</li><li>• Part List</li><li>• Assembly Steps</li></ul>	- 02
IV	WARRANTY	- 14
V	MCOMBO CUSTOMER SUPPORT	- 15
VI	RETURN / REPLACEMENT POLICY	- 16

# I. SAFETY GUIDELINES

 **WARNING**

For your own safety, please strictly follow the instructions in this manual, otherwise personal injury may result!

Before you proceed, please read the following safety precautions:

- Separate and count all parts and hardware.
- Install not less than 6 feet from any obstruction such as fence, garage, house, overhanging branches, laundry lines, or electrical wires.
- Tighten all nuts and bolts securely.  
  
Never use power tools or excessive force during assembly and tightening of bolts.
- Always place the product on a flat, steady and stable surface.
- It is recommended to protect in case of strong wind or rain and in your absence.
- Do not use candles, matches, or any open flames in or near the swing.

# II. MAINTENANCE

- Wash frame parts and fabric with mild soap and water, rinse thoroughly.
- Dry frame completely and allow the fabric to drip dry.
- Do not use bleach, acid, or other solvents on the fabric or frame parts.
- Please inspect and tighten all bolts or fasteners on a regular basis to ensure proper performance and safety of your swing.

# III. ASSEMBLY INSTRUCTIONS













1. Product Parameters


















Specification	Description
Package Quantity	2 boxes
Package Contains	Box 1 of 2: D. Bottom Support (Left), D-1. Bottom Support (Right), E. Cup Table, G. Swing Arm, I. Conecting Bar (Front), J. Conecting Bar (Back), O. Cushion, P. Knob, X. Spacer, Z. Spring Hook, Screw Pack
	Box 2 of 2: A-1. Top Bar (Left), A-2. Top Bar (Right) , B. Back Leg, C. Front Leg, F. Seat, H. Backrest, L. Canopy

2. Preparation

Please remove all protective foam.Before assembling, make sure that you lay out and identify all parts listed below in the parts list. install on level ground.

3. Part List


Frame Part			
<b>A-1</b>  Top Bar ( Left ) x1	<b>A-2</b>  Top Bar ( Right ) x1	<b>B</b>  Back Leg x2	
<b>C</b>  Front Leg x2	<b>D</b> 	<b>D-1</b>  Bottom Support ( Right ) x1	
<b>E</b>  Cup Table x2	<b>F</b>  Seat x1		
<b>G</b>  Swing Arm x2	<b>H</b>  Backrest x1		
<b>I</b>  Conecting Bar ( Front ) x2	<b>J</b>  Conecting Bar ( Back ) x2		

<div>L</div> <div></div> <div>Canopy x1</div>		<div>O</div> <div></div> <div>Cushion x3</div>	
<div>P-1</div> <div></div> <div>Knob x2</div>	<div>X-1</div> <div></div> <div>Spacer x12</div>	<div>Z-1</div> <div></div> <div>Spring Hook x2</div>	
<div>Screw Pack</div>			
<div>M</div> <div></div> <div>M8 x 100 Bolt Set x6</div>	<div>N</div> <div></div> <div>M6 x 95 Bolt Set x4</div>	<div>Q</div> <div></div> <div>M8 x 95 Bolt Set x2</div>	<div>R</div> <div></div> <div>M8 x 80 Bolt Set x2</div>
<div>S</div> <div></div> <div>M8 x 78 Bolt Set x2</div>	<div>K</div> <div></div> <div>M6 x 68 Bolt Set x2</div>	<div>Y</div> <div></div> <div>M6 x 32 Bolt Set x1</div>	<div>T</div> <div></div> <div>M6 x 50 Bolt Set x2</div>
<div>U</div> <div></div> <div>M6 x 20 Screw x8</div>	<div>V</div> <div></div> <div>M8 x 90 Bolt Set x2</div>	<div>P-2</div> <div></div> <div>Double-ended Spanner x1</div>	<div>P-3</div> <div></div> <div>Allen Wrench x1</div>


4. Assembly Steps

Step1 - Frame Assembly


(1). Connect **#A-1** (Left Top Bar) and **#A-2** (Right Top Bar) by two sets of bolts **#K** (M6x68 Bolt Set).




(2). Connect **#B** (Back Leg) and **#C** (Front Leg) by six sets of bolts **#M** (M8x100 Bolt Set).




(3). Connect **#D** (Left Bottom Support) and **#D-1** (Right Bottom Support) with a set of **#Y** (M6x32 Bolt Set).



(4). Connect **#D** (Left Bottom Support) and **#D-1** (Right Bottom Support) to **#B** (Back Leg) with four sets of **#N** (M6x95 Bolt Set).




(5). Connect **#E** (Cup Table) to **#B** (Back Leg) and **#C** (Front Leg) with eight **#U** (M6x20 Screw).




## Step2 - Seat Assembly


(1). Connect **#F** (Seat) to **#G** (Swing Arm) with **#R** (M8x80 Bolt Set) and **#X-1** (Spacer).



(2). Connect **#H** (Backrest) to **#G** (Swing Arm) with **#S** (M8x78 Bolt Set) and **#X-1** (Spacer).




(3). Connect **#G** (Swing Arm), **#J** (Back Conecting Bar), **#H** (Backrest) with **#V** (M8x90 Bolt Set) and **#X-1** (Spacer).  
Connect **#I** (Front Conecting Bar), **#G** (Swing Arm), and **#F** (Seat) with **#Q** (M8x95 Bolt Set) and **#X-1** (Spacer).  
Connect **#I** (Front Conecting Bar) and **#G** (Swing Arm) with **#T** (M6x50 Bolt Set).




Step3 - Combine Assembly

(1). Hang the seat to with #Z-1 (Spring Hook).



(2). Fix #L (Canopy) to #A-1 (Left Top Bar) and #A-2 (Right Top Bar) through #P-1 (Knob).



(3). Put the #O (Cushion) on the seat.



IV. WARRANTY

■ Notice

- For product beyond the limited manufacturer warranty period and scope, MCombo® can also provide replacement service, but a basic charge will be charged according to the circumstances.
- The warranty only applies to MCombo® products and does not include any accessories or enhancements.
- Warranties are only valid in the 48 contiguous United States and are contingent upon the consumer operating the product according to the corresponding instruction manual.

Swing Frame	★ 1 Year
Swing Fabric	★ 6 Months

CONSUMER WARRANTY LIMITATIONS AND EXCLUSIONS


All warranties begin on the date of delivery.  
All warranties are to the original purchaser from MCOMBO® ONLY.

- MCOMBO® will replace the defective parts or send replacement product provided that the warranty parts have not been subjected to misuse, abuse or improper service by the consumer, for example, damaged wire arising in consequence of negligence or improper operation.
- Exclusions also include components with damage caused by:
  - Contamination
  - Abuse, misuse, accident, or negligence
  - Commercial use, or use other than normal
  - Improper operation, maintenance, or storage


**NOTE:**  
MCOMBO® will pay standard shipping rates on all warranted parts for the first year. We can also sell you replacement part for a discount price when your product is out of warranty policy.

# V. MCOMBO CUSTOMER SUPPORT


If for any reason, we have fallen short of your expectations, or if you have any questions and suggests, please refer to the following contact information, we will do our best to work with you to make sure you are entirely satisfied.





sales@mcombo.com  
(Respond within 24 hours)



**1-323-597-1109**  
8:00 a.m. - 4:00 p.m. (Monday - Friday)  
TIME ZONE: PST

**DE**  
2411 Bear Corbitt Rd STE 1  
New Castle, DE, 19720

**TN**  
3980 PREMIER AVE,  
MEMPHIS, TN, 38118

**CA**  
2808 Vail Ave  
Commerce, CA, 90040

15

MCombo®

# VI. RETURN/ REPLACEMENT POLICY

■ Notice

Why don't we recommend returning the item by yourself?

- Huge cost- UPS/FedEx oversize fee.
- Need you to take the box to UPS/FedEx facility.

Return/ Replacement Policy

MCOMBO®

You have 30 days from the date of purchase to return any item purchased from our store. Please securely pack the item in its original packaging, including any accessories or manuals that came with the product. To initiate a return, please contact our customer service team at sales@mcombo.com/ 323-597-1109 for any help.

Return Conditions

We accept the return of items that are in new, unused condition, with original tags attached and all original packaging and other components included. Refunds will be issued in the original form of payment for the price of the item, including taxes.

NOTE:

- Please keep the original packaging in case the product needs to be returned. If the original packaging is not available, the newly found packaging needs to meet the following size standard:  
UPS/FedEx packaging size standard: ( width+ height ) \* 2+ length< 128 inch.
- Please disassemble the product before you return it, otherwise there will be a huge cost as oversized and it could even exceed your order amount.
- Please do not purchase return label for a damaged/defective product by yourself.
- If you have any problem to return the product, please contact us immediately, we will do our best to help you with a reasonable solution.

16