




POWER SCRUB™ XL

CARPET & UPHOLSTERY CLEANER



QUICK START GUIDE

GETTING STARTED



1 Attach Handle.




2 Fill Clean Water Tank with Water up to MAX line located on side of the tank.



3 Fill Solution Bottle with HOOVER Solution and slide into back of the unit.

HOW TO USE: MAIN UNIT



1 Use pedals to operate.



2 Slowly Push forward and squeeze trigger to wash. Release Trigger and slowly pull unit back to Dry carpet. Repeat and move to new section.

HOW TO USE: ABOVE FLOOR



1 Lift hose cover on nozzle.



2 Attach hose to hose port.




3 Saturate stain and scrub.


HOW TO USE: CLEANING AND MAINTAINING



1 Remove Dirty Water Tank.



2 Pull to Remove Nozzle Cover.



3 To Remove Brushes, press both tabs on side of foot.



4 Reinsert Brushes and Press Firmly until Latches Lock.

HOW TO USE: QUICK CLEAN MODE*



Quick
Clean
Mode



Deep
Clean
Mode

1

To Engage Quick Clean Mode, Turn Knob Counter-Clockwise until engaged. Return to Deep Clean Mode by Turning knob Clockwise to Starting Position.