

# Appearance Description

Smart Watch User Manual



# Schematic Diagram of Charging

Operate in strict accordance with the following figures: 1.Please use the product-specific magnetic charging cable to charge by aligning it with the charging contacts on the back of the watch. 2. Do not use a power adapter with a voltage exceeding 5V and an output current exceeding 1A for charging, as this may cause charging failure and damage to the magnetic charging cable or the device. 3.Please activate the watch when it runs out of power before charging: the watch screen will only light up after about 5 minutes of normal charging.



## Introduction to Watch Function

- 1. Bluetooth switch for calls
- Brightness adjustment
- 3. Sound and vibration
- 5. Version informat
- 8. Settings

4. Power

6. Flashlight

7. Mute switch

### Main interface: Display the current time, period, steps and other mation of the watch: long press on the main interface can ch the main dial left and right, and click to confirm: right stroke


Calls: Tap this icon to view contacts (need to be synchronized to the vatch via APP), call logs, unplugged calls. SOS. etc.




Click on the icon on this page to enter the Multi Exercise Mode tion, select an exercise mode, click on the icon to start, and press the on to pause or stop the exercise.










































## ♦ Watch APP Installation and Connection Instructions As a Bluetooth product, most of the functions of

Remote control photo: The watch can control the cell phone to take

the camera permissions and keep the APP connection.

rientation of your phone, this function requires your phone to

Settings: Tap the icon to enter the function, you can set the menu.

style, brightness adjustment, restore factory, shutdown and view

Watch audio switch: You can turn on/off the watch call function and

ultimedia sound playback function.

tay connected with the watch APP. No alert on the phone in

photos, this function needs to go to the APP device settings to open

itoring and data records can be viewed through the APP settings.

this product need to be connected to a special APP for normal use, such as time display, call alert, and message alert. For Android phones, please do not use Bluetooth to connect and pair with the watch directly. Please scan the following QR code to select the version suitable for your mobile phone system or enter main application markets to download and

# Device Connection

Before using the APP, please turn on the mobile phone Bluetooth and mobile phone GPS positioning to obtain the mobile phone positioning permission. After the connection is successful, it will prompt "To pair with: \$97 ", please select pairing.

affect the user experience.

connecting in the APP, you

need to connect to the S97

for the second time in the

mobile phone, and then you

Bluetooth settings of the

2. For systems below

iPhone iOS 13, after

functions.

### The watch connection operates as follows:

Open the APP and make setting For Android users, the APP according to the prompt run backstage, otherwise it will

Click [Select Device] to search

elect the name of the searc Bluetooth: S97

install GloryFitPro.

Connection succeeded

### can make calls, play nultimedia music and other

1.No charging with water stains.

This product is an electronic monitoring product, not for medical use. and the measurement data is for reference only.

3.It is not recommended to wear in hot water baths and longtime

4.Please charge with the matching charging cable. 5. Please keep the charging port on the back of the watch clean to

avoid poor charging contact.

Precautions

1. Problems such as the watch cannot be searched in the APP, or the watch cannot synchronize with the time of the phone.

A. Make sure your phone's Bluetooth and phone GPS positioning are or before using it for the first time.

B. Users need to open the APP to obtain positioning permission (Phone Settings - Applications).

C. If the watch has already been paired with a Bluetooth connection in the phone, please cancel the pairing first and then search for the connection

5. The watch cannot measure, or the data is not accurate. D. If the watch is not used for a long time, the Bluetooth will go into a dormant state. Please turn off the Bluetooth of the watch and the phone A. Sit down before the measurement and put your body in a relaxed state reopen it after about 1 minute, and try to search the connection in the APP with your arms level with your chest position.

measurement results.

B. Adjust the tightness of the watch. The back of the watch should be close to the skin to prevent light leakage from the photoelectric sensor.

E. The watch must be connected to the APP, otherwise, the steps, sleep, time, and other function will not work properly

### 2. There is no alert function on the watch. Answer: For first time use:

For Android users: Please operate according to the page prompt, or open the information reminder function in the APP, and open the APP notification permission according to the prompt.

For Apple users: After the watch is connected to the APP, the phone will pop up a pairing request, please choose to allow pairing and turn on the switch of the application reminder that you need to use in the APP. Please open the "Notification Center" in the application you need to use via Phone Settings - Notification.

## 3. The reminder switch is turned on, but there is no reminder on the watch, or the reminder is sporadic.

If the phone turns on the message notification and the corresponding notification permission according to the above tips, the Bluetooth is kept on, and the APP and the watch are kept connected, maybe the system authorized APP alert function is not working, and the user needs to re-check the message push function.

4. Android's phone Bluetooth often disconnects or has no message alert after a period of connection.

applications or applications that consume more power for smooth system

C. Keep your body calm during the measurement. Talking/coughing/

sneezing and other movements will affect the accuracy of the

# Android will from time to time clean up the phone's backstage

operation. If the APP is not set to allow backstage running, it will be easily cleaned by the system and the Bluetooth will drop out. Different Android following measures: phones have different methods for APP backstage running settings. As in the Huawei nova 8 SE: Settings - Battery - Power Consumption Ranking APP - Application Launch Management - Manually manage to turn on backstage running.

## RF warning statement

portable exposure condition without restriction.

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est

FCC STATEMENT

This device complies with Part 15 of the ECC Rules. Operation is subject

to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device nursuant to Part 15 of the ECC Rules

. These limits are designed to provide reasonable protection against harmful interference in a resident installation. This equipment generates uses and can radiate radio frequency energy and, if not installed

and used in accordance with the instructions, may cause harmful interference to radio communication However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined turning the equipment off and on, the user is encouraged to try to correct the interference by one of

### Regrient or relocate the receiving antenna

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to

which the receiver is connected

Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RE exposure requirement. The device can be used in

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the

le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions

(1) l'appareil nedoit pas produire de brouillage et

susceptible d'en compromettre le fonctionnement," nuestro servicio al cliente.