尺寸：70X100mm
材质：105g双铜纸
工艺：风琴折页 单黑印刷

USER MANUAL

For more details,
please consult online
customer service.

⚠ **Notice** Please read this user manual carefully before use.

Safety Tips

For the best viewing effect, please use the projector in dark room.

1. Do not install this projector in the area which directly blown by the air conditioner, to prevent projector failed caused by water vapor condensation or excessive temperature.
2. Ensure that the environment is ventilated to prevent overheat caused by heats build—up.
3. Prevent foreign objects from falling into the machine. Never insert any metal objects into the machine. If foreign objects fall into the machine accidentally, please power off immediately and seek professional assistance.
4. Do not place any liquid on the machine to avoid leakage.
5. Avoid violent vibrations when transporting. Please protect the lens from wear.
6. Do not touch the vents when using the projector to avoid burns due to excessive temperature.
7. Do not look directly at the lens while the projector is running to prevent eye injury.
8. Please clean the filter regularly to prevent malfunction caused by clogging.

Notice ⚠
Do not open the case of projector to prevent electric shock. Please seek professional assistance for maintenance matters.

Warn ⚠
Do not touch! The inside of the projector contains uninsulated voltage.

Warn ⚠
Do not install the projector around flammable objects to prevent fire.

1

Important Safety Notes

To ensure the performance and stability of the projector, please place it horizontally and leave a space of about 30cm between the projector and the wall.

Do not install in place with poor ventilation.

Do not install in high temperature or humid places.

Do not block the vents

Do not install in dust or smoky places

2

Specifications

Item		Specification
Product		X1 Pro
Native Resolution		1920x1080
Projection Technology		LCD Display
Lamp Type		LED Lamp
Interface	HD	HD IN*2
	USB	USB 2.0 Port*2
	Earphone	3.5mm Audio Port
	AV	AV IN
Environment		
Power Input		AC 100~240V 50-60HZ
Operating Temperature		0 ~ 30℃
Storage Temperature		−20 ~ 65℃
Operating Humidity		0 ~ 90% Non−condensing

1 Package contents

Projector

Power Cord

HD cable

Remote control

Heightening screw

User manual

Canvas bag

3

Projector Introduction

AV port

HD Input

Ventilation holes

USB port

3.5mm Audio port
(Available for earphones)

Dust filter

IR Receiver

Navigation key

AC Port

4

Remote Control Introduction

Power ON/OFF

Navigation key

Return

Home

VOL −

Focus−

Voice Key

Input Source

Menu

Mouse Mode

Setting

VOL +

Focus+

Mute

5

Electric Focus

Press the focus +/− keys to adjust the clarity of the picture.

F−   F+

6

Q&A

1 Unable to Boot Up
* Check if the power cord is connected properly, and if the power light is on.Try to unplug and plug the power if the projector still can not boot up.

2 Remote Controller is Insensitive or Unresponsive
* Do not cover IR receiver.
* In the infrared mode, make sure remote points at IR receiver directly.
* There is an obstacle between the remote control and the projector.
* The batteries are out of power or the battery is not installed correctly

3 Why is there no display when I connect HD port?
*Check if the interface is securely connected.
*The devices may be incompatible.

4 Blurry Display
* The lens is not clean.
* The projection lens is not correctly focused.
* The projector and the screen are not aligned properly.
* The environment is too bright.

5 Screen Freeze
* Please reboot the projector to test again. If the screen still freeze, please turn off for 10 minutes and turn on again.

¥ If you have any other problems or suggestions, please contact our online services to help you immediately.

7

Maintenance Suggestion

Open from here

Filter

⚠ **Notice**

To make this projector work longer, we recommend you to follow the suggestions.
1. Before cleaning the projector, turn off the projector, then turn off the main power and unplug it from the outlet.
2. Clean the filter regularly every month to prevent clogging.
3. Make sure to close the projector off once you finished using it.
4. Make sure not to use it continuously for more than 6 hours.

8

Warranty Card

Client Name: _____   Client ID: _____

Client Phone Number: _____

Purchase shop: _____

Return Address: _____

Fault description:
(For quick repair, please describe the problem in details.)

FC CE RoHS ♻ ⌧