

PROVENCE

With Automatic Temperature Controller User Manual



Manufactured by

Universal Innovations

Dear Customer,

We tried to achieve two targets when developing this product. The first was to produce the best quality heater on the market. The second was to produce the most cost-effective heater. We feel that we have achieved these two objectives however we would be delighted to hear from you if you have any comments.

Thank you for purchasing one of the products in our range. We wish you many enjoyable warm hours.

Yours Sincerely



Chairman

GUARANTEE

The Provence gas stove is made by Universal Innovations. It is made to an exacting quality standard and is covered by the following guarantee:

THIS PRODUCT IS FULLY GUARANTEED FOR 2 YEARS,
REGARDING PROPER USE.

This guarantee does not affect your statutory rights in any way.

HELPLINE Dublin Ireland
00 353 1 2873797 or at www.saharabbqs.com

IF YOU NEED ANY ASSISTANCE PLEASE DO NOT HESITATE TO CONTACT US
DIRECTLY AT THE FACTORY. DO NOT BRING GOODS BACK TO PLACE OF
PURCHASE.

USER INSTRUCTIONS

Read the instructions before using this appliance.

When lighting for the first time, burn on high in a very well ventilated area for 4 hours minimum to cure the synthetic logs (The logs give off an odour when curing).

Flame colour is yellow when turned on for the first time.

The appliance must be installed and used in accordance with the regulations, which are currently in force.

The heater should be positioned on a level surface. Use only in a well ventilated area.

The minimum room size when using this appliance is 64 cubic metres with a minimum ventilation of 80 cm squared area.

To fit a Butane Gas Regulator:

Attach regulator to end of hose and secure with hose clip.

Note: for ease of fitting hose, lubricate ribbed nipple of regulator with a soap solution.

To fit a Butane Gas Cylinder:

(Ensure that the area is free from any unprotected combustible material or substance)

Containers should be changed in accordance with instructions provided.

1. The changing and connection of LPG cylinders must be undertaken in a flame free atmosphere.
2. Attach the regulator to the new cylinder. Ensure that the hose is not twisted or damaged in any way.
3. Use gas cylinders with a gas capacity of 7-15kgs.
4. In order to remove the regulator you must ensure that the regulator is in the "off" position.



Before lighting:

1. Inspect the hose assembly. If the hose is cut or shows signs of excessive wear, or is leaking it must be replaced prior to operation of the heater.
2. Ensure the heater is positioned with a minimum clearance above and beside of 0.6metres from flammable materials both vertically and horizontally.
3. Ensure that the stove door is closed securely.

The Auto Temperature Control Function




This heater is fitted with an automatic temperature controller. When the desired temperature in the room is reached, the controller will automatically adjust the burner to the low setting and when the temperature in the room drops, the burner will adjust back to the high setting automatically.

The marking on the setting dial does not represent actual temperatures. Through use, you will find the setting position that works best for your room.




USER INSTRUCTIONS

To Light Heater:

1. Fit battery type AAA provided into ignition button ("+" side up). See **Fig.1**. Remove battery during periods of non-use to prevent battery leak.
2. Turn on gas supply at gas cylinder regulator.
3. Push control knob down and turn the control knob to the on position  and at the same time, press sparker button to light the pilot while continually holding down control knob.
4. If there is no spark, check the battery type AAA is correctly fitted. The pilot flame can be viewed at the right hand side of the log bed.
5. If pilot does not light, turn control dial to off position . Wait one minute and repeat step 3. Do not continuously hold down the control knob as you may cause a build up of gas.
6. Once the pilot is lit, continue holding down the control dial for at least 10 seconds until the main burner lights.
7. Adjust the setting control dial to your preferred position. The heater will automatically adjust from low to high to maintain that setting.
8. If the pilot and main burner do not stay lit on releasing the control knob, turn the control knob to the ignition position and repeat steps 3 to 4.
9. The  is a pilot setting only.


To Turn Off Heater:

1. Turn the control knob to  position.
 2. After use turn off the appliance at the gas container valve.
- NOTE:** The pilot light will remain alight until the cylinder regulator is turned off.
3. Disconnect the regulator from the cylinder when the heater is not in use.
 4. Remember to remove battery during periods of non-use to prevent battery leak.

Important: Read all of the instruction Manual before using this appliance. This appliance must be installed in accordance with such regulations as are in force. Installation to be carried out by a competent person.

Warning: The guard (glass door) on this appliance is to prevent risk of fire or injury from burns and no part of it should be permanently removed. IT DOES NOT GIVE FULL PROTECTION FOR YOUNG CHILDREN OR THE INFIRM. For the full protection of young children or the infirm, we recommend a fireguard conforming to BS 8423 be fitted.

Never leave the heater operating unattended.



ASSEMBLY INSTRUCTIONS - IN 3 EASY STEPS

If you require any further assistance please do not hesitate to contact us directly at the factory.

HELPLINE DUBLIN IRELAND: Ph: 00 353 1 2873797,

Email: info@saharabbqs.com


1



Test all gas connections for leaks with proprietary leak detection fluid or soapy water applied with a small paintbrush.


Fit the back panel of the heater by positioning the tabs on the bottom of the door into the inside of the rim at the bottom of the heater. Then push the panel flush with the back of the heater and rotate the door catch to the up position to secure the panel.

2



Open the heater door by loosening the thumb screw.
Remove the box containing synthetic logs and cardboard insert from the heater.
Carefully remove the synthetic logs from the box.

3



Place the synthetic logs into the heater grate as shown.
Close door and lock with thumb screw. To fit battery, unscrew ignition button and place battery inside housing. Refit ignition button securely.

(place battery "+" side up)

An odour at first use is normal. Burn on highest setting in a very well ventilated area for 4 hours to cure synthetic logs.

TECHNICAL & SERVICING INFORMATION

Technical and servicing information:

This appliance is designed for indoor use only, using Butane gas at a supply pressure of 28-30 millibar and must be serviced by a fully qualified and competent registered engineer in accordance with the instructions included.

Please read all accompanying documentation carefully.

Technical Specifications:

Overall height:	775 millimetres approximately
Overall width:	460 millimetres approximately
Heat input:	3.4kW (Gross)
Gas consumption:	247 grams per hour at maximum setting
Gas category:	I3B(28-30) using Butane gas at 28-30mbar
Gas type & Supply pressure:	Butane 28-30 mbar
Injector size:	0.9 mm
Cylinder sizes:	11.34kg cylinder (Eire) and 15kg or 7kg cylinder (U.K)
Hose:	Length 40 cm LPG hose compliant to EN 16436-1
Destination Countries:	IE/GB

The product is fully guaranteed for two years regarding proper use.

This guarantee does not affect your statutory rights. For servicing contact your local gas supplier. Servicing to be carried out by a qualified, competent registered gas engineer before the start of every heating season.

For help on this product and our range of products see our website www.saharabbqs.com or contact the factory direct on our Helpline 00 353 1 2873797.

Helpline hours are 9am to 5pm Monday to Friday.

We are located at: Universal Innovations Ltd.
Kilcoole Industrial Estate,
Kilcoole,
Co. Wicklow,
Ireland.

 2797/23

SAFETY INSTRUCTIONS

Do not: Attempt to use the heater in high rise flats, basements, bathrooms or bedrooms.

Do not: Use any other gas except Butane.

Do not: Attempt to clean the heater until it is turned off and fully cooled.

Do not: Use naked flame to detect suspected gas leaks.

Do not: Allow children or pets to play near the heater.

Do not: Twist the flexible gas hose.

Do not: Touch the glass panel or front and sides of the unit while the heater is operating. Allow the unit to cool down for one hour before touching the front or sides.

Do not: Use in leisure vehicles such as caravans and autocaravans.

Do not: Position the appliance close to walls, furniture, hangings, net curtains, bed linen and other inflammable materials as this would result in the risk of fire.

In the event of a gas leak. ie. If you smell gas, turn off the cylinder valve. Disconnect the cylinder, take it outdoors and contact a competent service technician.

Warning:

Never attempt to light the unit if the hose is loose or damaged in any way. Also never attempt to light the unit if you have reason to believe that the unit may be leaking gas. In the event of a gas leak turn off the gas supply at the cylinder and have the unit fully checked by a competent person in accordance with the instructions enclosed. We recommend servicing at the start of every heating season.

Should you need to change the gas bottle, confirm that the gas supply is turned off at the cylinder and that there are no sources of ignition near before proceeding.

This appliance requires a hose and regulator, check with your gas supplier.

Do: Place heater on a flat, level and solid surface at all times.

Do: Leak test the unit after long periods of storage.

Do: Wait for 3 minutes before relighting, if the burner flame becomes extinguished during use.

Do: Ensure that all naked flames are extinguished before fitting a new cylinder.

Do: Store gas cylinders outdoor, above ground level in a safe and secure environment.

Do: Make sure that the gas supply at the gas cylinder is turned off after use.

Do: Ensure that servicing of the unit is carried out by a competent person in accordance with the instructions enclosed.

Do: Allow the unit to cool down for one hour before touching the front or sides.

Always: Follow any safety instructions supplied with gas cylinders.

Always: Keep unit well away from glass doors and windows to ensure no possibility of heat build up and damage.

Always: Service once a year or after a prolonged period of non-use.

Always: Ensure that there is no blockage of airflow. For example sooting and poor burning can be caused by dirt, insects, cobwebs, blocking the airflow to/in the burner.

Cleaning:

Abrasive cleaners are not to be used. Clean unit with a damp cloth when fully cooled.

Gas Cylinders:

This unit is designed for use with a 7kg or 15kg (UK) and 11.4kg Butane gas cylinder (Eire).

Do Not Bring Goods Back To Place Of Purchase.

For help, contact our website www.saharabbqs.com or our factory helpline.

Helpline hours: 9am - 5pm Monday to Friday. Ph: 00 353 1 2873797.