



COMMERCIAL TRAINING TOOLBOX TIPS

Lennox CORE Service App Pre-Install Setup

Applies to Lennox Model L and Enlight Rooftop Units 3-25 tons



Helpful Resources

1. Download installation and service literature from LennoxCommercial.com or LennoxPros.com.
2. [CORE Service App Reference Guide](#) takes you step-by-step through the startup and commissioning procedures.
3. Log in to LennoxPros.com to start the online [CORE Service Curriculum](#).
4. View [Lennox Model L and CORE Control System](#) videos on YouTube.

Required Tools

1. Download the CORE Service App to your mobile devices by scanning these QR codes.



A new or replacement CORE controller will come shipped in a Pre-Install state. The startup technician will use the CORE Service App to set up the unit for operation.

Pair your device to the Lennox CORE Control System to perform the setup steps.

See the excerpt from the [CORE Service App Reference Guide](#) below. Complete instructions are included in the guide.

3. Once connected, the screen shown is a reading of the CORE controller's information.

Tap the Finish button to continue.

4. Congratulations! The unit and CORE Service App have been successfully paired!

The next screen is the unit operation overview screen.

Tap the Menu button. (3 lines in the upper left of the screen) to open the menu.

5. Tap Install.

6. Set the date and time.

Self-Service Technical Support with No Wait Times
Click on the black logos below to download these apps



Download all [Training Toolbox Tips](#)
Register for [Technical Training Webinars](#)

