
ASSEMBLY INSTRUCTION <

MODEL NUMBER: 747E



WARRANTY:

We stand behind our products & service with confidence! If parts damaged or mising please feel free to contact us for a FREE REPLACEMENT.

We warranty this product to be free from defects in materials. This waranty covers one year from the date of orginial purchase.

orginial purchase.

NOTES:


- The item is only intended to be used indoors. The product must be assembled and used in accordance with the provisions of the
- It is recommended that assembly is undertaken by about 2 adults. Please read assembly instructions before assembly and strictly adhere to each step outlined. Estimated assembly time

WARNING:

 WARNIND FOR YOUNG CHILDREN - This product contains small components, please ensure that they are kept away from small children while assembling.

After-sales support email: after-saleservice@outlook.com


PARTS LIST



IMPORTANT:


Please check parts list before you start to assembly. If parts damaged or missing. Contact your seller for a FREE REPLACEMENT. Please provide your order number, a brief message about the issue, and your shipping address. Thank you!

After-sales support email: after-saleservice@outlook.com




After-sales support email: after-saleservice@outlook.com

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED



After-sales support email: after-saleservice@outlook.com

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED



[IMPORTANT:Please completely tighten all the bolts and nuts.]
After-sales support email: after-saleservice@outlook.com