



TOMAHAWK

TG5500i
INVERTER GENERATOR


Operation Manual




LARGE COV



IGNITER



CYLINDER




LARGE COVER			
No.	Part No.	Description	QTY
1	2000.B20.0010.00.00	AIR HOOD COMPONENT	1
2	5787.06018.00.01	BOLT M6×18	8
3	1220.528.R0010.00.00	TENSION DISC	1
4	2000.T70.001V.00.03	HANDLE	1
5	2000.T70.0020.00.02	PULL THE PLATE	1


IGNITER			
No.	Part No.	Description	QTY
1	2100.JB4.0020.00.00	IGNITER	1
2	5787.06012.00.01	BOLT M6×12	4
3	5789.05016.00.01	BOLT M5×16	2
4	2160.168.006V.00.00	SPARK PLUG	1
5	2230.B20.0020.00.00	BOX COVER	1

CYLINDER END			
No.	Part No.	Description	QTY
1	3020.B20.0010.00.00	CYLINDER HEAD GASKET	1
2	3170.168.002V.00.00	LOCATING PIN 10×14	2
3	0900.68120.00.01	BOLT M6×120	2
4	0900.08037.00.01	BOLT M8×37	2
5	0010.B20.0011.00.00	CYLINDER HEAD COMBINATION	1
6	5787.06014.00.01	BOLT M6×14	4
7	5789.08060.00.10	BOLT M8×60	4
8	3000.B20.0010.00.00	CYLINDER HEAD GASKET	1
9	2230.B20.0010.00.00	CYLINDER HEAD AIR GUIDE COVER	1
10	0001.B20.0010.00.00	CYLINDER HEAD COVER COMBINATION	1
11	5787.06018.00.01	BOLT M6×18	4
12	2230.B20.0070.00.00	CYLINDER HEAD COVER	1


SILENCER



CRANKHAFT



CAMSHAT




SILENCER			
No.	Part No.	Description	QTY
1	0845.04016.00.01	SCREW M4×16	4
2	2230.B20.0090.00.00	REAR COVER OF MUFFLER	1
3	5787.08016.00.01	BOLT M8×16	4
4	2400.B20.0010.00.00	MUFFLER	1
5	1689.B20.0010.00.00	MUFFLER BRACKET	1
6	2230.B20.0040.00.00	MUFFLER FRONT COVER	1
7	3100.188.004V.00.00	EXHAUST PORT GASKET	1
8	0097.08000.00.01	FLAT WASHER Φ8	2
9	0093.08000.00.01	ELASTIC WASHER Φ8	2
10	6170.08000.00.01	NUT M8	2
11	5787.06014.00.01	BOLT M6×14	3


CRANKSHAFT			
No.	Part No.	Description	QTY
1	5787.06018.00.01	BOLT M6×18	4
2	2020.F80.0050.00.00	STARTER KIT	1
3	2030.T70.0020.00.00	FAN	1
4	6177.14000.06.01	BOLT M14×1.5	1
5	5787.06012.00.01	BOLT M6×12	2
6	1521.F80.0020.00.00	TRIGGER	1
7	4000.JB4.0020.00.01	MOTOR ROTOR	1
8	5787.06065.00.01	BOLT M6×65	4
9	4000.JB4.0030.00.02	MOTOR STATOR	1
10	3170.188.001V.00.00	LOCATING PIN 8×12	4
11	0180.B20.0012.60.00	CRANKSHAFT COMPONENTS	1

CAMSHAFT			
No.	Part No.	Description	QTY
1	1040.B20.0010.60.00	CAMSHAFT COMPONENTS	1
2	1030.B20.0010.00.00	TAPPET	2
3	0160.B20.0010.00.00	PUSH ROD	2
4	0020.B20.0010.00.00	INTAKE VALVE	1
5	0030.B20.0010.00.00	EXHAUST VALVE	1
6	0060.B20.0010.00.00	VALVE SPRING SEAT	2
7	1120.165.0020.00.00	VALVE COLLET	2
8	0100.B15.0010.00.00	ARM ARM COMBINATION	1
9	0107.B15.0010.00.00	SWING ARM SHAFT PIN STOPPER	1
10	0101.B15.0010.00.00	ROCKER SHAFT	1
11	5787.06012.00.01	BOLT M6×12	1


CRANKCASE COVER



CARBURETOR



PISTON




CRANKCASE			
No.	Part No.	Description	QTY
1	5787.08030.00.01	BOLT M8×30	7
2	1230.164.0021.00.00	OIL DIPSTICK	1
3	1010.B20.0010.00.00	CRANKCASE COVER	1
4	1020.B20.0010.00.00	OIL ALERT	1
5	5787.06014.00.01	BOLT M6×14	2
6	3040.B20.0010.00.00	CRANKCASE GASKET	1
7	0270.B16.0010.00.00	BEARING	1


CARBURETOR			
No.	Part No.	Description	QTY
1	3060.B20.0010.00.00	AIR INLET GASKET	1
2	2300.B20.0010.00.00	CARBURETOR CONNECTOR	1
3	3080.B20.0010.00.00	CARBURETOR GASKET	1
4	2260.B20.C030.00.00	CARBURETOR	1
5	2340.B20.0010.00.00	AIR FILTER STEEL GASKET	1
6	2370.B20.0010.00.00	EXHAUST PIPE	1
7	2280.B20.0010.00.00	AIR FILTER	1
8	2360.458.R003V.00.00	BELT SHAPED TUBING CLAMP Ø8	1
9	2332.487.003V.00.00	OIL PIPE SHEATH	1
10	6177.06000.00.01	NUT M6	2
11	2330.528.C110.00.23	OIL PIPE	2

PISTON			
No.	Part No.	Description	QTY
1	0190.B20.0010.00.00	CONNECTING ROD ASSEMBLY	1
2	0200.B20.0010.00.00	PISTON	1
3	0230.168.001V.00.00	PISTON PIN RETAINING RING	2
4	0220.168.001V.00.00	PISTON PIN	1
5	0210.B20.0010.00.00	ONE PISTON RING	1

STARTING DYNAMO




RIGHT HOUSING




STARTING DYNAMO			
No.	Part No.	Description	QTY
1	5787.06014.00.01	BOLT M6×14	2
2	0845.04016.00.01	SCREW	2
3	2230.B20.0030.00.00	START MOTOR COVER	1
4	1220.528.R0010.00.00	TENSION DISC	1
5	2070.B20.0010.00.00	STARTING MOTOR+DUAL CORE PLUG-IN BOX RELAY	1
6	5787.06035.00.01	BOLT M6×35	2
7	5789.05012.00.01	BOLT M5×12	2
8	4080.520.001V.04.00	NYLON ZIP TIES	1
9	5787.06016.00.01	BOLT M6×16	1
10	1220.528.R0010.00.00	TENSION DISC	1
11	6951.528.0020.00.00	BATTERY WIRING HARNESS	1
12	6950.528.0020.00.00	WIRE HARNESS COMPONENTS	1
13	6950.J24.0010.00.00	WIRE HARNESS COMPONENTS	1
14	6950.JB4.0030.00.00	WIRE HARNESS COMPONENTS	1

RIGHT HOUSING			
No.	Part No.	Description	QTY
1	2222.528.0030.00.00	RIGHT SHELL	1
2	6178.05000.01.04	NUT	6
3	0845.42013.00.01	SELF TAPPING SCREW	7
4	5598.467.001V.00.00	PLUM BLOSSOM HOLE RETAINING RING	4
5	4789.467.001V.00.00	BOLT	3
6	7495.528.001V.00.00	DECORATIVE COVER OF STARTING HANDLE	1
7	5596.528.0070.A6.00	RIGHT APPEARANCE COVER	1
8	1142.528.0030.A6.00	OIL FILLING AND DRAINING MAINTENANCE DOOR	1

LEFT HOUSING




FRAME




LEFT HOUSING			
No.	Part No.	Description	QTY
1	2220.528.0030.00.00	LEFT HOUSING	1
2	6178.05000.01.04	NUT	6
3	5787.06012.00.01	BOLT	2
4	5522.467.002V.00.00	OIL TANK SUPPORT RUBBER SLEEVE B	3
5	4789.467.001V.00.00	BOLT	3
6	5424.528.001V.00.00	SLOTTED HALF ROUND HEAD SCREW	2
7	5596.528.0080.A6.00	LEFT APPEARANCE COVER	1

FRAME			
No.	Part No.	Description	QTY
1	4863.528.0060.00.00	LEFT BRACKET 1	1
2	4863.528.0031.00.00	RIGHT BRACKET 1	1
3	6170.08000.00.07	NUT	8
4	9727.528.001V.00.00	FRONT CROSS BAR	1
5	5787.06012.00.01	BOLT	9
6	2999.528.001V.00.00	LEFT RAIL	1
7	7174.528.002V.00.00	FUEL TANK REAR BRACKET	1
8	2999.528.002V.00.00	RIGHT RAIL	1
9	7174.528.001V.00.00	FUEL TANK FRONT BRACKET	1
10	6177.08000.00.01	NUT	6
11	3360.487.001V.00.00	DAMPING PAD 1	2
12	3340.JB8.0010.00.00	POWER FIXED BASE PLATE 1	1
13	3360.460.002V.00.00	DAMPING PAD 1	2
14	5787.08020.00.07	BOLT	4
15	3340.528.0050.00.00	FLOOR	1
16	6178.05000.01.04	CLIP NUT	4
17	4863.528.0070.00.00	LEFT BRACKET 2	1
18	4863.528.0080.00.00	RIGHT BRACKET 2	1
19	3340.528.002V.00.00	POWER FIXED BASE PLATE 2	1
20	6177.06000.00.01	NUT	2
21	6353.JB8.0030.00.00	FRAME BOTTOM BRACKET	1
22	3360.460.002V.00.00	SHOCK ABSORBER PAD/SQUARE SHAPE	2
23	5787.06025.00.01	BOLT	2
24	2470.JB4.0010.00.00	INVERTER	1
25	5926.467.001V.00.00	SQUARE NUT	6
26	6854.528.0050.00.00	VOLTAGE REGULATING RECTIFIER	1
27	5787.06016.00.01	BOLT	1
28	2461.188.0011.00.00	BATTERY	1
29	4885.528.001V.00.00	BATTERY HOLDER	1

PULL ROD/HOUSING




TAIL COVER




PULL ROD/HOUSING			
No.	Part No.	Description	QTY
1	3200.528.001V.00.03	RUBBER SLEEVE OF OIL FILLING PORT	1
2	0845.42016.00.07	SELF TAPPING SCREW	8
3	5787.06012.00.01	BOLT	10
4	3330.528.0010.00.00	HANDRAIL	1
5	9988.528.001V.00.00	OIL LEVEL WINDOW RUBBER SLEEVE	1
6	8787.528.001V.00.00	OIL LEVEL WINDOW GLASS	1
7	9577.528.001V.00.00	PULL HANDLE SUPPORT FRAME	1
8	0845.35095.00.07	SELF TAPPING SCREW	2
9	9674.528.0030.00.00	UPPER SHELL	1
10	9874.528.0010.04.00	PULL HANDLE ASSEMBLY	1

TAIL COVER			
No.	Part No.	Description	QTY
1	3332.562.0010.00.00	FRONT WHEEL	2
2	5787.06012.00.01	BOLT	2
3	4100.460.R001V.20.00	NON STANDARD FLAT PAD	2
4	0818.05016.00.07	CROSS LARGE PAN HEAD SCREW	6
5	2435.JB8.0010.00.00	MUFFLER SIDE COVER	1

PANEL



FUEL TANK COMPONENTS



PANEL			
No.	Part No.	Description	QTY
1	2140.464.0010.00.00	FOUR-IN-ONE SWITCH	1
2	0819.04212.00.01	SELF TAPPING SCREW	3
3	0818.04020.00.01	CROSS PAN HEAD SCREW	1
4	2141.528.0010.00.00	FOUR-IN-ONE SWITCH HANDLE	1
5	0818.05010.00.07	CROSS PAN HEAD SCREW	6
6	3370.1B8.0030.00.99	CONTROL PANEL COMBINATION	1
7	0818.05016.00.07	CROSS LARGE PAN HEAD SCREW	6
8	6655.528.0040.00.00	PANEL SEAT	1

FUEL TANK COMPONENTS			
No.	Part No.	Description	QTY
1	3200.487.C001.04.01	FUEL TANK CAP	1
2	3200.168.075V.00.05	FUEL FILTER SCREEN	1
3	3200.528.0010.00.06	CIRCULAR ELECTRONIC OIL MARK	1
4	3201.528.C020.D7.00	TANK	1
5	3206.168.R001V.00.00	FUEL TANK OUTLET NOZZLE	1
6	5787.06025.00.01	BOLT	4
7	4100.460.R001V.20.00	NON STANDARD FLAT PAD	4
8	3213.460.001V.00.00	TANK BUSHING	4
9	3217.460.001V.00.00	OIL TANK MOUNTING RUBBER SLEEVE	4
10	2360.458.R003V.00.00	FERRULE	2
11	2330.188.C100.00.23	OIL TUBE	1
12	3200.487.004V.00.02	TANK COVER CHAIN	1



Power Your World

Tomahawk understands to keep a job-site running smoothly the proper equipment and spare parts are needed at the drop of a hat. With same day shipping and faster delivery times, count on Tomahawk to keep you powered throughout the day! With long lasting parts and engines, Tomahawk equipment will be the star of your fleet for years to come. Visit www.tomahawk-power.com to get started today!

TOMAHAWK

TOMAHAWK®, LLC
San Diego, CA

Sales Support
(866) 577-4476
sales@tomahawk-power.com

Equipment Support
(866) 577-4476
support@tomahawk-power.com

www.tomahawk-power.com



FACEBOOK
facebook.com/TomahawkPowerUSA

YOUTUBE
youtube.com/TomahawkPower

INSTAGRAM
[@tomahawkpower](https://instagram.com/tomahawkpower)