

无线蓝牙耳机说明书 蓝牙版本V5.4

参数配置

真正无线连接，实现无缝立体声。左右声道分离，双效，左右耳均具有完全独立蓝牙功能，可单连接，也可双连接，实现双共享模式，主从切换。

注：首次使用本产品前，请先充满电。

①本产品可以与任何一款具有蓝牙功能的设备进行连接使用。

一、简单操作说明

①. 耳机开/关机

- 开机：打开充电盒上盖，取出耳机自动开机。
- 关机：直接放入充电盒关机。

②. 配对：

开机首次配对时，自动进入配对，提示音“嘟”声。

（注意：当没有配对，需重新放入充电盒，关机后开机，再重新配对，才能显示“已配对”成功。）

③. 已连接设备连接切换：

打开耳机“设置”，打开蓝牙搜索，找到“设备”，面对着，逐一选择一下，“已连接”。当耳机在连接第一次后，再次长按麦克风，耳机会自动与手机连接。

二、功能定义说明

①. 蓝牙状态与连接状态

手电筒	长按1-2秒以上
震动震动	轻触任意一边一下
亮度调节	轻触上下一下，长按1-2秒

②. 音乐状态与控制状态

播放暂停	轻触任意一边一下
下一首	轻触任意一边一下
上一首	轻触任意一边一下
减音量	轻触任意一边一下

③. 音频助手

蓝牙连接	长按1-2秒，进入蓝牙连接
接听电话	长按1-2秒，接听电话

三、充电仓定义和参数

产品状态	指示灯显示 电量剩余，空电
2.5米远	显示电量百分比
充电仓	显示电量
插入孔	充电孔，支持快充
耳机充电口	耳机充电口
Micro USB	Micro USB充电线，适配器
3.5mm插孔	音频线
麦孔	麦克风孔

功能	描述
充电仓容量	3000mAh
充电电压	DC 5V 2A
充电仓电流	DC 5V 200mA
充电仓待机	≤10分钟
通话能力	≥10小时(待机)

注意事项

- 请勿暴力拆卸产品，也不要随意拆卸，以免造成安全隐患，如果出现故障或损坏，建议到正规维修点维修。
- 长时间连续使用（约4-5小时）会使电池过热，严重时可能会导致电池起火或爆炸，不要在极端环境下使用。
- 不要长期不充电，一个月内将耳机电量耗尽进行充电。

保修

①. 保修卡

尊敬的客户，感谢您购买本公司产品，为了便于维修及为您提供售后服务，请认真填写以下信息：

②. 保修说明

- 本保修卡是用户必备凭证，以作维修凭证。
- 本产品自购买之日起保质期为12个月。
- 保修期内若在保修期内，在正常使用和维护的情况下，若因本公司生产制造原因，发生故障，本公司免费维修并承担维修费用。
- 在保修期间，若发生下列情况，本公司有权拒绝维修并要求赔偿维修材料费、邮资费。

③. 保修期限及维修情况

④. 保修期限

⑤. 保修情况

- 不能多枚体半导体及石英购买凭证。
- 用户购买不合格的产品及损坏及损坏。
- 人为破坏证据。
- 未经授权修改的维修服务及维修中心损坏。
- 向顾客销售或出售不可抗力因素造成损坏及损坏。
- 其他人为故意损坏。



新家乐点

WIRELESS BLUETOOTH HEADSET MANUAL BLUETOOTH VERSION V5.4

Parameter configuration

Real wireless connection, wireless stereo left and right channel separation, left ear independent, left and right ears have complete Bluetooth function, can be used alone, can also be used in pairs, using dual-mic intelligent noise cancellation function.

①. ②. And the system connected are inserted.

Open the phone "Settings", then the "Bluetooth" switch - find the "BT390" pairing name, click "Connect" - display "Connected". When the phone connection is completed, use the first point again, the car will automatically connect with the phone.

Note:

- ① before using the product, please full charge it.
- ② this connection can be with the one which has the function of Bluetooth devices. Connection to use.

一、Simple instructions

①. The headset on/off:

- Power on: open the cover charge storage box, remove the headset automatically switched on.
- Turn off: directly drop it into the storage box.

②. Setting:

Automatic pairing is performed when the device is powered on. After the pairing is successful, a beep tone is displayed. Note: If there is no pairing, you need to put it back into the charging box, close the cover and turn on the case, then the "sleep" pairing is easier.

③. ④. And the system connected are inserted.

Open the phone "Settings", then the "Bluetooth" switch - find the "BT390" pairing name, click "Connect" - display "Connected". When the phone connection is completed, use the first point again, the car will automatically connect with the phone.

二、Function definitions

①. Function definition of state

Phone answering	Touch either side 1 time
Hang up the phone	Touch either side 1 time
Call connection	Press and hold either side 2 seconds

②. Function definition in music state

Play & pause	Touch either side 1 time
Previous song	Touch either side 1 time
Next song	Touch either side 1 time
Add volume	Touch either side 3 times
Reduce the volume	Touch either side 3 times

③. Voice assistant

Apple system	Wake up Siri, Press and hold 3 seconds
Android system	Support to wake up the voice assistant, tap & hold 3 seconds

三、Charging bin definition and parameters

Product status

Indicate light display

Charging status

Indicate light

Charging voltage

Charging current

Charging time

Standby time

Indicate light

Charging box

Indicate light

Charging box capacity

Charging box current

Charging box voltage

Charging box time

Standby time

Indicate light

Warning: Please do not force the signal reception of the machine, resulting in sound card break and disconnection.

- Please use this product in an effective environment (10 meters), and there is no physical barrier such as wall, door between the Bluetooth device and the box.
- If the product is not used for a long time, charge the headset and have put it in new condition.

Warranty card

Please customer, thank you for buying our products, in order to better serve you, after the purchase of products, please carefully read, fill in and properly keep the warranty card.

Warranty specification

1. Please keep the warranty card for reference.

2. This product is guaranteed for 8 months from the date of purchase.

3. Service equipment during the maintenance period. In the case of normal use and maintenance, the machine has functional problems, fill in, verified, the company provides free maintenance service.

4. During the warranty period, the following items are, the company not bear the right to maintain or charge materials and costs fees as appropriate.

①. Unable to provide the passenger and valid proof of purchase.

②. Product is law and damage caused by incomplete use of the user.

③. Non-made or thermal damage.

④. Damage caused by disassembly and repair not authorized by the company.

⑤. Damage caused by natural disasters or other force majeure factors.

⑥. Other people's intention damage.

⑦. The company reserves the right to modify and improve all contents.

Warranty

①. Contact information

Customer service

Product code

Delivery number

User

Causes of failure and treatment

①

②

③

④

⑤

⑥



Touch position

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.