


# Team Scoreboard Clock with Bluetooth® Wireless Technology Instructions

(model#7CL-I)



## Setting the Clock:

When setting the clock for the first time, follow all directions in order.


- 1. Set the year:** Push button A and the 4-digit year will flash. Adjust the year by using buttons B or C.
- 2. Set the date:** Push button A and the month will flash. Adjust the month by using buttons B or C. Push button A again and the day flash. Adjust the day by using buttons B or C.
- 3. Set the time:** Push button A and the hour will flash. Adjust the hour by using buttons B or C. Push button A again and the minutes will flash. Adjust the minutes by using buttons B or C.
- 4. Activate the unit:** Push button D to activate the clock.

**Note:** The temperature is preset and will adjust automatically.

## Changing from the 12 to 24 hour time format:

1. Hold the B button down for 3 seconds to switch between the 12/24 hour time formats.

- (A) Set Button
- (B) Upward Adjust
- (C) Downward Adjust
- (D) Activate



# **USER'S MANUAL: BLUETOOTH® TECHNOLOGY SPEAKER GET CONNECTED IN 3 QUICK STEPS**

**Contents:** 1-Team Scoreboard Clock with Bluetooth® Technology, 1 - Power Cord

## **No Tools required**

### **BEFORE YOU BEGIN**

Before using this product, read the important Safety and Legal information and follow its instruction. Take a moment before you get started to familiarize yourself with your new Bluetooth® technology speaker.

### **1. START BLUETOOTH® TECHNOLOGY FEATURE ON YOUR SMARTPHONE**

Your phone's Bluetooth® technology feature is off by default. To use your speaker, you must turn on the Bluetooth™ technology feature on your smartphone. On your device under "settings" turn on your Bluetooth® program.

### **2. PAIR YOUR BLUETOOTH® TECHNOLOGY SPEAKER**

Before you can use your speaker, you must pair (link) it to your smartphone for the first time.

**Step A - Plug in the clock using the included Power Cord.**

**Step B - Turn on the Bluetooth® technology speaker. Power switch located on the side of the clock.**

**Step C - Under "settings" on your device, turn on your Bluetooth® program.**

**Step D - When your device finds the new Bluetooth® technology speaker, the display will show My Team, please select it to pair it with your smartphone.**

When the Bluetooth® technology speaker is successfully paired with your smartphone the blue indicator light on the Bluetooth® technology speaker will change from single long flashes to double short flashes. Once the pairing is complete the clock a chime will sound letting you know the pairing was successful.

Note: These steps are for most smartphones. For some special phones, please see your phone's user's guide.

### **3. TEST AND USE**

Your smartphone and Bluetooth® technology speaker are now paired and you are ready to play music.

**To play music with the Bluetooth® technology speaker:**

- a. Open the music player on your smartphone or Bluetooth® device and select one song on your music list and the Bluetooth® technology speaker will begin playing.
- b. Adjust the volume from the music player on your smartphone or Bluetooth® device.

This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**This equipment should be installed and operated with a minimum distance 20cm between the transmitter and your body.**


Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The Bluetooth® wordmark and logos are registered trademarks owned by Bluetooth® SIG, Inc. and any use of such marks by Evergreen Enterprises of Virginia, LLC is under license. Other trademarks and trade names are those of their respective owners.



© EVERGREEN ENTERPRISES OF VIRGINIA, LLC  
RICHMOND, VA 23225  
WWW.MYEVERGREEN.COM  
MADE IN CHINA

# Horloge tableau de pointage avec technologie sans fil Bluetooth®



(model#7CL-I)

## Ajustement de l'horloge :

Lors du premier ajustement, suivre ces étapes dans l'ordre.


- 1. Ajustement de l'année:** Appuyer sur la touche A. Les 4 chiffres de l'année se déclencheront. Utiliser les touches B et C pour ajuster l'année.
- 2. Ajustement de la date:** Appuyer sur la touche A. Les chiffres du mois se déclencheront. Utiliser les touches B et C pour ajuster le mois. Appuyer sur la touche A de nouveau, et les chiffres de la journée se déclencheront. Utiliser les touches B et C pour ajuster la journée.
- 3. Ajustement de l'heure:** Appuyer sur la touche A. Les chiffres de l'heure se déclencheront. Utiliser les touches B et C pour ajuster l'heure. Appuyer sur la touche A de nouveau, et les chiffres des minutes se déclencheront. Utiliser les touches B et C pour ajuster les minutes.
- 4. Activer l'horloge:** Appuyer sur la touche D pour activer l'horloge.

**Note:** La température s'ajuste automatiquement.

## Changer le format de l'heure pour le système horaire sur 24 heures :

1. Appuyer la touche B pendant 3 secondes pour changer le format de l'heure.

- (A) Touche de position
- (B) Touche d'ajustement ascendant
- (C) Touche d'ajustement descendant
- (D) Touche d'activation



# **MANUEL DE L'UTILISATEUR : HAUT-PARLEUR BLUETOOTH® BRANCHEZ-VOUS EN 3 ÉTAPES RAPIDES**

**Contient:** 1- Tableau de pointage d'équipe avec technologie Bluetooth®, 1 - Fil d'alimentation

## **Aucun Outil Requis**

### **AVANT DE COMMENCER**

Avant d'utiliser ce produit, il est important de lire les informations de sécurité et légales et de suivre les instructions. Prenez quelques instants avant de commencer pour vous familiariser à votre nouveau haut-parleur Bluetooth®.

### **1. ACTIVEZ LA FONCTION BLUETOOTH® SUR VOTRE TÉLÉPHONE INTELLIGENT**

La fonction Bluetooth® de votre téléphone est éteinte par défaut. Pour utiliser votre haut-parleur, vous devez activer la fonction Bluetooth® sur votre téléphone intelligent. Dans le fichier "Paramètres" de votre appareil, activez la fonction Bluetooth®.

### **2. SYNCHRONISEZ VOTRE HAUT-PARLEUR BLUETOOTH®**

Avant de pouvoir utiliser votre haut-parleur, vous devez le synchroniser à votre téléphone intelligent pour la première fois.

**Étape A - Branchez le tableau avec le fil d'alimentation.**

**Étape B - Allumez le haut-parleur Bluetooth®. L'interrupteur est situé sur le côté du tableau.**

**Étape C - Dans le fichier "Paramètres" de votre appareil, activez la fonction Bluetooth®.**

**Étape D - Quand votre appareil trouve le haut-parleur Bluetooth®, l'affichage indiquera "My Team", veuillez le sélectionner pour le synchroniser à votre téléphone intelligent.**

Quand la synchronisation est réussie entre le haut-parleur Bluetooth® et votre téléphone intelligent, le témoin lumineux bleu du haut-parleur Bluetooth® passera de longs clignotements à un court clignotement double. Une fois la synchronisation réussie, un son sera émis, vous indiquant que la synchronisation est faite.

Note : Ces étapes fonctionnent pour la plupart des téléphones intelligents. Pour certains téléphones spéciaux, veuillez consulter le guide d'utilisateur de votre téléphone.

### **3. TESTEZ ET UTILISEZ**

Votre téléphone intelligent et votre haut-parleur Bluetooth® sont maintenant synchronisés et vous pouvez maintenant faire jouer de la musique.

**Pour faire jouer de la musique dans votre haut-parleur Bluetooth®:**

a. Ouvrez le lecteur de musique sur votre téléphone intelligent ou sur votre appareil Bluetooth® et choisissez un morceau sur votre liste musicale, puis le haut-parleur Bluetooth® fera entendre cette pièce.

b. Ajustez le volume à partir du lecteur de musique sur votre téléphone intelligent ou sur votre appareil Bluetooth®.

Ce produit a été testé et est conforme aux limites pour appareils numériques de classe B, en vertu de la Section 15 des règlements de la FCC. Ces limites sont conçues pour assurer une protection raisonnable contre une obstruction nuisible dans une installation résidentielle. Ce produit génère, utilise et peut irradier des radiofréquences et, s'il n'est pas installé et utilisé selon les directives, peut causer une obstruction nuisible aux communications radio. Toutefois, il n'y a aucune garantie que cette obstruction ne se produira pas dans une installation particulière. Ce produit cause une obstruction nuisible à la réception des ondes radio et de télévision, ce qui peut être déterminé par l'activation et la désactivation de l'équipement, l'utilisateur est encouragé à tenter de corriger l'obstruction par l'application d'une ou de plusieurs de ces mesures :

—Réorienter ou relocaliser l'antenne de réception.

—Accroître la séparation entre l'équipement et le récepteur.

—Brancher l'équipement dans une prise sur un circuit différent duquel le récepteur est branché.

—Consulter le détaillant ou un technicien radio/télé expérimenté pour avoir de l'aide.

Cet appareil est conforme à la Section 15 des règlements de la FCC. Le fonctionnement est assujéti aux deux conditions suivantes:

(1) Cet appareil ne peut pas causer d'obstruction nuisible, et

(2) Cet appareil doit recevoir toute obstruction reçue, notamment l'obstruction pouvant causer un fonctionnement non désiré.

**Cet équipement devrait être installé et être utilisé sur une distance d'au moins 20 cm entre l'émetteur et votre corps. Avertissement:**

Des changements ou des modifications à cette unité qui ne sont pas explicitement approuvés par la partie responsable en matière de conformité pourraient annuler l'autorité de l'utilisateur à faire fonctionner l'équipement.

The Bluetooth® wordmark and logos are registered trademarks owned by Bluetooth® SIG, Inc. and any use of such marks by Evergreen Enterprises of Virginia, LLC is under license. Other trademarks and trade names are those of their respective owners.



© EVERGREEN ENTERPRISES OF VIRGINIA, LLC  
RICHMOND, VA 23225  
WWW.MYEVERTGREEN.COM  
MADE IN CHINA