

RECLINING CHAIRS



LIGHTWEIGHT

ADJUSTABLE

STRONG

FOLDABLE

EN USER INSTRUCTION & OPERATION MANUAL

EN



Thank you for purchasing this SUNMER product.

Please read the user manual carefully before using this product.

We will update our instruction manuals if necessary.

For the most up-to-date user manual, please visit our official website:
www.netta.co.uk.

You can download a copy of up-to-date user manuals at any time in electronic format. We do not supply you with a paper-based user manual after each revision.

**Require a larger version of this
Instruction Manual?**

**Please download electronically from
our website and use PDF reader on
your device to enlarge the text if
needed.**

www.netta.co.uk



SAFETY & WARNINGS

INTENDED USE

SUNMER products are for private and residential use only. This product is not intended for use in public places such as hotels, sports grounds, etc.

REGULAR CHECKUPS

- Ensure the fabric seats do not have any rips or tears before use.
- Ensure plastic arms are intact and have no sharp points.

RISK OF PERSONAL INJURY

- Do not use the appliance other than for the intended use.
- Take care when putting this chair in the recline position.
- Ensure fingers do not get trapped in the mechanisms.
- Failure to completely unfold the chair will result in the chair tipping over which may cause injury.
- Placing the chair on an uneven, unlevelled, or unstable surface will result in the chair tipping over which may cause personal injury.
- Never attempt to sit in the chair whilst it is in the reclined position. Only attempt to sit in the chair whilst it is in the upright position.

ASSEMBLING THE PRODUCT

1. The chair folds for easy transportation




2. Unfold the chair completely before using



3. To recline, push back with your body while elevating your feet. Resistance tabs on the arms allow the chair to stop in any position.




4. To return to the upright position, pull forward with your body while pushing downward with your feet.



How to add the side tray to your chair?

① Unfold the chair



③ Install Instruction

② Install the side tray





CLEANING & STORAGE

Cleaning

- While the chair is dry, use a soft bristle brush to brush away loose dirt or mould.
- Use mild soap, warm water, and a clean cloth/soft bristle brush to wipe over the material of the chair and remove any dirt.
- Then use warm water to rinse the remaining cleaning mix, dirt, and debris away.
- Leave the chair in direct sunlight and let it dry completely.

Storage

- To prolong the life of these chairs, it is recommended that they are stored inside or in a sheltered area.

SPARE PARTS/REPAIR

We hope our products will last as long as possible to reduce the build-up of waste in the world.

If any consumable parts need replacing, please check our website for stock availability and purchase.

If our website does not have the parts listed, but you still need consumable parts, please contact our customer support to check availability and process your order.

To order replacement parts, please go to netta.co.uk/collections/parts

You will need PDC information from your product, user manual or carton box. Alternatively, go to our website and use search bar to find the parts available.

You can also find this code on the [back of this User Manual](#).

For our Repair Service, please contact our customer support with email on support@netta.co.uk they will provide with more details of repair service with NETTA.

DISPOSAL OF PRODUCT

IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH EC DIRECTIVE 2002/96/EC.

DISPOSAL:

Please dispose of this product responsibly. This item cannot be disposed of with general waste. Please contact your local council authority for more information on how to dispose this product. If this product is disposed of with general waste, it will end up in a landfill and may leak hazardous substances into the groundwater – effecting our food chain.



YOUR WARRANTY

If you purchased with NETTADIRECT, or one of our authorised resellers, you will automatically enrol your warranty for 1 (ONE) year. You do not need to register again for your warranty. All warranties will be carried out to our terms and conditions including warranty conditions you will find out from our website at www.netta.co.uk.

PLEASE NOTE: Consumable parts will not be covered by warranty. If a consumable part needs replacing, you need purchase separately from our website.

Please quote with your original proof of purchase (invoice) and name or delivery address, postcode, so we can locate you when you contact us for warranty.

NOTES:

You may need fill following details after your purchase.

I purchased this product with _____
(Name of Authorised Reseller/Distributor)

Purchase Date: ____/____/____



COPYRIGHTS

SUNMER is a part of the NETTA brand. NETTA and its logo including images and contents in this manual and website is copyrighted. All intellectual property rights belong to NETTA owner CONSUMABLE DIRECT LIMITED.

ANY UNAUTHORISED USE, MODIFICATION or DISTRIBUTION of the NETTA logo, website image, and its contents (from website, manuals) will violate worldwide copyright, trademark, and associated laws.

We reserve the right to proceed with lawsuits to anyone who is found breaching our copyrights policy. For more details, please check our website copyright policy for more information.

PRODUCT DEPENDENCY CODE (PDC)

Your PDC is below:

PDC: FCZ001
SKU: 103362/103363

SUNMER is a registered trademark of CONSUMABLE DIRECT LIMITED.
Product Produced for CONSUMABLE DIRECT LIMITED, 78 CAWDOR
STREET, ECCLES, GREATER MANCHESTER, M30 0QF, U.K.

Printed in China