

IKR8083\_

IKR3073\_

Instructies voor installatie

**Inductiekookplaat met afzuigunit**

Instructions d'installation

**Table de cuisson à induction avec extracteur**

Installationsanleitung

**Induktionskochfeld mit integriertem Abzug**

Installation instructions

**Induction hob with extractor**






**Recirculation**  
HF2027  
HD4003  
HF4004  
HD2014  
HD2015




**OK!**






Hob: 2-2N: 220-240V - 50/60 Hz - 7.6 kW  
2N: 380-415V - 50/60 Hz - 7.6 kW  
1N: 220-240V - 50/60 Hz - 7.6 kW  
1N: 220-240V - 50/60 Hz - 3.7 kW




Vrije ruimte rondom toestel  
Espace libre autour de l'appareil  
Freier Raum rundum das Gerät  
Free space around appliance



A (mm)    B (mm)    C (mm)  
min. 550    min. 150    min. 40







|          | X   | Y   |
|----------|-----|-----|
| IKR3073_ | 558 | 700 |
| IKR8083_ | 755 | 830 |



|          | Z   |
|----------|-----|
| IKR3073_ | 560 |
| IKR8083_ | 760 |


## Standard installation









OPTION A




OPTION B



OPTION C










OPTION D







## OPTION B









**2N 380-415V 50/60Hz - 2x 16A** ⇌

2 fase - 1 nul  
2 phases - 1 neutral  
2 Phasen - 1 Nullanschluss  
2 phases et 1 neutre




**1N 220-240V 50/60Hz - 1x 32A** ⇌

1 fase - 1 nul  
1 phase - 1 neutral  
1 Phase - 1 Nullanschluss  
1 phase et 1 neutre




**3N 380-415V 50/60Hz - 3x 16A** ⇌

3 fase - 1 nul  
3 phases - 1 neutral  
3 Phasen - 1 Nullanschluss  
3 phases et 1 neutre





**2-2N 230V 50Hz - 2x 16A** ⇌














2 fase - 2 nulle  
2 phases - 2 neutral  
2 Phasen - 2 Nullanschlüsse  
2 phases et 2 neutres




only NL/alleen NL



Controleer de correcte werking van het toestel. / Vérifier le bon fonctionnement de l'appareil.  
Überprüfen Sie die korrekte Funktion des Geräts. / Verify the correct functioning of the appliance.





**1** ✓

Max. 70°


**2** ✓

2H - Max. 70°

Elke 3 tot 4 maanden  
Tous les 3 à 4 mois  
Alle 3 bis 4 Monate  
Every 3 to 4 months

Max. 8x

HF2027





Op onze website kunt u de meest recente versie van het installatievoorschrift vinden.

Die neueste Version der Installationsanleitung finden Sie auf unserer Website.

Vous pouvez trouver la version la plus récente des instructions d'installation sur notre site Web.

You can find the most recent version of the installation instructions on our website.

[www.pelgrim.nl](http://www.pelgrim.nl)

[www.pelgrim.be](http://www.pelgrim.be)



941354

**Pelgrim**