

Important: Read all instructions prior to installation.

IT5-xKx-120V Series

Linkable Integrated T5 Linear LED Light

Safety and Notes

- Product should be installed in accordance with applicable national, state, and local electrical codes.
- To reduce the risk of electric shock, ensure that the main power source is switched off before performing any installation or wiring procedures.
- Product is for use in dry, indoor locations only.
- When installing multiple lights in a run, make sure to check for voltage drop. Minimum voltage must be maintained to avoid damaging lights. Maximum connected lights for a single run should not exceed the number listed in the table below.



Included Accessories

- Surface mounting bracket (x2)
- Mounting screws (x2)
- Tube to tube butt connector (x1)
- Tube endcap (x1)
- 6 in. pigtail power adapter (x1)

Optional Accessories

- 48 in interconnect (IT5-I48)
- 48 in power cord (IT5-IP48)
- 48 in power cord with built-in-switch (IT5-IPS48)

Specifications

IT5-xKx-x	
Operating Temperature	-4°–104° F (-20°–40° C)
IP Rating	IP20
Max Run	6

Check product label for specific electrical specifications related to installation.
Improper installation will void warranty.

Installation Instructions

1. Remove supply power.
2. Drill pilot holes for mounting screws and install mounting clips approximately 1/4 of the total length from each end of fixture. For example, about 3 in. from each end of a 12 in. fixture. Repeat for all fixtures in the run.
3. Snap fixtures in place. Make connections between fixtures using supplied butt connector or optional interconnect cable.
4. Use tube end cap to cover unused power connector on the last fixture in the run.
5. Connect power cord to the first light in the run and plug into appropriate outlet.

