


EARBUDS ON



EARBUDS OFF




CORDED CHARGING




WIRELESS QI CHARGING

Charger not included



WAKE CASE

Tap the screen or press the button on back to wake charge case from sleep.



DOWNLOAD APP

Download Poly Lens App to get the most out of your wireless earbuds.


- Customize swipe features
- Change settings
- Update devices
- View user guide

↓ poly.com/lens

Poly Lens Mobile App
Poly Lens Desktop App


BLUETOOTH TRANSMITTER

Listen wirelessly to an inflight entertainment system or other audio source with a 3.5 mm port. Connect your case to audio port with included 3.5-mm-to-USB-C cable.



QUICK START


VOYAGER FREE 60+ UC
WITH TOUCHSCREEN CHARGE CASE





BT700 Bluetooth™ adapter
design may vary

CONTROLS

Button



Swipe




- Use either earbud

- Use either earbud
- Swipe slowly
- Customize in Poly Lens App

Volume

Adjust on charge case or paired device




Streaming media only:
swipe earbud




PAIR


Mobile phone | Remove earbuds from the charge case before pairing.



Computer



FIT | Rotate the earbuds toward your mouth for optimum fit and sound.




EARTIPS | Select size for comfort and bass response.


Sizes



Remove at eartip's base



Replace



© 2023 Poly. Bluetooth is a registered trademark of Bluetooth SIG, Inc. All trademarks are the property of their respective owners. Manufactured by Plantronics, Inc. Model IDs: **earbuds** F60T (F60TR, F60TL) **adapter** BT700/BT700C **charge case** CBF60+
211720-06 01.23



Recyclable where facilities exist