

## WARRANTY & SUPPORT

La Crosse McCormick, LLC provides a 2-year limited warranty on this product against manufacturing defects in materials and workmanship. Under the Song-Beverly Act, in the state of California, the warranty on this item becomes effective on the date of delivery.

If a defect that is covered by this warranty arises during the warranty period, promptly return the product (postage prepaid) with proof of purchase showing the date of purchase to the following address and such defects will be repaired, or the product will be replaced at La Crosse McCormick, LLC option without charge.

La Crosse Clock Company  
Warranty Department  
2830 South 26<sup>th</sup> Street.  
La Crosse, WI 54601

For Online support visit: [www.lacrossetechnology.com/support](http://www.lacrossetechnology.com/support)  
Patents: [www.lacrossetechnology.com/pages/patents](http://www.lacrossetechnology.com/pages/patents)

## LET'S BE SOCIAL!

Ask questions, watch set up videos, and provide feedback on our social media outlets. Follow La Crosse Technology on Youtube, Facebook, Instagram, and X (Twitter).



**WARNING:** This product can expose you to chemicals including acrylonitrile, 1, 3-butadiene, and styrene, which are known to the State of California to cause cancer and birth defects or other reproductive harm.

For more information go to: [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

Made in China - Printed in China

Page | 4


## Analog Quartz Alarm Clock



Model: 617-3816B  
DC: 071024

## Power up

1. Insert 1 fresh AA battery into your clock according to polarity.
2. Turn the Time Set Knob clockwise to set your time.



## Time Alarm Set:

Turn the Alarm Set Knob counter clockwise to set alarm time.

### Activate/Deactivate:


- Slide the Alarm ON/OFF switch to ON to activate your alarm.
- Slide the Alarm ON/OFF switch to OFF to deactivate your alarm.

### Snooze:

When the alarm sounds, press the  **Zz** button to silence the alarm for 4 minutes. Snooze may be repeated.

The alarm will increase in frequency and sound for 45 minutes if not snoozed or turned off.

## On-Demand Backlight

Press and hold the  **Zz** button to activate the Backlight; the light will stay on until the button is released.

## Specifications

**Alarm Duration:** 45 minutes

**Alarm Beeping Sound:** 68-95dB

**Snooze Duration:** 4 Minutes

**Backlight:** On-Demand (Press & Hold)

**Movement:** Quartz – Step Motion

**Lens Type:** Plastic

**Construction:** Plastic, Glass, Metal

**Power Requirements:** 1 "AA" Alkaline Battery (Not Included)

**Battery Life:** 12+ Months (1 Battery)

**Dimensions:** 4.45 in L x 1.95 in W x 4.45 in H (11.3cm L x 4.95cm W x 11.3cm H)



## Care & Maintenance

When batteries of different brand or type are used together, or new and old batteries are used together, some batteries may be over-discharged due to a difference of voltage or capacity. This can result in venting, leakage, and rupture and may cause personal injury.

- Always purchase the correct size and grade of battery most suitable for intended use.
- Always replace the whole set of batteries at one time, taking care not to mix old and new ones, or batteries of different types.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the battery is installed correctly with regard to polarity (+ and -).
- Remove the battery from product during periods of non-use. Battery leakage can cause corrosion and damage to this product.
- Remove a used battery promptly.
- For recycling and disposal of the battery, and to protect the environment, please check the internet or your local phone directory for local recycling centers and/or follow local government regulations.