



Original	Recharge
	 Input / RDS
	 Power
	 Digital / OPT /
	 TV / Radio /
	 Exit / Cancel / Clear
	 Display / Media
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 Info / Angle
	 0

Original	Recharge
	 Text / Goto
	 Shift + Yellow / YouTube /
	 Shift + Red / Netflix /
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Guide / EPG / -/-
	 D.Menu / Top
	 Up
	 Shift + Green / APP /
	 Left
	 OK
	 Right
	 Back / Return
	 Down
	 Menu / Home



