


papalook.

Hello



5 INCHES 1080P FULL HD
Baby Monitor

Model: E95A

User Manual

papalook.

For more information, please visit our official website
www.papalook.com

Your valuable comments and suggestions on improving
papalook products are welcomed!

support@papalook.com www.papalook.com

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, Pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

1.Packing List

Camera Unit*1
Monitor Unit*1
Type-C Power Cable*1
Micro Power Cable*1
Charging Plugs*2
User Manual*1


2.Camera Brief Introduction



- 1080P Lens
- Microphone
- Sensillum Opticum
- Decorative Hole
- Camera Recording TF Card Slot
- Temperature Sensor
- Reset Button
- Power Socket
- Heat Emission Hole
- Speaker Hole

3.Screen Introduction

TF Card Slot



RET/Menu Switch Camera

Select Button/Camera Rotation Button

OK/Zoom in Sound/Brightness

Interphone Power

Sound Detection Switch/Alarm Confirmation

Antenna

4.Screen Icons



- 1.Signal
- 2.Power
- 3.Sound
- 4.Temperature
- 5.Feeder Reminder Clock
- 6.Music
- 7.Sound Detection
- 8.Real-time Carousel
- 9.Camera Channel
- 10.Time

Low Power No Signal Temperature Alarm

Feeder Reminder

5.Menu Introduction

AOD: You can set the screen display time (the screen enters screensaver state and enable power saving mode)

Video Recording: You can turn on or off the video recording. (This function requires insertion of TF card. Support camera or screen recording. Please use Class 4 TF card, MAX 256GB)


Alarm Clock: You can set meal time regularly (you can loop the alarm or turn it off)

Noise Detection: The screen will alarm if a sound is detected, like a child's crying. (You can select 4 sensitive modes, including low, medium, high and turn off)

Temperature Measurement: The ambient temperature can be detected in real time, the screen will alarm if it is lower than 18° (65F) or higher than 30° (86F)

Music: You can play a variety of soothing music

6.Connect to the Camera



- 1.Position your Camera no lees than 10 feet away from your baby's crib.
- 2.Press and hold Power Button 5 second.
- 3.You will hear "System starting up" 8-10 seconds after startup and then start working.

7. Q&A

Q: The LCD screen shows no image.
A: 1. Please make sure the camera is turned on
2. Please reset the camera and reconnect if there is still no image when the camera is turned on.

Q: The screen power runs out very fast.
A: The display will always be in monitor mode and use time will be shortened if screensaver mode is not turned on. So, we recommend to set the screen entering screensaver mode when not to operate for certain time, which can save unnecessary electricity.

Q: There will be noise when you call and the camera is too close to the screen.
A: This is a normal physical phenomenon. Noise will be generated when the two microphones are too close. This problem can be solved by turning down the screen sound or widen the distance between them.

Q: How to turn off the alarm?
A: Press the alarm confirmation button to turn it off.

8. Notes

- Turn off the power and store the LCD screen in a dry environment.
- Please charge the screen for 1 hour every 2 months if you don't use it for a long time
- Use dry cloth to clean if necessary.
- Don't drop the screen or camera from a height or onto a hard surface.
- Don't expose the screen or camera to extreme temperatures. (Recommended storage temperature -10°C to 60°C)
- Screens and cameras are not waterproof. Don't expose the screen or camera to rain or allow liquids to enter any button ports or other openings.
- Don't twist or bend the screen. This may lead to permanent deformation.
- Don't put the internal battery in the fire to avoid explosion.
- Please use the original charging plug and charging cable to avoid accidents.

9. Warranty

Papalook E95A is covered by a 1-year warranty. For more information, please visit: www.papalook.com/