
HiFuture Yacht TWS Earbuds User Manual **CHARGING**




Device Overview 1. Microphone

- 2. Tap area
- 3. Earbuds indicator light
- 4. Microphone
- 5. Earbuds charging interface
- 6. TYPE C charging port
- 7. Earbuds case indicator light








3 If the earbuds do not charge, please clean the charging slot in the charging case and contact point surface on the earbuds.



IMPORTANT NOTES

Before using Yacht wireless earbuds, please charge both of charging case and

2 If both earbuds do not pair together, please reset the earbuds, see page 7.




POWER ON

POWER OFF









Automatically

Note: When the charging case is at low battery or out of power, the earbuds will not automatically power on/off, please turn them on/off manually.

WEARING





1 Put the earbuds into your ears.

Rotate the earplugs to adjust the comfortable Angle

Please fully charge the Yacht after unboxing. Use Type-C cable to charge the charging



INDICATORS' DESCRIPTIONS

1. Earbuds


Power ON	Power OFF	Pairing	Connected	Fully Charged
LED flashes orange for 1Second	LED flashes white for 1Second	LED flashes orange and white alternatively	LED off	LED off




2. Reset Indicators Earbuds orange LED lights flash three times.

3.Charging Status

status indicator LED lights in It will shine when you charge the earbuds in.	the middle of two earbud
Battery 100% - 75%	4Lights
Battery 75% - 50%	3Lights
Battery 50% - 25%	2Lights
Battery 25% - 0%	1Light



TAP CONTROL



CONNECT THE EARBUDS





Power on the earbuds and turn on the Bluetooth in your phone.

2 Tap "HiFuture Yacht" from the martphone's Bluetooh menu There's a voice prompt "You are Connected to HiFuture" after successfully connecting with smartphone, and the indicator will be off automatically.


HOW TO RESET THE EARBUDS

If your earbuds stop syncing with each other, please follow below steps to reset the earbuds

Make sure the Yacht were disconnected with phone or other Bluetooth devices.



Put both earbuds into charging case for 5 seconds and then take them out, QUICKLY TAP L or R earbud 5 times, there will be a prompt sound "Reset Succeed", which means the Yacht has been reset successfully.





3 Put them back into charge case, and the Yacht is ready to use.

HiFuture SIMPLIFIED EU DECLARATION

Hereby, SHENZHEN FUTURE ACCESS TECHNOLOGY CO., LIMITED declares that the radio equipment type HiFuture earbuds. mentioned in this manual is in compliance with Directive 2014/53/EU.

Manufacturer: SHENZHEN FUTURE ACCESS TECHNOLOGY CO., LIMITED Address: B-206, Block B, Tsinghua Unis Inforport, Hi-Tech Park(North), Nanshan District, Shenzhen, China.











MORE VALUABLE

For more information, please visit: www.hifuturegroup.com

For any assistance, email us:

info@hifuturegroup.com







