

FAQ

Q. How does the cleaning performance of the Roomba® i3+ Robot Vacuum compare to other iRobot models?

A. Power-Lifting Suction delivers 10X the air power* for improved pick-up performance. Premium 3-Stage Cleaning System cleans the dirt and pet hair you see and the allergens and dust you don't.

*(Compared to Roomba® 600 Series.)

Q. How smart is Roomba® i3+?

A. Powered by iRobot Genius™, the Roomba® i3+ learns from your cleaning habits to offer up personalised schedules, while Google Assistant and Alexa allow you to start cleaning with just the sound of your voice**. The i3+ will even suggest an extra clean when your area's pollen count is high or during pet shedding season.

Q: Is the robot bin dishwasher safe?

A: No. The washable bin should be rinsed by hand using warm water. Important: Be sure to remove the filter before rinsing the bin. Allow bin to dry completely before reinstalling the filter.

Q. How often does the Clean Base® Automatic Dirt Disposal need to be emptied?

A. Clean Base® is designed to hold up to 60 days of dirt and debris. Results will vary based on floor surfaces, whether you have pets, etc.

Q. Does the Clean Base® Automatic Dirt Disposal work with previous Roomba® robot vacuum Models?

A. It only works with other i Series Roomba® robot vacuum models.