


PHANTEKS

REVOLT



INSTALLATION GUIDE SUPPORTS

- PH-P1000PR_BK01C
- PH-P1000PR_WT01C
- PH-P1200PR_BK01C
- PH-P1200PR_WT01C
- PH-P1600PR_BK01C
- PH-P1600PR_WT01C
- PH-P1300TR_BK01C
- PH-P1300TR_WT01C
- PH-P1600TR_BK01C
- PH-P1600TR_WT01C
- PH-P2200PR_BK01C



ACCESSORIES INCLUDED

INCLUDED ACCESSORIES	POWER SUPPLY REVOLT	MANUAL WARRANTY	POWER CABLE 1500MM
User Manual			
Installation Guide			
PSU Bag			
Zip Tie Bag			
Velcro Bag	ZIP TIE BAG	VELCRO BAG	SCREW PACK
Screw Pack			
Power Cable			

AVAILABLE OUTPUT CONNECTORS

MOTHERBOARD 10+18-PIN	CPU PCIe 8-PIN	PCIe GEN5.1 12V-2X6	SATA MOLEX 6-PIN

CONNECTOR QUANTITY	1000/1200 watt models	1300 watt models	1600/2200 watt models
Motherboard 10+18-PIN	1	1	1
CPU PCIe 8-PIN	5	9	9
PCIe GEN5.1 12V-2x6	1	1	2
SATA MOLEX	5	6	6

FOLLOW US ON SOCIAL MEDIA



Instagram
Phanteks



Facebook
Phanteks



YouTube
Phanteks



Twitter
@phanteks

SUPPORT

US & Canada


support@phanteksusa.com

International

support@phanteks.com

01 CHOOSE YOUR CABLES


The Revolt power supply comes as a cable free model, cables are purchased separately. Make sure the cables are compatible with the Phanteks Revolt power supply before proceeding.



Cables sold separately

02 INSTALL POWER SUPPLY INTO CHASSIS

Install the Revolt PSU in the computer chassis using the 4x PSU screws. Follow the chassis instruction manual.




PRO TIP

Pre-connect all needed cables to the PSU before installing it into the chassis. See step 3


03 CONNECT CABLES TO POWER SUPPLY

Connect all needed cables to the power supply according to the overview below. The exact connector lay-out and quantity may be different depending on the model.




04 PCIE GEN5.1 GPU CONNECTOR

The Revolt is equipped with the PCIe GEN5.1 (12V-2x6) GPU connector. Make sure it is fully seated and clicked in to prevent any damage to your system. **Note that a compatible GPU is required.**




05 ULTIMATE SILENCE WITH HYBRID FAN CONTROL

Activate the 0 RPM mode with the Hybrid Fan button on the rear to go for absolute silence when under low load. The Revolt will control the fan speed intelligently based on load and temperature.



Hybrid Fan Mode is turned **on** when the button is in the 'OUT' position and turned **off** when pushed 'IN'.



06 CONNECT POWER CABLE

Connect the power cable to the power supply and a grounded power outlet respectively. Make sure the power supply is turned off 'O' before connecting it to a power outlet.



07 BE SAFE!

Switch the power button to the 'I' position to turn on your system.

When making any changes to the hardware, be sure that the power button is switched from the 'I' to the 'O' position so the power supply is turned off.

