



BATMAN RGB 6400DPI GAMING MOUSE

KAGAMEMSWBA

SAFETY & WARNINGS

Ensure to read all warnings and instructions in this user guide prior to first use.


- Do not expose the mouse to water or any other liquid.
- If disconnecting the mouse from a device, do not pull on the cable or from the mouse itself. This may cause damage to the cable. Instead, pull on the head of the USB cable for safe removal.
- Do not hold the mouse by the cable.
- Do not clean the mouse using abrasives or detergents.
- Do not throw the mouse.
- Do not expose the mouse to direct sunlight or be use near other heat sources.

OVERVIEW



OPERATION

1. Plug the USB cable into a USB port on your computer to use the mouse.



Changing light modes

Cycle through the various light modes by clicking on light mode button.

CLEANING & CARE

Unplug the mouse and clean it by wiping using a damp cloth.

SPECIFICATIONS

Buttons	7 buttons
Sensor	Sunplus 1991C
DPI	Up to 6400 DPI
Cable	1.5m
Cable type	USB-A
Plug and play	Yes
Anti-slip scroll wheel	Yes
Lifetime	HUANO switch, 5 million clicks
Systems supported	Windows: 9X, 2000 and later MacOS: 10.14 and later

NOTES

This image shows a single page of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page, leaving small margins at the top and bottom. There are no vertical margin lines, and the entire surface is available for writing.

Need more information?

We hope that this user guide has given you the assistance needed for a simple set-up.

For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to **help.kogan.com**

kogan.com