



BOX CONTENT




PARTS DESCRIPTION

INDOOR UNIT




OUTDOOR UNIT (DOORBELL)




ELECTRICAL INSTALLATION


CONNECTING THE AC POWER ADAPTER (INDOOR UNIT)




CONNECTING THE AC POWER ADAPTER



CONNECTING A DOORLOCK




INSERT BATTERIES (6x AA)




PAIRING

PAIRING THE INDOOR AND OUTDOOR UNIT




INSTALLATION




USE


SET MELODY




SET RINGTONE VOLUME



TALK



INTERNAL CALL



UNLOCK DOOR

