



PAIR LED

LINK LED

PAIR BUTTON

LINK BUTTON

Bluetooth

Step 1: Press button to pair your Bluetooth device. Select **ALTO PRO WIRELESS** in your device.

Step 2: Press button on **BOTH** stereo loudspeakers to link speakers together.

MIN **MAX**

BLUETOOTH VOLUME

- NOTE, IF YOU ARE EXPERIENCING PROBLEMS:** (1) Reset your loudspeakers by pressing and holding the bottom LINK BUTTONs on each loudspeaker for 3 seconds until you hear a long tone from each. (2) On Your Bluetooth device, select “Forget” or “Unpair” ALTO PRO WIRELESS. (3) Repeat steps 1-8.

PAIR LED

PAIR BUTTON

Bluetooth

Step 1: Press button to pair your Bluetooth device. Select **ALTO PRO WIRELESS** in your device.

Step 2: Press button on **BOTH** stereo loudspeakers to link speakers together.

MIN **MAX**

BLUETOOTH VOLUME

- NOTE, IF YOU ARE EXPERIENCING PROBLEMS:** (1) Reset your loudspeaker by pressing and holding the bottom LINK BUTTON for 3 seconds until you hear a long tone. (2) On Your Bluetooth device, select “Forget” or “Unpair” ALTO PRO WIRELESS. (3) Repeat steps 1-4.

MASTER and SLAVE loudspeakers will reconnect automatically. On your Bluetooth audio device, pick **ALTO PRO WIRELESS** and press connect.

altoprofessional.com/wireless