

KY35
真无线蓝牙耳机

使用说明
使用前请阅读使用说明书

产品使用简介

(1) 随说明书有特释指示的操作方式以外,请勿尝试拆卸或更换产品内的任何零件。
(2) 请勿将产品放入水或其他液体中,此产品并非防水设计。
(3) 如果有任何液体不小心进入产品内时,请立即断开连接并拆开此产品。
(4) 为避免触电,请在安装或卸装产品时,确保手上没有沾水。
(5) 请勿将此产品放置于热源附近或直接暴露在火源附近。
(6) 请勿将本产品放置在有强大电磁力的环境中,否则会导致产品故障。

包装清单

耳机X2

充电盒X1

使用说明书X1

充电线X1

产品示意图

功能触摸区

Type-c接口

耳机

充电仓

产品规格

蓝牙版本: V 5.4
传输距离: 约10-15米
电池容量: 28mAh
充电时间: 约1.5小时(耳机)
满电通话时间(50%音量): 3-3.5小时(耳机)
满电音乐时间(50%音量): 4小时(耳机)
额定输入: 5V==30mA(耳机)

充电盒规格

电池容量: 200mAh
充电时间: 约1.5小时
额定输入: 5V==200mA
(所有技术信息以实际性能为准)

给充电盒充电

用Type-C充电线连接充电盒到5V电源适配器。
(温馨提示:电压低于3.4V 属低电量提示时,请及时给充电盒充电。)

LED指示灯状态和提示音

耳机指示灯

- 开机:当耳机电灯闪烁,即显示“Power On”
- 成功配对成功后,灯光即显示“Power Off”
- 左右耳同时快速三次短闪:即显示“Pairing”
- 左右耳同时慢速三次短闪:即显示“Full”,提示充满
- 耳机充电时快速短闪:即显示“Connected”
- 断开连接(无耳机的情况下),即显示“Disconnected”
- 充电盒没电时(充电前需先一次“Battery On”)
- 低电量提醒:“Power Off”
- 插入充电盒充电时:白光

充电仓指示灯

- 充电仓充电时:绿灯闪烁
- 充电仓充电完成时:红灯常亮
- 充电仓充满电:绿灯常亮

产品操作说明

1.开机
方式一:从充电仓内取出,耳机自动开机。
方式二:手动长按 3秒开机。

2.关机
方式一:将耳机放回充电仓,耳机关机。
方式二:手动长按 5秒关机。

3.配对
步骤一:打开充电仓上盖取出耳机,双耳自动配对。
步骤二:打开智能设备的蓝牙耳机表,搜索“ KY35 ”并连接(支持单耳使用)。

触控按键的操作
音乐播放

■左/右耳机操作

- 上一曲:三击任意耳机功能键
- 下一曲:双击任意耳机功能键

电话免提

■左/右耳机操作(来电状态下)

- 接听:单击任意耳机功能键
- 拒接:长按任意耳机功能键
- 挂断:单击任意耳机功能键

语音助手

■左/右耳机操作

——长按 3秒任意耳机功能键唤醒语音助手

产品中有害物质名称及含量

产品中有害物质的名称及含量

部件名称	有害物质				
	铅(Pb)	汞(Hg)	镉(Cd)	多溴联苯(PBB)	多溴二苯醚(PBDE)
印刷电路组件	○	○	○	○	○
外表等小结构件	○	○	○	○	○

本表格依据GB/T 11364的规定编制。
○:表示该有害物质在该部件所有均质材料中的含量均GB/T26572规定的限量要求以下。
×:表示该有害物质在该部件的某一均质材料中的含量超过GB/T26572规定的限量要求。
数量级标记“x”的部件,指因全球技术发展水平限制无法实现有害物质的替代。

印刷电路板组件(包括印刷电路板及其零部件、电子元器件等,根据产品类型不同,您所购买的产品可能不会含有以上所有部件)

在中华人民共和国境内销售的电子电气产品必须标识此标志,标志内的数字代表在正常使用状态下产品的环保使用期限。

保修卡

尊敬的客户,本卡片可作为您申请保修凭证,请您配合销售商填写并妥善保管备用!

用户信息

用户名名

电子邮箱

联系电话

邮政编码

通讯地址

产品信息

产品名称

产品型号

产品条码/编号/批号

销售商信息

名称

地址

联系电话

邮政编码

销售日期

发票号码

备注

合格证


生产商名

检验合格

出厂日期

KY35

True Wireless Bluetooth Headset





Usage Instruction

- (1) Do not attempt to disassemble or replace any part of the product except as specifically indicated in the instructions.
- (2) Do not put the product in water or any other liquid, this product is not waterproof design.
- (3) If any liquid accidentally enters the product, disconnect and remove the product immediately.
- (4) To avoid electric shock, please ensure that your hands are free of water when installing or unloading the product.
- (5) Do not place this product near a heat source or directly expose it to a fire source.
- (6) Do not place the product in an environment with strong electromagnetic force, otherwise it will lead to product failure.

Packing list

	Headphone × 2		Charging case × 1
	User manual × 1		Type-C × 1

Product schematic description

Bluetooth specification

Bluetooth version: V5.4
Transmission distance: ≈10-15M
Battery capacity: 28mAh
Charging time: ≈1.5 hour (forheadphones)
Talk time at full power (50% volume): 3-3.5 hours (forheadphones)
Music time at full power (50% volume): 4 hours (forheadphones)
Rated input: 5W=30mA (forheadphones)

Charging case specification

Battery capacity: 200mAh
Charging time: ≈1.5 hours
Rated input: 5V=20mA
(All technical information is subject to actual performance)

Charge the Charging case

Connect the Type-C cable to the 5V power adaptor, and another end to the charging port of the Charging case.
(Tip: When the voltage is lower than 3.4V and a low battery prompt is issued, please charge the charging case in a timely manner.)

LED indicator light status and prompt tone


- *Power On: The white light stays on and blue flash goes out, and the prompt tone is "Power On"
- *Power Off: The white light stays on and blue flash goes out, and the prompt tone is "Power Off"
- *Automatic Pairing: The white lights of both earbuds flash
- *Successful Pairing between the Left and Right Earbuds: The white light of the main earbud flashes, the light of the secondary earbud goes out, and the prompt tone is "Pairing"
- *Successful Connection between the Earbud and the Mobile Phone: The light goes out, and the prompt tone is "Connected"
- *Disconnection: The white light of the main earbud flashes, the light of the secondary earbud goes out, and the prompt tone is "Disconnected"
- *Low Battery Prompt Tone: "Battery Low": Broadcast once every 40 seconds
- *Power Off due to Low Battery: "Power Off"
- *Charging when Placed in the Charging Case: The white light is on

Indicator light of the charging case

- When the charging case is being charged: The green light flashes
- When the charging case is charging the earbuds: The white light stays on constantly
- When the charging case is fully charged: The green light stays on constantly

Product operating instructions

- Power on**
Method 1: Take it out from the charging compartment, and the headset automatically starts.
Method 2: Press and hold it manually for 3 seconds to turn it on.
- Power off**
Method 1: Put the headset back into the charging bin, and turn off the headset.
Method 2: Press and hold it manually for 5 seconds to turn it off.
- Pairing to the BT device**
Step 1: Open the top cover of the charging bin and take out the earphones.
Step 2: Open the Bluetooth list of smart devices, search for " KY35 " and connect (support single-ear use)



Instruction manual

Please read the instruction manual before use

Operation of touch buttons

Music playback

■ Left/right headphone operation



Previous track: Triple-click any function button of the earphone

Next track: Double-click any function button of the earphone

Pause/Play: Single-click any function button of the earphone

Phone Hands Free

■ Left/right headphone operation (in incoming call state)



Answer a call: Single-click any function button of the earphone

Reject a call: Long-press any function button of the earphone

Hang up: Single-click any function button of the earphone

Voice assistant

■ Left/Right Earphone Operation



Long-press any function button of the earphone for 3 seconds to wake up the voice assistant

Name and content of hazardous substances in products

Part Name	Harmful materials				
	Pb	Hg	Cd	Cr(VI)	PBB
Printed circuit board(s)	○	○	○	○	○
Small structural parts (such as shell)	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364.
 ○: Indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirements specified in GB/T 26572.
 X: Indicates that the content of the hazardous substance in at least one of the homogeneous materials of the part exceeds the limit requirements specified in GB/T 26572.
 The parts marked with "X" on the form are all harmful due to the limitations of global technological development.
 Substitution of substances:
 Printed circuit board components*: including printed circuit boards and their parts, electronic components, etc., depending on the product model, the product you purchased may not contain all the above components.

10 Electronic and electrical products sold in the People's Republic of China must mark this Logo; the number in the logo represents the product under normal use Environmental protection use period.

Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info	
User name	Email
Contact number	Postal code
Mailing address	

Product information	
Product name	Product number
Product barcode/Serial number/Batch number	

Vendor information	
Name	
Address	
Contact number	Postal code
Sales date	Invoice number
Remark	



文件名称	KY35			材料	70g书写纸	单位	mm	厂商物料编号	变更履历	修改	虹	日期	2025.05.07
文件尺寸	54x80mm（单P尺寸）			工艺	1C印刷 风琴折 	公差	±0.5mm			审核		日期	
设计日期	2025/02/26	文件版本	V02			比例	1:1			批准		日期	

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.