


Chapter 1


Date and Time Setting

1. Press and hold the [**SET**] button to enter the DATE setting, the Year "2022" begins to flash, press the [**+**] or [**-**] to set the Year.
2. Press the [**SET**] button again, the Month "1" begin to flash, press the [**+**] or [**-**] button to adjust.
3. Press the [**SET**] button again, the Day "1" begins to flash, press the [**+**] or [**-**] button to adjust.



→Go on

4. press the [**SET**] button again, enter Time Setting, the Hour number "12" starts to flash, press the [**+**] or [**-**] button to adjust the Hour.
5. Press the [**SET**] button again, the Minute digit "00" starts to flash, press the [**+**] or [**-**] button to adjust.
6. Press[**SET**] button to save Date and Time setting.
- No operation 15S automatically can also save.




Chapter 2

12/24 Hr Change

Under normal using, Press the [**-**] button to switch 12/24H time format.

Note: When the 12H time format is selected, the "AM" or "PM" will display on the screen.



Chapter 3

°F/°C Switch

Under normal using, Press the [**+**] button to switch temperature unit to °C/°F

