


# DEFIANT®

## INSTALLATION GUIDE



SCAN FOR INSTALLATION



<https://bit.ly/3IJTs8m>

Questions, problems, missing parts?

Before returning to the store, call Defiant Customer Service

**TOLL FREE HELP LINE 1-877-ONE-LOCK**

**HOMEDEPOT.COM**

08:30 a.m.-05:30 p.m., EST, Monday - Friday

G22-KPLC312A

Rev. 21/01-00



Contents in this package are **NOT** interchangeable with other units. Please contact customer service for more information.

## WARRANTY

### LIMITED LIFETIME MECHANICAL AND 1 YEAR ELECTRONIC WARRANTY

The retailer of this product, hereby warrants, subject to the conditions set forth below, that it will either repair or replace, at its option, this product if it proves to be defective by reason of improper workmanship or materials within the original purchaser's limited time. In order to obtain repairs or replacement under this limited warranty you must bring this product to the retailer's store in which you bought it. Original purchaser: This limited warranty is limited to the original purchaser at retail of this product from retailer. Except to the extent prohibited by applicable law, no other warranties, whether express or implied, including the warranties of merchantability and fitness for a particular purpose, shall apply to this product. Under no circumstances shall retailer be liable for consequential or incidental damages in connection with this product. To the extent retailer is prohibited by applicable law from excluding implied warranties, the duration of such implied warranties which are not excludable shall be the original purchaser's lifetime. Some states do not allow the limitation on how long an implied warranty lasts, so the above limitation on the duration of implied warranties which are not excludable, if any, may not apply to you. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion of incidental or consequential damages may not apply to you. Retailer neither assumes nor authorizes any representative or other person to assume for it any obligation or liability other than such as is expressly set forth herein. This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

## IMPORTANT NOTICE

Please Read This Notice before Installing, Using, and Servicing the Product

The product is designed and manufactured for providing security. Please read carefully and follow the instructions given below. Lack of proper working knowledge or improper use could cause unexpected damage or loss to personal or commercial belongings.

### Installation

- Please contact your local service provider prior to the installation as your door preparation may be different from the standard the product conforms to.
- Please change the master code (programming code) to prevent unauthorized individuals from gaining access.
- Any removal or replacement of parts in installation is NOT recommended and may invalidate the warranty of the product.
- Not to be used on an Emergency Exit.

### Product Use


- **ALWAYS use authentic alkaline batteries.** It is the user's responsibility for damage caused by using unauthentic batteries.
- The product is made of mechanical and electronic components, which may be sensitive towards water, physical impact, and electric shock. Using the product with care prevents unexpected malfunction and optimizes the product life span.
- **DO NOT** disassemble the product without advice from qualified service provider. Unauthorized disassembly will void the product warranty.
- Please refer to TROUBLESHOOTING page if any problem occurs, or contact your local service provider for professional instructions.
- Remove all batteries from the lock at the same time and replace them with new batteries of the same size and type.
- Preserve battery and lock life by removing the batteries when the lock is not being used for more than 3 months.

### Service and Maintenance

- **ALWAYS** refer to user's manual or seek advice from your local service provider on cleaning, moving, or maintaining the product.
- The information in this notice is subject to change without notice.


## Package Contents List

| Part | Description                | Quantity |
|------|----------------------------|----------|
| A    | Key                        | 2        |
| B    | Cylinder                   | 1        |
| C    | Exterior Assembly          | 1        |
| D    | Power Cable                | 1        |
| E    | Latch                      | 1        |
| F    | Mounting Plate             | 1        |
| G    | Interior Assembly          | 1        |
| H    | Battery Cover              | 1        |
| I    | Lever                      | 1        |
| J    | Strike Plate               | 1        |
| K    | Dust Box                   | 1        |
| L    | Drive-in Collar (Optional) | 1        |



## Hardware Contents (Actual Size)

| Part | Description                  | Quantity |
|------|------------------------------|----------|
| AA   | 1-1/16"(27 mm) Mounting Bolt | 2        |
| BB   | 13/16"(20.5 mm) Screw        | 2        |
| CC   | 3/4" (19 mm) Wood Screw      | 4        |
| DD   | Catch tool                   | 1        |



## Safety Information

**NOTE:** Before beginning installation of product, make sure all parts are present. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Call the Customer Service Team or visit [www.homedepot.com](http://www.homedepot.com).

**Do not use electric drill or electric screwdriver to tighten screws.**




- Read the precautions and instructions in this manual before installing and using this lock. Save this manual for future reference.
- Do not attempt to disassemble any internal components of the lockset. Doing so will void the limited warranty.
  - Do not drop or hit the lockset. Too much shock may result in permanent damage.
  - Do not use pins or sharp objects to press the keypad.
  - Always create a backup of information you wish to keep (Master Code, User Codes, etc.)
  - Promptly change the Master Code before operating this lockset.
  - Restrict access to your lock's interior assembly and routinely check your settings to ensure they have not been altered without your knowledge.

**CARE and MAINTENANCE:** The following instructions should be followed to properly protect and maintain your lockset:


- Remove locks, or do not install locks, prior to painting your door.
- Periodically clean with mild soap and a soft cloth only.
- Do not use any abrasives or chemical products containing alcohol, benzene, acids, and avoid using sharp or abrasive objects to clean this lockset.
- Do not allow any water or liquids into the lockset during installation.

## Before Proceeding

### Check Dimensions



### Tools Required




**WARNING:** If the door needs to be drilled, please be familiar with how to use a drill safely and understand all of the door preparation steps before proceeding.

## Step 1: Door Drilling For New Installation


**1** Cut out TEMPLATE and use to mark the door, drill holes, and chisel out the mortise.

**NOTE:** If your door already has holes, skip to **Step 2**

**Drill from both sides of the door to prevent wood splitting.**




**2** Prepare the door jamb – use the strike plate as a template to drill the latch and screw holes and chisel out the mortise. The strike plate must fit flush with the surface of the door jamb.



**WARNING:** If the door needs to be drilled, please be familiar with how to use a drill safely and understand all of the door preparation steps before proceeding.

## Step 2: Install the latch and strike


**1** Choose faceplate



**Proceed to next step.**

**2** Set the latch backset


Your latch is set for 2-3/8" backset. It can be adjusted if needed to 2-3/4" (skip this if your door has a 2-3/8" backset).



**Proceed to next step.**


## Step 3: Mount the lockset

**1** Mount the lockset



**Proceed to next step.**

**2** Mount the strike plate




**Proceed to next step.**

**WARNING:** If the door needs to be drilled, please be familiar with how to use a drill safely and understand all of the door preparation steps before proceeding.


### 3 Install the latch

**⚠ You must use the latch that was provided in the packaging.**



### 4 Install strike plate in door jamb



**NOTE:** Check the strike plate to make sure it is properly aligned and clear so the bolt can freely move in the hole.



### Step 3: Change Handle Orientation For Right Or Left Swing Doors



**How to determine if your door is a Right Swing or Left Swing door?**  
While facing the door, if the door hinges are on the right side of the door, you have a Right Swing Door. If the hinges are on the left side of the door, you have a Left Swing Door.

**NOTE:** The lock ships default for Right Swing Doors. You may skip **Step 3** if your door is a Right Swing Door. To change your door handle orientation for a left swing door, please continue reading.





### Step 4: Install The Lock Assemblies

#### 1 Install exterior assembly





#### 2 Install interior assembly





#### 3 Switch levers (optional)



If your product comes with asymmetrical levers, you have the option to switch the interior lever with the exterior to have levers rotated 180 degrees.



#### B.




#### 11




### TEMPLATE

**NOTE:** Double check your product for the correct hole sizes.



# DEFIANT®

## GUIDE D'INSTALLATION



BALAYER POUR INSTALLER



<https://bit.ly/3lJTs8m>

Le contenu de ce conditionnement **N'EST PAS** interchangeable avec d'autres unités. Pour plus d'information, veuillez contacter le service client.

### GARANTIE

#### GARANTIE LIMITÉE À VIE SUR LES PIÈCES MÉCANIQUES ET D'UN AN SUR LES PIÈCES ÉLECTRONIQUES

Le détaillant de ce produit, garanti, sous réserve des conditions énoncées ci-dessous, qu'il réparera ou remplacera, à son gré, ce produit s'il s'avère défectueux en raison d'une mauvaise fabrication ou de matériaux à l'intérieur de la période de temps limité de l'acheteur initial. Afin d'obtenir les réparations ou le remplacement en vertu de la présente garantie limitée vous devez amener ce produit au détaillant à lequel vous l'avez acheté.

Acheteur initial : Cette garantie limitée est limitée à l'acheteur initial de ce produit auprès du détaillant. Sauf dans la mesure interdite par la loi applicable, aucune autre garantie, explicite ou implicite, y compris les garanties de qualité marchande et d'adéquation à un usage particulier, s'appliquent à ce produit. En aucun cas, le détaillant devrait être tenu responsable de dommages accidentels ou indirects en lien avec ce produit. Dans la mesure où il est interdit, au détaillant, par la loi applicable, d'exclure toute garantie implicite, la durée des garanties implicites qui ne peuvent être exclues doivent être de la durée de vie de l'acheteur initial. Certains états n'autorisent pas la limitation de la durée d'une garantie implicite, de sorte que la limitation ci-dessus sur la durée des garanties implicites qui ne peuvent être exclues, le cas échéant, peuvent ne pas s'appliquer à vous. Certaines provinces n'autorisent pas l'exclusion ou la limitation de dommages indirects ou consécutifs, dans ce cas, cette disposition ne s'appliquerait pas.

Le détaillant n'assume ni n'autorise tout représentant ou toute autre personne à assumer une quelconque obligation ou responsabilité autre que celles qui sont expressément énoncées dans le présent document. Cette garantie limitée vous donne des droits légaux spécifiques et vous pouvez également avoir d'autres droits, qui varient d'une province à l'autre.

G22-KPLC313A  
Rev. 21/01-00

### AVIS IMPORTANT

Veuillez lire cette notice avant de procéder à l'installation, l'utilisation et la réparation du produit. Ce produit a été conçu et fabriqué pour apporter la sécurité. Veuillez lire et suivre toutes les instructions ci-dessous. Le manque de connaissances sur son bon fonctionnement ou son utilisation inappropriée pourrait entraîner des dégâts inattendus ou la perte des biens personnels ou marchands.

#### Installation

- Veuillez contacter votre prestataire de service local avant l'installation étant donné que la préparation de votre porte pourrait être différente du standard auquel répond ce produit.
- Veuillez changer le code maître (code de programmation) pour éviter l'accès par des individus non-autorisés.
- Tout enlèvement ou remplacement de pièces pendant l'installation N'est PAS recommandé et ceci peut abroger la garantie de ce produit.
- Ne pas utiliser sur une sortie de secours.

#### Utilisation du produit


- **TOUJOURS utiliser des piles alcalines originales.** L'utilisateur est responsable des dégâts causés par l'utilisation des piles non originales.
- Le produit est constitué de composants mécaniques et électroniques qui peuvent craindre l'eau ou être sensibles à l'impact physique et au choc électrique. Une utilisation précautionneuse du produit prévient des dysfonctionnements inattendus et optimise la durée de vie du produit.
- **NE JAMAIS démonter le produit sans demander conseil à un prestataire de services qualifié. Le démontage non autorisé entraînera la nullité de la garantie.**
- Veuillez vous rapporter à la page DÉPANNAGE du GUIDE de L'UTILISATEUR en cas de problème, ou contactez votre prestataire de services local pour recevoir des conseils de professionnel.
- Retirez toutes les piles de la serrure en même temps, puis remplacez-les par des piles neuves de même type et taille.
- Vous pouvez préserver la durée de vie de la pile et de la serrure en retirant les piles lorsque la serrure ne doit pas être utilisée pendant plus de 3 mois.

#### Réparation et entretien

- **TOUJOURS** vous rapporter au manuel de l'utilisateur ou demander conseil à votre prestataire de services local sur le nettoyage, le déplacement ou l'entretien du produit.
- Les informations contenues dans le présent manuel de l'utilisateur sont sujettes à modifications sans préavis.


### Assemblage De Serrure Avec Poignée

| Pièce | Description                   | Quantité |
|-------|-------------------------------|----------|
| A     | Ciè                           | 2        |
| B     | Cylindre                      | 1        |
| C     | Bloc Extérieur                | 1        |
| D     | Câble D'alimentation          | 1        |
| E     | Verrou                        | 1        |
| F     | Plaque de Fixation            | 1        |
| G     | Bloc Intérieur                | 1        |
| H     | Couvercle De La Pile          | 1        |
| I     | Levier                        | 1        |
| J     | Gâche                         | 1        |
| K     | Boîte à Poussière             | 1        |
| L     | Collier Encastré (Facultatif) | 1        |



### Quincaillerie Incluse (Taille Réelle)


| Pièce | Description                          | Quantité |
|-------|--------------------------------------|----------|
| AA    | Boulon de Fixation de 1-1/16" (27mm) | 2        |
| BB    | Vis de 13/16" (20.5mm)               | 2        |
| CC    | Vis à Bois de 3/4" (19 mm)           | 4        |
| DD    | Clé à ergot                          | 1        |



### Informations De Sécurité

**REMARQUE :** Avant de commencer l'assemblage du produit, assurez-vous que toutes les pièces sont présentes. S'il y a des pièces manquantes ou endommagées, n'essayez pas d'assembler, d'installer ou d'utiliser le produit. Contactez notre Service à la clientèle ou visitez [www.homedepot.com](http://www.homedepot.com).

**N'utilisez pas de perceuse électrique ou de tournevis électrique pour serrer les vis.**




**AVERTISSEMENT :** S'il faut percer la porte, sachez comment utiliser adéquatement votre perceuse et assurez-vous que vous connaissez toutes les étapes De préparation de la porte avant de continuer.


- Retirez les serrures, ou ne les installez pas avant de peindre votre porte.
- Nettoyez régulièrement avec un savon doux et un chiffon doux.
- N'utilisez pas de produits abrasifs ou de produits chimiques contenant de l'alcool, du benzène, de l'acide chlorhydrique ou de l'acide nitrique, et évitez d'utiliser des objets tranchants ou abrasifs pour nettoyer cette serrure.
- Ne laissez pas l'eau ou un liquide quelconque entrer dans la serrure pendant le processus d'installation.

### Avant L'installation

#### Vérifiez Les Dimensions



#### Outils Nécessaires




**AVERTISSEMENT :** S'il faut percer la porte, sachez comment utiliser adéquatement votre perceuse et assurez-vous que vous connaissez toutes les étapes De préparation de la porte avant de continuer.

### Étape 1: Perçage De La Porte Pour L'installation


**1** À l'aide du gabarit, marquez la porte, percez les trous, et enlevez une mortaise au burin.

**REMARQUE :** Si votre porte a déjà des trous, **Passez à 2**

**Percez des deux côtés pour éviter l'éclatement du bois.**




**2** Préparez le jambage de la porte – à l'aide de la gâche comme modèle, percez les trous de la serrure et de la vis, ciselez une mortaise jusqu'à ce que la gâche puisse entrer sans force.



**AVERTISSEMENT :** S'il faut percer la porte, sachez comment utiliser adéquatement votre perceuse et assurez-vous que vous connaissez toutes les étapes De préparation de la porte avant de continuer.

### Étape 2: Installez le loquet et la gâche


**1** Choisissez la tête



**Passez à l'étape suivante.**

**2** Réglez la distance d'entrée de la serrure


2-3/8" (60 mm) OU 2-3/4" (70 mm)



**Passez à l'étape suivante.**

### Étape 3: Installez le loquet et la gâche


**1** Choisissez la tête



**Passez à l'étape suivante.**

**2** Réglez la distance d'entrée de la serrure


2-3/8" (60 mm) OU 2-3/4" (70 mm)




**Passez à l'étape suivante.**

### 3 Installation du loquet

**⚠** Vous devez utiliser le loquet inclus dans l'emballage original.





### 4 Vissez la gâche au montant de la porte.



### Étape 3 : Modification de l'orientation de la poignée pour les portes tournantes droites ou gauches



Comment déterminer si votre porte est une porte tournante droite ou gauche?  
Si face à la porte, les charnières se trouvent sur le côté droit de la porte, il s'agit d'une porte tournante droite. Si face à la porte, les charnières se trouvent sur le côté gauche de la porte, il s'agit d'une porte tournante gauche.

**REMARQUE :**  
La serrure est livrée par défaut pour les portes tournantes droites. Vous pouvez sauter l'Étape 3 si votre porte est tournante droite. Pour changer l'orientation de votre poignée de porte pour une porte tournante gauche, veuillez continuer à lire.




### Étape 4: Installation De La Serrure Extérieure

#### 1 Installez l'ensemble extérieur




#### 2 Installez l'ensemble intérieur




#### 3 Faites basculer les leviers (facultatif)

À la livraison, vous pouvez constater que votre produit contient des leviers asymétriques. Dans ce cas, vous avez la possibilité de commuter le levier intérieur avec le levier extérieur pour faire tourner les leviers de 180 degrés.



#### 3 Faites basculer les leviers (facultatif)



## MODÈLE

**REMARQUE :**  
Vérifiez de nouveau votre produit pour vous assurer que les trous sont de bonne taille.

