

ecobee Adapter for Prime Chime Plus

INSTALLATION INSTRUCTIONS

Model:PRCP2FBADAPT1WH

What's In The Box



Tools Needed

The ecobee Adapter requires very few tools for installation. A screwdriver and a pair of wire cutters will be required to install the adapter.





Junction Box

The adapter is required to be installed on the low voltage side of a dual voltage box (CARLON Model#SC200DV or equivalent, not provided)

Installation

Preparation

- Shut off power to desired circuit before any work. Identify and prepare location for installation.
- Carefully unpack the fixture from its packaging and inspect product for defects due to shipping.
- If installed, remove the PRCP2/A from its junction box. If not yet installed, move to Step 2.

2 Mounting

- Mount the ecobee unit to the side wall of the low voltage section of the junction box using double-sided tape.
- Mount the NICOR adapter to the ecobee unit using double sided tape.

Wiring

 Connect the PRCP2/A, ecobee unit and NICOR adapter per the wiring diagram.





