

# Flip Key Blade Pin Removal Tool Kit

## User Guide

Remove your original key blade from the case (search your vehicles make of key on [YouTube](#) for instructions on how to take apart the key case).

Place the key blade on a piece of cardboard or something similar.

Put the car key blade pin punch (choose the correct size first) on top of the pin.

Gently tap the pin until it comes out using a small hammer (do not whack it or use a large hammer)

Remove the original key blade.

Repeat the process on the new key blade.

Put the original key blade into the new silver knuckle piece (the piece the new blade came out of).

Put the pin into the hole of the pin holding tool and put the magnet at the end (near the pin) to hold it in place.

Locate the hole in the silver knuckle and gently tap the pin in so it locates and sits in the hole.

Remove the pin holding tool.

Tap the rest of the pin using the pin punch.

Congratulations, you should have successfully changed the original key blade, and you can now put the key back together.