1. Kindly Note


- It takes the risk to update the firmware, please avoid updating the firmware when the device is used for the important events
- To avoid the power being cut off suddenly during the updating, please make sure the device with enough power during updating.
- Please feel free to contact our technical support engineer if the updating failure or error causes the malfunction of the device:
- The link for contacting Hollyland Technical Support Engineer: support@hollyland.com

2. Upgrade Steps

2.1 Upgrade with Windows

- Download the upgrade file and unzip the file
- Install the USB driver


(Windows system only. download link: https://download-hollyland.oss-us-east-1.aliyuncs.com/Firmware/Wireless Intercoms/USB Driver/STSW STM32102 V1.5.0.zip)



Turn on the headset one by one, and connect it to laptop via USB-A to Type-C cable



• Open the 【I5803_Headset_Upgrade.exe】 application



- It will recognize the headset automatically, and then Click [YES] for upgrade.(Please do not unplug the USB cable during the upgrade.)
- After the upgrade, pair the master headset and remote headset again by long-press the [A] button on both headsets.

2.2 Upgrade with Mac

- Download the upgrade file and unzip the file
- Turn on the headset one by one, and connect it to laptop via USB-C cable



2/25/2023 SOT PM

10/10/2022 313 PM

33 5803 Headset Upgrade

• It will recognize the headset automatically, and then Click [YES] for upgrade.(Please do not unplug the USB cable during the upgrade.)

Set Dunament

Application

10

13,300 (0)

• After the upgrade, pair the master headset and remote headset again by long-press the [A] button on both headsets.