

尺寸: 105x148.5mm

专色

#A7E800
R167 G232 B0
C39 M0 Y90 K0
PANTONE 2290C

折页方式: 骑马钉 100g铜版纸

英语

SEENDA

User Manual

Multi-Device Wireless Bluetooth Keyboard and Mouse Set





COE300

EN

Product Warranty










All Seenda products come with a 24-month warranty policy, please do not hesitate to contact us if you have any questions. Our support team will try our best to provide you with a pleasant shopping experience. Our email: support@seenda.com. Our website: www.seenda.com

Product Features



2.4G Mode Connection

- Place 2 AAA batteries into the battery compartment on the underside of the keyboard (ensure correct polarity: positive and negative terminals match). Place 1 AA battery into the battery compartment on the bottom of the mouse (ensure correct polarity: positive and negative terminals match).
- Turn the power switch to ON.
- Press **BT1** on the keyboard until the 2.4G indicator lights up, confirming the keyboard is in 2.4G mode. Press the channel switch button on the bottom of the mouse. The 2.4G indicator will light up, indicating the mouse is in 2.4G mode.



德语

SEENDA

Benutzerhandbuch

Kabellose Tastatur und Maus





COE300

DE

Produktgarantie

Für alle Seenda-Produkte gilt eine 24-monatige Garantie. Bitte zeigen Sie nicht, uns zu kontaktieren, wenn Sie Fragen haben. Unser Support-Team wird sein Bestes tun, um Ihnen ein angenehmes Einkaufserlebnis zu bieten. Unsere E-Mail: support@seenda.com. Unsere Website: www.seenda.com

Produktmerkmale



2.4G Verbindung

- Stecken Sie 2 AAA-Batterien in das Batteriefach an der Unterseite der Tastatur und 1 AA-Batterie in das Batteriefach an der Unterseite der Maus (Achten Sie bitte auf die Plus- und Minuspole der Batterie, bitte verlegen Sie die Plus- und Minuspole der Batterie nicht).
- Schieben Sie den Schalter auf ON.
- Drücken Sie **BT1** der Tastatur, bis die 2.4G-Anzeige aufleuchtet und die Tastatur in den 2.4G-Modus wechselt. Drücken Sie die Kanalschalttaste an der Unterseite der Maus, die entsprechende Kanalanzeige schnell blinkt und die Maus in den Bluetooth-Kopplungsmodus wechselt.

