

Quick Setup Guide



- 1

Download BroadLink APP
Download the latest BroadLink APP from the Apple App Store or Google Play.
- 2

View installation guide
Open BroadLink APP tap "View device installation guide".
- 3

Scan product QR/SN code
Scan product QR/SN code or select product category to view installation guide.

Télécharger l'application BroadLink
Téléchargez la dernière application BroadLink depuis l'App Store d'Apple ou Google Play.

Voir le guide d'installation
Ouvrez l'application BroadLink, appuyez sur « afficher le guide d'installation de l'appareil ».

Scannez le code QR/SN du produit
Scannez le code QR/SN du produit ou sélectionnez la catégorie de produit pour afficher le guide d'installation.

Laden Sie die BroadLink APP herunter
Laden Sie die neueste BroadLink APP aus dem Apple App Store oder Google Play herunter.

Installationshandbuch anzeigen
Öffnen Sie BroadLink APP, tippen Sie auf "Geräte installationshandbuch anzeigen".

Scannen Sie den QR/SN Code von Produkt
Scannen Sie den QR/SN Code oder wählen Sie die Produktkategorie aus, um die Installationshandbuch anzuzeigen.

Descargar la aplicación BroadLink
Descargue la última versión de la aplicación BroadLink de la App Store o Google Play.

Ver guía de instalación
Abra la aplicación BroadLink, toque "ver guía de instalación del dispositivo".

Escanear el código QR/SN del producto
Escanee el código QR/SN del producto o seleccione la categoría para ver la guía de instalación.

BroadLinkアプリをダウンロードする
AppleのApp StoreまたはGoogle Playから最新版のBroadLinkアプリをダウンロードしてください。

インストールガイドを表示する
BroadLinkアプリを開き、「デバイスのインストールガイドを表示」をタップしてください。

製品のQR/SNコードをスキャンする
インストールガイドを表示するために、製品のQR/SNコードをスキャンするか、製品カテゴリを選択してください。

عرض دليل التثبيت
افتح تطبيق BroadLink ، وانقر على "عرض دليل تثبيت الجهاز".

مسح رمز QR/SN للمنتج
امسح رمز QR/SN للمنتج أو حدد فئة المنتج لعرض دليل التثبيت.

- FCC radiation exposure statement**
- Contains FCC ID refers to product label
 - This device complies with Part 15 of the FCC Rules. Operation is subject to the following 2 conditions:
 - This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.



BroadLink

Hangzhou BroadLink Technology Co.,Ltd.
Building C, 57 Jiang'er Road, Binjiang, Hangzhou, 310052, P.R.China
www.ibroadlink.com