


Smart Watch



User Guide

1 : Touch And Key Operation Instructions



Screen Operation



Swipe Up

1. SMS Notification



Swipe Down

1. Control Interface



Swipe Left

1. Function Interface



Swipe Right

1. Quick Sidebar

Button Operation

Long press the ON/OFF button

1. Power on 2. Power off

Short press the ON/OFF key

1. Awaken the screen
2. Display the UI list
3. Return to previous menu


Einführung in Taschenlampen und Gelddetektoren

In the main interface, scroll down to see the control interface, tap the “flashlight icon” to turn on/off the light.

In the main interface, scroll down to see the control interface, click on the “banknote checking light icon” to turn on/off the light.

2 : Watch Charging

This product is magnetic charging. One end of the charging cable is connected to the charging adapter via USB, and the other end is attached to the contact point on the back of the watch. The watch screen will display the charging indication, and the charging will start



Note: Connect USB interface to charger with output current of 1A or above or USB interface of computer for charging

3 : Download Installation APP

Use your mobile phone to scan the QR code below, download and install the APP, or use an Android phone to go directly to App Store, or use an Apple phone to go directly to the Apple Store, and search for "**FitCloudPro**" to download and install.




Mobile phone system requirements :

Android 5.1 and above

IOS 8.2 or above

4 : Connect the Watch

- 1 Scan code connection: open the "Device" column under the "FitCloudPro" APP in the mobile phone, click to add the binding device on the top right of the device, and the QR code in the scan watch is paired and bound
- 2 Manual connection: After the mobile phone turns on wireless, enter the "Device" column under the "FitCloudPro" APP, click Add Device, and manually connect the device by hand
 - Before pairing, ensure that the power of the watch is above 20% to avoid pairing due to insufficient power
 - During the pairing connection, ensure that the wireless of the mobile phone is turned on, the call audio of the watch, and the media audio open
 - To turn off call audio, media audio, click the phone icon to turn it on and off
 - If the watch is not connected to the mobile phone APP for a long time or the power is cut off for a long time, the time will be inaccurate, APP synchronization required



5 : Functions on Smart Watch

Smart watch supports : Answer/dial calls, message notification, stress measurement, sleep information, breathing training, weather, sports mode, remote photo, music control and more.

6 : FitCloudPro APP Function

1. wireless data transmission : When connected to the mobile phone, the watch will instantly synchronize data with the mobile phone through wireless, such as weather, notification messages, sports and health data, etc. These data will not be synchronized after disconnecting or turning off wireless
2. Watch faces : Over 100 watch faces for choosing, you could download and custom watch face on FitCloudPro App
3. Notifications : Turn on the switch to sync related information to smartwatch (Phone, Messages, Facebook, X, WhatsApp, WaChat, Instagram, Skype, KakaoTalk, Line, Others)

7 : Product Parameters

Product Type	Smart Watch	Battery Type	Lithium polymer
Display Size	2.01ch	Battery Capacity	600mAh
Weight	59g	Charging Voltage	DC 5V
Watch Size	51,5*44*13,0mm	Wristband Material	RUBBER
Package Contents	Smartwatch, manual,charging cable		

Matters needing attention

- Do not disassemble, repair or modify the product without authorization
- Do not collide the product violently to avoid product damage。
- Please avoid using in strong magnetic field, direct light or high temperature environment。
- This product is not used for disease diagnosis, treatment and prevention.

Common problem handling

The watch cannot be switched on

- Please fix the power key for more than 3 seconds
- The battery may be too low, please charge it in time。

wireless is not connected or cannot be connected

- Please try to restart the watch and reconnect。
- Please try to restart the mobile phone wireless and connect again。
- The mobile phone should not be connected to other wireless devices at the same time。

For more frequently asked questions, please check the mobile app [My>FAQ]