YELLOWFIN BOTTOM SHELVES

Model # 55-0145




PARTS LIST		
	QTY	Parts
	2	Bottom Shelf

Shelf load capacity 50 lbs.

Shelf Installation

PARTS NEEDED: BOTTOM SHELF

With the YellowFin Work Station (55-0140) already assembled ensure the stand is on a level surface. Locate an open end on the stand and rotate the *Bottom Shelf* vertically and pass the *Shelf* through the stand. When centered in the stand lower the *Shelf* onto the *U-Brace Bars* attached to the *End-Frames*. Repeat the process on the other stand.



Rev. 4/24

FOR TECHNICAL ASSISTANCE OR REPLACEMENT PARTS: CALL 866.787.7369

