

# YELLOWFIN BOTTOM SHELVES™

Model # 55-0145



PARTS LIST	
QTY	Parts
2	Bottom Shelf

Shelf load capacity 50 lbs.

## Shelf Installation

### PARTS NEEDED : BOTTOM SHELF

With the *YellowFin Work Station (55-0140)* already assembled ensure the stand is on a level surface. Locate an open end on the stand and rotate the *Bottom Shelf* vertically and pass the *Shelf* through the stand. When centered in the stand lower the *Shelf* onto the *U-Brace Bars* attached to the *End-Frames*. Repeat the process on the other stand.



Rev. 4/24

FOR TECHNICAL ASSISTANCE OR REPLACEMENT PARTS: CALL 866.787.7369

SUSPENZ®, INC.  
590 W. CROSSVILLE ROAD #103  
ROSWELL, GA 30075



CUSTOMER SERVICE: 770-518-0045  
FAX: 770-518-8507  
WEBSITE: WWW.SUSPENZ.COM