





KODAK MEMO SHOT ERA MS100

User Guide Guide de l'utilisateur Kasutusjuhend Podręcznik użytkownika Benutzerhandbuch ユーザーガイド
guía del usuario Uživatelská příručka 사용자 설명서 Naudotojo gidas Användarguide 单色热敏即时相机
Guida dell'utente Uživatelská příručka Käyttöohjeet Lietotāja rokasgrāmata Brugervejledning 用户指南

www.kodakphotoprinter.com



APP ↓



KODAK MEMO




Available on the App Store


ANDROID APP ON Google play




2 Sec




Android





iOS




1



2



3



4




1



2 Sec



2




3



1




2



3




3



1




2




3



3




1




2



3



3




1



2



3



3



产品保修卡 (主卡)

厂家留存联

产品SN码 _____

客户姓名 _____

联系方式 _____

购买日期 _____

售出终端 _____

报修日期	故障及处理	维修员

产品保修卡 (副卡)

用户留存联

产品SN码 _____


客户姓名 _____

联系方式 _____

购买日期 _____

售出终端 _____

"三包"服务政策(中国大陆地区)
出现非人为损坏的外观问题或性能故障,享有国家规定的三包服务。
消费者自签收之日起:
• 7日内,可换、可退、可修;
• 15日内,可更换或维修;
• 1年内,可免费维修。
本行"三包"服务期限:
• 因不可抗力造成的损坏,未经授权的维修/拆修等;
• 长期(约3个月)未充电可能导致电池自然损耗,无法激活充电的。



120 MIN

