




LED Floor Lamp

SKU: HLFL01B
[Instruction Manual]




Thank you for your purchase.
Please contact us if you have any questions.
We will get back to you within 24 hours.
Email: support@dewenwils.com
Please attach your Order ID so that
we can serve you better.

CAUTION

1. Before assembly, place all parts out on a clean flat surface and inspect each part for defects that may have occurred during shipping.
2. Inspect wire insulation for any cuts, abrasions or exposed copper that may have resulted during shipping. If there are any defects in the wire, DO NOT continue assembly. Please send an email to our Customer Service immediately (Support@dewenwils.com).
3. Consult a qualified electrician if you have any electrical questions.
4. Never drape clothes over the lamp.
5. To reduce the likelihood of tipping over, we recommend placing the lamp behind furniture and keep children and pets away.
6. To prevent children from suffocating and choking, keep them away from packing materials.
7. Please keep this manual and hand it over when you transfer the product.


Packing List:

Part	Description	Quantity
1	Torchiere Lamp	1
2	Adapter	1
3	Base	1
4	Glass lampshade	1
5	Remote Control	1
6	Screw	3
7	Screwdriver	1
8	Instruction Manual	1



ASSEMBLY INSTRUCTIONS


Before assembly, compared to the packing listing to make sure all parts are present; Install the adapter first to check if product functions as intended.



1. Install the glass lampshade on the lamp panel with screws.

Note: The glass lampshade has three openings, which need to be aligned with the holes of the lamp panel.

Take care not to damage the glass lamp shade.




2. Screw the Tube-2 clockwise onto the Top Lamp (A) until tight.
3. Screw the Tube-3 4 5 6 7 clockwise onto the previous Tube until tight.
4. Screw the Base (B) onto Tube-7 until tight.
5. Pull out any excess power cord through the Tube-7 . Connect the Adapter connector (D) to the Adapter(C).
6. Place the floor lamp where you need it and plug into the power supply.

Functions

Touch Switch

Three color temperature(3000K/4500K/6000K), Stepless Dimmable



Touch Switch :

A is the top lamp, B is the reading lamp :

Touch the switch once to turn the light ON; Short press this button in turn to select the color temperature(3000K / 4500K / 6000K).At last, short press this button to turn off.


Touch the switch and hold for a moment to adjust the brightness higher or lower. Remove hand when desirable brightness is reached.

Remote Control

The left side with black of the switch controls the top lamp;

The right side with white color of the switch controls the reading lamp;

All of the function is the same, Top to end of the Switch as below:



Memory function: the floor lamp can remember the mode of the brightness and color you settled before closing.

Specifications

- Product Height: 69.3 IN.
- Base Diameter: 9.8 IN.
- Materials: Metal & Glass
- Input Voltage: 110-240VAC 60Hz

Torchiere Lamp

- Max. Wattage: 20W
- CCT: 3000K/4500K/6000K
- CRI: ≥ 80

Reading Lamp

- Wattage: 5W
- CCT: 3000K/4500K/6000K
- CRI: ≥ 80

One Year Limited Warranty

DEWENWILS guarantees this product to be free from defects in material and workmanship for a period of one year from the date of purchase. Warranty will be void if damage is due to misuse or improper installation. Please contact us if you have any questions.

Email: support@dewenwils.com