



NS110 HD60 Pro Quick Guide

© 2021 Narvitech Corp.

English | 繁體中文

Package Contents



NS110



USB 2.0 Micro to Type A



HDMI Cable




Quick Guide



Cyberlink Key

Parts and Ports




2


How to live streaming / record on PC/Laptop

- 1 First, connect NS110 to a camera via HDMI cable.

*Different model camera has different HDMI port configuration, please prepare the HDMI cable accordingly.



- 2 Then, connect NS110 to a PC/Laptop via USB cable, switch NS110 to PC mode.



- 3 After set up, open software(Screen Recorder 4, OBS, etc) and start live streaming/recording immediately!



LED indicator status


Green	Ready to record
Green flashing	Recording (PC/SD mode)
Red	No Video
Red flashing	SD card not inserted (SD card mode)
Blue	SD card reader mode long press recording button in SD card mode when connected to PC
White flashing	Firmware Update

3

How to record the screen on camera?

- 1 First, setup a camera on a tripod, connect NS110 to the camera via HDMI cable to the camera.

*Different model camera has different HDMI port configuration, please prepare the HDMI cable accordingly.




- 3 Secure NS110 and power bank on to the tripod (Velcro tape is recommended), press the record button to start recording ! (press again to stop recording)

*More information about SD card recording can be found in the Narvitech official website > Support



- 2 Connect NS110 to the camera via HDMI cable, power up NS110 with a power bank, then switch NS110 to SD card mode and insert a SD card.




LED indicator status


Green	Ready to record
Green flashing	Recording (PC/SD mode)
Red	No Video
Red flashing	SD card not inserted (SD card mode)
Blue	SD card reader mode long press recording button in SD card mode when connected to PC
White flashing	Firmware Update

4

包裝內容



外觀簡介



如何在筆電/PC上進行直播/視訊？

1 首先，將 HDMI 接上相機

*每種相機的 HDMI 輸出接口規格可能會有所不同，需搭配對應規格的 HDMI 傳輸線

2 接著將 NS110 透過 HDMI 連接相機，再透過 USB 連接 PC 或是筆電，最後將 NS110 切換到 PC 模式。

3 連接完畢後，打開軟體(如 Screen Recorder 4, OBS)就可以開始直播或視訊囉!

*NS110 與軟體的設定流程請至 Narvitech 官網 > 支援中心 > 下載專區 > NS110 的中找尋

LED 指示燈狀態

錄燈	錄製準備就緒
錄燈閃爍	錄製中(PC/SD 卡模式)
紅燈	未偵測到 HDMI 輸入源
紅燈閃爍	未插入 SD 卡(SD 模式)
藍燈	讀卡機模式 (SD 卡模式連接電腦後長按錄製鈕)
白燈閃爍	韌體更新

如何透過 NS110 外錄相機螢幕？

1 首先把相機與三腳架架設好後，接著將 HDMI 連接相機

*每種相機的 HDMI 輸出接口規格可能會有所不同，需搭配對應規格的 HDMI 傳輸線

2 將 NS110 透過 HDMI 與相機連接，然後透過 USB 連接行動電源，最後再將 SD 卡插入 NS110 並切換到 SD 卡模式。

3 將連接好的 NS110 與行動電源分別綁在腳架上(建議使用魔鬼氈)，最後按下 NS110 錄製按鈕即可開始錄製! (再次按下按鈕即可停止)

LED 指示燈狀態

錄燈	錄製準備就緒
錄燈閃爍	錄製中(PC/SD 卡模式)
紅燈	未偵測到 HDMI 輸入源
紅燈閃爍	未插入 SD 卡(SD 模式)
藍燈	讀卡機模式 (SD 卡模式連接電腦後長按錄製鈕)
白燈閃爍	韌體更新

Please visit Narvitech.com for more information | 更多 NS110 的資訊都在 Narvitech.com

Please go to "Contact us" on Narvitech Official website, our customer service are willing to help you for any further questions.
NS110 user manual: Narvitech official website > Support > Download > NS110
NS110 FAQ: Narvitech official website > Support > FAQ > NS110

如有使用上的問題，請利用官方網站的「聯絡我們」或 Facebook 粉絲團的私訊，我們將有專人為您服務。
NS110 完整使用說明書: Narvitech 官網 > 支援中心 > 下載專區 > NS110
NS110 相關 FAQ: Narvitech 官網 > 支援中心 > FAQ > NS110

Copyright and Trademark | 版權及商標資訊

© 2021 Narvitech Corp. All Rights Reserved. Narvitech, NS110, its products names and logos are trademarks or registered trademarks of Narvitech Corp. All other company and product names and logos may be trademarks or registered trademarks of their respective owners in certain countries. Product specifications are subject to change without notice.

©2021 Narvitech Corp. 保留所有權利。Narvitech 及其產品名稱和商標屬於 Narvitech Corp，所有其他公司和產品名稱及商標可能是其各自所有者在某些國家的商標或註冊商標。

CAUTION | 注意

- Do not scratch the product with sharp object to avoid peeling off the housing printing.
- Do not bring the product close to fire source to avoid damage to the product.
- Do not drop the product to avoid damage to the product.
- Narvitech will not be responsible for the warranty if the product is damaged intentionally.
- Please make sure to return color box, device, accessories all together within the warranty period, otherwise Narvitech will not responsible for the warranty.

- 請勿使用銳利物品觸碰產品本體，以免造成外殼印刷剝落。
- 請勿使用打火機接觸產品本體，以免造成硬體損毀。
- 請勿重摔產品，以免造成硬體損毀。
- 如惡意毀損產品，本公司恕不負責固維修責任。
- 保固期內如需維修，請務必將外盒、產品本體、及所有配件一同寄回，否則恕不負責固責任。

XSplit

CyberLink

FCC

CE

Pb

RoHS

REACH