

Battery Powered LED String Lights

User Manual

Description:

Thank you for purchasing our LED string lights. This flexible LED string light combines decoration and lighting and is perfect for indoor spaces such as closets, patios, hallways, stairs, bedrooms, kitchens and more. It offers flexible design options, making it different from traditional LED lights. This string light is ideal for creating a cozy atmosphere for you and your family.

Specifications:

- Light Color: Warm White / Cool White / Multicolor
- Number of LEDs: 20 / 50 LEDs
- String Length per Light: 2m / 5m
- Distance Between LEDs: 95mm / 3.7inch
- Batteries Required: 3 AA Batteries (Not Included)
- Battery Compartment Size: 2.87" x 1.96" x 0.7" / 7.3cm x 5cm x 1.8cm

Package Content:

2 LED String Lights

Important Safety Information

Please read these safety instructions carefully before using the product. Failure to follow these warnings may result in fire, injury, or damage to the product.

1. Battery Safety

- ① Battery Requirement: This product requires 3 AA batteries (not included).
- ② Non-Rechargeable Batteries: Use only non-rechargeable AA batteries. Do not mix old and new batteries or different battery types (e.g. alkaline and zinc carbon).
- ③ Battery installation: Make sure that the batteries are installed with the correct polarity (+/-).
- ④ Battery replacement: Remove discharged batteries immediately to prevent leakage and corrosion. Dispose of batteries in accordance with local regulations.
- ⑤ Battery compartment: The battery compartment is NOT waterproof. Do not expose the battery compartment to water, moisture or extreme temperatures.
- ⑥ Fire hazard: Do not expose the batteries to heat or direct sunlight. Do not attempt to disassemble or short-circuit the batteries.

2. Choking hazard

Small parts: This product contains small parts that may pose a choking hazard. Keep away from children under 3 years of age.

3. Electrical Safety

Damaged Parts: If any part of the product, including the battery compartment, cords or lights, is damaged or worn, stop operating immediately to avoid the risk of electric shock or fire.

4. General Warnings

- Not a Toy: This product is not a toy. It should not be used by infants or young children without adult supervision.
- Supervision Required: Always supervise children when the product is in use, especially around batteries.
- Product Disposal: At the end of its life, dispose of the product responsibly in accordance with local recycling or e-waste guidelines.

5. Contact Information:

If you need further assistance or have any problems with the product, please contact us at support@bxroi.com