

Universal Wireless VR Remote & Gamepad User Manual



like: Y key is for mute under iOS, but menu key under Android.

4.2 Selfile operation:

For iOS mobile, press A key to shutter; for Android Samsung mobile, then press OK key to shutter, Volume key to adjust focus; for other Android mobile, please enter camera setup first, then set volume key to shutter or scan QR code to download camera software.

4.3 Mouse operation(just for Android):

When the controller is in the music operation function, Press ESC, then joystick can change to mouse function, OK is for mouse confirm key, OK+ is for mouse right key. Press ESC again, then can switch to music mode. If need move mouse function, please press the confirm key on the top and at same move the joystick.

MENU function: press Y is MENU key function.

4.4 E-Book flip function:


In iReader: use Volume +/- to turn page up down; In Kindle or PPT for iOS, use joystick in Game mode to turn page.

5. VR (Game/Video) function: Turn side switch to Game side (there is "GAME" on side).

5.1 VR (Game/Video) function on Android:

VR App Download: use QR code software to scan QR code on the packing (or enter into website: <http://www.migamepad.com/>) to enter into MIGAMEPAD download center, then you can download MIGAMEPAD game application or third party's VR application. such as: Baofeng VR app, 3D Bobo etc.

VR game: from these applications download games, if support the Gamepad, connect wireless can be directly used to operate the game (note that the side of the switch to GAME side). This kind of games



03

6. Battery:

Our product is need two 1.5V batteries of type size AAA, when power is low, LED will flash, please change the batteries.

7. Product Specifications

Item	Specifications
Model	052
Size	116mmx45mmx13.5mm
Wireless Protocol	Wireless 3.0 compliant
Wireless Distance	2-10 Meters
OS	Android /iOS/PC
CPU	ARM968E-S Core
Battery	Type size alkaline AAA 1.5V x 2
Working time (Continuous game)	About 40 hours
Work current	0.5~8mA
Standby current	0.5-1mA
Shutdown current	<20uA


05

Many thanks for purchasing our product! This is a portable wireless controller, used for mobile phone, MID, TV box, smart TV, PC and so on. It can be used as gamepad, VR remote, wireless mouse, music control, E-book page, PPT presentation etc. and support iOS, Android, Windows and so on.

Important Note: Products are subject to change without any notice. And this product has applied for patents, counterfeiting is not permitted.

Operating instructions:

- Power On:** Press OK button until LED is on (about 2 seconds). (First put the batteries.)
- Power Off:** Press OK button until LED is off (about 5 seconds). Note: If no connecting with wireless device after 5mins, system will power off automatically; after connecting with wireless device, if no any operation, system will power off after 30mins.
- Pair and connect:** after power on, LED indicator will flash, the device will enter into the wireless pair mode automatically to find the address and name of this device (MOCUTE-052-xxxx), click then can connect. Pair and connect successfully, LED indicator will turn off. Next power on, it can connect and match the last wireless device. Under turn off state, press OK (over 8 seconds), LED will flash, then go to pair mode again, and can't connect last paired device automatically.
- KEY Mode:** Turn switch on side to KEY (there is "KEY" on the side). (as shown to the right)
- 4.1 Music/Video operation:**
After connecting with wireless, open mobile's music player (like Samsung's player), click play, then can use this device to operate, like music play, pause, changing songs and so on. There are some difference due to different software and system,



02

such as: Zombie Hunter, Virtual Reality FPS, etc.. (Some games maybe need set to use gamepad control when playing)

VR video operation: VR software generally: key play / pause, key to return, the analog stick fast forward and rewind operation. (Note: the Baofeng VR App must be download from the website of www.migamepad.com (QR code center), can to connect the gamepad).

Touch OK function keys: in the Samsung VR Oculus Gear or other VR games, the general need to touch the screen to click the cursor point, to start Games etc. when using the handle, press the button B.

5.2 iOS VR APP operation:

VR APP download: Enter into iOS APP store or use QR code software to scan QR code on the packing (or enter into website: <http://www.migamepad.com/>) to enter into MIGAMEPAD download center, then you can download MIGAMEPAD game application or third party's VR application. such as: Baofeng VR app, 3D Bobo etc.

VR game: before entering the VR application, the soft keyboard input method, set the status of the English input, you can enter the English alphabet. Enter the address bar of the browser, there will be a keyboard input state. Then connect the wireless, you can operate the gamepad. (Note: in the Baofeng VR application need to select the handle -MOCUTE option). such as: ZombieFight or Zombie Warfare, Virtual Reality FPS, SCW VR Free etc. iCade games, you can use the gamepad operation. Or enter the APPStore search "iCade", you will find support for the games of iCade type, download and install, Such as: Lite Brotherhood, TTR, Premium Akane, etc. (Some games maybe need set to use iCade control when playing).

VR video operation: set to English input method, which can in the Baofeng VR APP or 3D Bobo control video operation (play, pause, fast forward, rewind, etc.)

(Note: the Baofeng VR App need to choose the handle -MOCUTE option). In addition, if you use Apple's official video software, you can also use KEY mode of music control functions to control the video operation.

04



Scan above QR code to get more details, help and game resource.

Notes:

- When accident cause not boot or unable to shutdown, please use needle to take out the batteries.
- If can't connect, please Press B+Y+Power button to Power On, then Power Off the device to restore factory settings.