



action Wireless Sports Headphones with LED Neckband

USER GUIDE
BLUETOOTH SPORTS EARPHONES
MODEL:GV-BT800

1. Introduction

Thank you for choosing the GV-BT800 Bluetooth stereo earphones, this manual will help you to operate the earphones, please firstly familiarize yourself with the Bluetooth functionality of your Bluetooth devices before using the earphones.

Safety Rules


1. Please follow the guidelines explained in this manual closely to ensure your safety, before using the earphones.
2. Be careful of any sharp edges on the packaging etc.
3. These earphones do not contain any reusable parts so please do not modify or dismantle these earphones, doing so may invalidate your warranty and could cause electric shocks / fires.
4. Do not use any abrasive or volatile liquids to clean the earphones.
5. Do not use the earphones in a hazardous location.

2. Pack Contents



- 1 x Bluetooth headset
- 2 x Extra pairs sport buds
- 1 x Micro Usb charging cable
- 1 x User manual
- 1 x Carry pouch

3. Connection Diagram



4.How to use

4.1 General Functions

To turn on	Press and hold the "►" button for 3 seconds (The red LED slowly flashes and a beep can be heard).
To enter the pairing mode	Ensure the earphones are off and press and hold the "►" button for 6 seconds. (The blue LED and red LED flash alternately and two beeps can be heard).
Pairing	When in pairing mode the earphones will be discoverable to your mobile device. Device and to perform pairing action (detail refer to the chapter about pairing).
Play/Pause	Press ► to play when the device is pausing and press ► to pause when the device is playing.
Volume up	Press+ is for volume up
Volume down	Press- is for volume down
To switch cable lights on/off	Press and hold the glowing cable control button, to change the frequency of the Flashing lights press the button once (to switch between slow flash or quick flash)

For previous track	Press-
For next track	Press+
To turn off	Press the "►" button for 3 seconds when the device is on. (a tone voice beep and all LED is off)
Low battery warning	The red LED flash
To Charge the earphones	Plug the micro Usb connector to the micro Usb port on the earphones, then plug the Usb adaptor into a suitable Usb charger. When charging, the red LED light will be illuminated.
To answer a call	Press the "►" button for 1 second
To end a call	Press the "►" button for 1 second
To switch a phone call between the phone and the earphones	Double click the "►" button during the call.
To reject call	Press the "►" button for 2 seconds to reject call when the call is ringing.
Last number redial	Double click the "►" button when connected or during music playback.
To perform a factory reset	Whilst in charging mode, short click the "►" button, the blue LED will flash twice; the earphones will now be restored to the factory setting.

4.2. Pairing to Bluetooth devices

To use your Bluetooth Stereo earphone, you must firstly pair them with your Bluetooth device .Once your earphones are paired to a specific device; they will remain paired when they are within range.

4.3 You can pair two devices at the same time.

After pairing the first device, switch off the Bluetooth function on the first device. Then turn on the second device to pair with earphones after the second device is successfully paired with earphones, switch the Bluetooth mode on the first device back on. Both devices are now connected to the earphones and so music can be selected from either device.

Pairing to a Bluetooth device:

- Turn on your device and ensure its Bluetooth function is activated.
- Turn on the Bluetooth Stereo earphones, and go to pairing mode.
- Set your mobile device to scan for mobile devices
- After a few seconds your device will discover the earphones under "GV-BT800". Select it and your device will confirm this pairing.
- You can listen to music and any other sort of entertainment with your device, enjoying all the audio through the earphones. You can control your device with the earphone controls i.e. Volume up/down and previous/next tracks.

Pairing to a computer:

- If there is no Bluetooth function supported by your computer, a Bluetooth adapter will be required. Connect the adapter to your computer and ensure its Bluetooth function is activated.
- Turn on the device, go to the pairing mode.
- Open the Bluetooth software (Such as Blue Soleil) installed on your computer, and select the "Search your Bluetooth devices" function. Refer to your user manual of the Bluetooth software for more information.
- After a few seconds the GV-BT800 will list in Bluetooth software of your computer as a discoverable device. Select this icon and click right button of mouse to select "pairing", then select "connect with audio device" with the right button on the mouse.


- Open your media player soft to play music, watch TV/movie and video games the audio effect will now be played back through your earphones.

4.4. Charging your device

The device is easy to connect to an Usb mains charger. Make sure the headphones are fully charged for at least 3.5 hours before initial use. Insert one end of your Usb cable to a charger or USB port on a PC and other end to the Micro USB socket on the headphones. While charging, the red LED light is on constantly. When charging is completed, the red LED turns off.

4.5. Earpieces

1. Ensure you assign the "R" into the right ear and the "L" into the left ear.
2. One ear at a time, hook the ear-hook around the ear.
3. Ensuring that the fin is pointing towards the "R" and "L", twist the ear-hook to secure the ear-fin into your inner ear lobe, this will ensure the best fit.



5.Technical specification


Bluetooth Specification	CSR Version 4.1
Bluetooth Profile	HSP,HFP,A2DP,AVRCP
RF Range	≥10m
Frequency Response	20Hz-20 KHz
Speaker rated power	0.35V
Signal-To-Noise	≥95dB
THD+N	≤1.0%
Charging Time	≤3Hours
Talk time	≥6-8hrs-glowing cable off ≥5hrs-glowing cable on
Music time	≥6-8hrs-glowing cable off ≥4 hrs-glowing cable on
Standby time	≥180hrs-glowing cable off ≥13 hrs-glowing cable on
Dimension (LxWxH)	180 X160 X35 mm
Weight	100g

6. Service and Support

If your device is not performing as expected, please contact your original point of purchase (ensure you have your warranty/ proof of purchase available).

7. Battery Remove/Disposal

Your product contains batteries which cannot be disposed of with normal household waste. Doing so may harm the environment. Please find out about your local council rules on battery disposal to prevent damage to the environment. Should your product develop a fault and your battery needs replacing. Or for further advice and information on how to safely remove your battery, please visit our website at www.groov-e.co.uk you can contact us via email: info@groov-e.co.uk Or via post: Groov-e, Unit J, Braintree Industrial Estate, Braintree Road,Ruislip. HA4 0EJ, UK



groov»e
Unit J, Braintree Industrial Estate
Braintree Road, Ruislip
Middlesex, HA4 0EJ,UK
www.groov-e.co.uk