

eero Router setup guide

- Intro- (Thank you for purchasing).....2**
- Package contents (Hardware, brackets, screws, etc)2**
- System requirements (Android/MacOS).....2**
- How do I set up eero?2**
 - STEP 1: Download the eero app for iOS or Android:2
 - STEP 2: Create an eero account or Log In with your Amazon Account.3
 - STEP 3: Set up your eero Gateway3
 - STEP 4: Create your eero network3
 - STEP 5: Add eeros to your network.....4
 - STEP 6: Connect devices to your eero network5
- Replacing an existing network..... 5**
- Safety Notices..... 6**
- Safety and Compliance (en-US)..... 6**
 - FCC COMPLIANCE INFORMATION6
- Product Specs (en-US)..... 7**
- Trademark (en-US)..... 7**
- Terms of Service, Privacy Notice, and Limited Warranty..... 8**
- Safety and Compliance (en-CA)..... 8**
- IMPORTANT PRODUCT INFORMATION..... 8**
 - SAFETY INFORMATION8
 - FOR CANADIAN CUSTOMERS9
 - Innovation, Science and Economic Development Canada (ISED) Compliance9
 - Information Regarding Exposure to Radio Frequency Energy9
- Terms of Service and Privacy Notice.....10**
 - Servicing Your device10
 - You Received (But Did Not Purchase) Your device From Your Service Provider.10
 - You Purchased Your device (Including From Your Provider)10
- Limited Warranty (en-CA).....11**
 - 1. Remedies.....11
 - 2. How to obtain Limited Warranty service.....11
 - 3. Exclusions.....12
 - 4. Limitations.....12
 - 5. Implied warranties and conditions13
 - 6. Limitation of damages13
 - 7. National statutory rights13
 - 8. Warranty Provider14
- Safety and Compliance (fr-CA)14**
- INFORMATIONS IMPORTANTES SUR LE PRODUIT14**

INFORMATIONS SUR LA SECURITE	14
SPECIFICATIONS DU PRODUIT	15
POUR LES CLIENTS CANADIENS.....	15
Conformite Innovation Sciences et Developpement Economique Canada (ISDE)	15
Renseignements relatifs à l'exposition à l'énergie des radiofréquences.....	15
Conditions de Service et Avis de Confidentialite	16
ENTRETIEN DE VOTRE APPAREIL.	16
Vous avez Re u (Mais N'avez Pas Achete) Votre Appareil aupres de votre Fournisseur de Services.....	16
Vous Avez Achete Votre Appareil (y compris aupres de votre Fournisseur)	17
Limited Warranty (fr-CA).....	17
GARANTIE LIMITEE.....	17
1. Recours.....	17
2. Comment beneficier du service de garantie.....	17
3. Exclusions.....	18
4. Limitations.....	19
5. Garanties et conditions implicites	19
6. Limitation de responsabilite.....	19
7. Droits nationaux accordes par la loi.....	20
E-labeling Instruction	20

Intro- (Thank you for purchasing)

Thank you for purchasing the eero Router. This User Manual is designed to take you through installation and setup. It also includes warranty terms, compliance and returns information.

Package contents (Hardware, brackets, screws, etc)

- One eero Router
 - One 45W USB-C power adapter
 - One CAT6a Ethernet cable
-

System requirements (Android/MacOS)

Internet connection, modem, Ethernet cable, and smartphone.

How do I set up eero?

Here's how to get started getting your eero network online:

STEP 1: Download the eero app for iOS or Android:

Download the free eero app - you can find it on the Apple App Store or Google Play. eero supports both iOS and Android (check

<https://support.eero.com/hc/en-us/articles/207852793-Which-mobile-devices-can-I-use-to-set-up-and-manage-my-eeros-> for details on the versions we support).

You will not be able to set up your system on a web browser.

STEP 2: Create an eero account or Log In with your Amazon Account

To begin setting up your new eero network, you will need to get Logged In. You can either Log In using your Amazon Account information, or you can make an eero account. You will need to enter your phone number and email address. By default, we'll send a verification code to your phone number Enter this code on the verification screen of the app to create your account.



STEP 3: Set up your eero Gateway

Your Gateway is the primary eero, needed to establish your network. The eero app will guide you through setting up your gateway eero in three easy steps:

1. First, unplug your old modem and router from power. If you have other wireless equipment connected to your modem, please unplug it as well.
2. Place your Gateway eero device on a flat horizontal surface in an upright orientation, with the label-side down and the power inlet and Ethernet ports on the back lower edge. Connect your Gateway eero device to your modem using the Ethernet cable that came in the box. You can use any of the Ethernet ports on the back of your eero.
3. Plug your Gateway eero device into an available power outlet, then reconnect your modem to power. Your eero device's status light will start flashing white. For placement tips, including DO's and DON'Ts, visit <https://support.eero.com/hc/en-us/articles/207897393>. Please note: you need a modem to connect to your eero router. If your modem is built into your current router (also known as a modem-router), then you will need to connect your eero to your existing router. The first eero device should be connected to either your existing cable, fiber, DSL modem, or modem-router



STEP 4: Create your eero network

Now that you've got your modem and gateway eero plugged in, it's time to create your eero network.

After tapping Next, the eero app will begin to look for your new eero. You will notice that your gateway eero's LED will begin to flash and then turn solid once found. Once your eero has been detected, you will be prompted to select a location for your eero (this is how you will identify each eero on your network).

- If prompted, you may need to enter your eero's serial number, which is located on a sticker attached to the bottom of your eero. Just look for a barcode with the letters SN on it - it's small, but it's there.

Once you've selected a location for your eero, you will enter your network name (SSID) and network password. This is how devices will join your network.

- If you're replacing an existing router, an easy option for choosing a network name (SSID) and password is to simply reuse your current SSID and password. This way, you won't have to reconnect devices that were previously on the network.
- Keep in mind that running two networks with the same SSID can be problematic. If you have a modem/router combo device, we encourage you to enable [bridge mode](https://support.eero.com/hc/en-us/articles/207613176-What-is-bridge-mode-How-does-it-work-with-eero-and-why-would-1-want-to-use-it-) (<https://support.eero.com/hc/en-us/articles/207613176-What-is-bridge-mode-How-does-it-work-with-eero-and-why-would-1-want-to-use-it->) on the modem/router so that your devices do not accidentally join the wrong network. If for any reason bridge mode is not available, you can also setup your network in [double NAT](https://support.eero.com/hc/en-us/articles/207621056-How-do-I-set-up-my-eero-if-I-want-to-keep-my-existing-router-) (<https://support.eero.com/hc/en-us/articles/207621056-How-do-I-set-up-my-eero-if-I-want-to-keep-my-existing-router->).

Tap *Next* and your eero network will complete setup!

STEP 5: Add eeros to your network

Once you've set up your gateway eero, your new network has been created and you can begin adding additional eeros to extend your network. You can add any eero device to your existing network.

When adding eeros to your network, please keep in mind the following placement tips:

1. Place any additional eero Model V010001 devices in an upright orientation.
2. Place your eero device centrally. If you have a dead spot, try to place your new eero device between the dead spot and another eero device to ensure a strong connection
3. Make sure it is Out in the open: eeros communicate best when they're not closed in - try not to place your eero(s) inside a media console or cabinet, behind or underneath any large furniture.
4. Place it Away from large electronics: Avoid placing your eero device in front, on top, or under any electronics or appliances as metal objects can block wifi signals.

eeros can be added wirelessly or by Ethernet backhaul, while eero Beacons (only available in the US) can only be added wirelessly. If you need help with placement, we've got lots of tips at <https://support.eero.com/hc/en-us/articles/207897393-Where-should-I-place-my-eeros->. It's a great idea to familiarize yourself with these tips before getting started so that you can optimize placement throughout your home from the get-go.

STEP 6: Connect devices to your eero network

One final (and important) step is to remember to connect all of your devices to your new eero network. To do this, simply find your eero network on your device, enter the network password that you've created, and get connected. If you're using the same network name (SSID) and password as your previous router, your devices should automatically reconnect. However, you may need to toggle WiFi on these devices or power cycle for them to recognize the new eero network.

If you experience any trouble connecting specific devices to your new eero network, try disconnecting and reconnecting WiFi on the device. If that doesn't work, try rebooting the device and then reconnecting to the network once it powers back on.

Replacing an existing network

To replace an existing network, open the eero App and tap the blue plus sign located on the top right corner of the home screen, then select "Add or Replace eero Devices." It's recommended to start with replacing non-gateway nodes first, simply follow in-app instructions replacing each node. Once all non-gateway nodes have been replaced, proceed to replace the Gateway eero.

When replacing the Gateway eero, we recommended unplugging your modem from power for 2 minutes to prevent potential issues with obtaining an IP address. Additionally, make sure the Gateway eero is plugged directly into your ISP connection, do not place a switch between the Gateway and the Modem or ONT, even if planning to use the network in bridge mode.

Safety Notices

Safety and Compliance (en-US)

IMPORTANT PRODUCT AND SAFETY INFORMATION



READ ALL SAFETY INFORMATION BEFORE USING THE DEVICE. FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS COULD RESULT IN FIRE, ELECTRIC SHOCK, OR OTHER INJURY OR DAMAGE.

Only use the power adapter supplied to power your device. Plug your power adapter into a power source that is easily accessible and near the equipment that it will be plugged into.

Do not expose your device or power adapter to liquids. If your device or power adapter gets wet, carefully unplug all cables without getting your hands wet, and wait for the device and power adapter to dry completely before plugging them in again. Do not attempt to dry your device or power adapter with an external heat source, such as a microwave oven or a hair dryer. If the device or power adapter appears damaged, discontinue use immediately.

Your device may get warm during normal use.

Small parts contained in your device and its accessories may present a choking hazard to small children.

Keep objects and liquids away from vents. Objects and liquids entering the vents may cause damage, or cause the device to reset or malfunction.

In some areas, the disposal of certain electronic devices is regulated. Make sure you dispose of or recycle your device in accordance with your local laws and regulations. Additional safety, compliance, recycling, and other important information regarding your device can be found at eero.com/legal/compliance

FCC COMPLIANCE INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

FCC regulations restrict the operation of this device to indoor use only. The operation of this device is prohibited on oil platforms, cars, trains, boats, and aircraft, except that operation of this device is permitted in large aircraft while flying above 10,000 feet. Operation of transmitters in the 5.925-7.125 GHz band is prohibited for control of or communications with unmanned aircraft systems.

Product Specs (en-US)

Device name: eero Router

Model number: V010001

Electrical rating: 100-240V AC, 50/60Hz

Operating temperature: 32°-104°F (0°-40°C)

Storage temperature: -13°-140°F (-25°-60°C)

Operating humidity: 0%-90%, non-condensing

Operating altitude: <9,800 ft. (<3,000m)

Trademark (en-US)

©2023 Amazon.com, Inc. or its affiliates. Amazon, eero, and all related marks are trademarks of Amazon.com, Inc. or its affiliates.

Terms of Service, Privacy Notice, and Limited Warranty

1-year limited warranty. For warranty info, privacy policy, terms of service, trial and subscription terms, and more, visit eero.com/legal

If purchased from **eero.com**, **Amazon.com**, or from authorized resellers located in the United States, then the warranty is provided by, and the party responsible for FCC compliance is, eero LLC, 660 3rd Street, 4th Floor, San Francisco, CA 94107 USA

Safety and Compliance (en-CA)

IMPORTANT PRODUCT INFORMATION

SAFETY INFORMATION



READ ALL SAFETY INFORMATION BEFORE USING THE device. FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS COULD RESULT IN FIRE, ELECTRIC SHOCK, OR OTHER INJURY OR DAMAGE.

Do not expose your device or adapter to liquids. If your device or adapter gets wet, carefully unplug all cables without getting your hands wet and wait for the device and adapter to dry completely before plugging them in again. Do not attempt to dry your device or adapter with an external heat source, such as a microwave oven or a hair dryer. If the device or adapter appear damaged, discontinue use immediately. Use only accessories supplied with the device to power your device.

Small parts contained in your device and its accessories may present a choking hazard to small children.

Your device may get warm during normal use. To reduce the effect of the warming, place your device on a heat resistant surface.

Only use the power adapter supplied to power your device. Plug your power adapter into a power source that is easily accessible and near the equipment that it will be plugged into.

Install your power adaptor or power source into an easily accessible location near the equipment that will be plugged into, or powered by, the power source.

Keep objects and liquids away from vents. Objects and liquids entering the vents may cause damage, or cause the device to reset or malfunction.

Product Specs (en-CA)

Device name: eero Router

Model Number: V010001

Electrical rating: 100-240V AC, 50/60Hz

Operating temperature: 32°-104°F (0°-40°C)

Storage temperature: -13°-140°F (-25°-60°C)

Operating humidity: 0%-90%, non-condensing

Operating altitude: <9,800 ft. (<3,000m)

FOR CANADIAN CUSTOMERS

Innovation, Science and Economic Development Canada (ISED) Compliance

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Information Regarding Exposure to Radio Frequency Energy

This equipment complies with IC RSS-102 RF exposure limits set forth for an uncontrolled environment.

Privileged and Confidential

This device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

CAN ICES-003 (B)/NMB-003(8)

1) Operation shall be limited to indoor use only; and

2) Operation on oil platforms, cars, trains, boats, and aircraft shall be prohibited except for large aircraft while flying above 10,000 ft

In some areas, the disposal of certain electronic devices is regulated. Make sure you dispose of or recycle your device in accordance with your local laws and regulations. Additional safety, compliance, recycling and other important information regarding your device can be found at eero.com/legal/compliance

Terms of Service and Privacy Notice

Your use of your eero network is subject to the eero Terms of Service, found at www.eero.com/legal/tos. You can view eero's Privacy Notice at www.eero.com/legal/privacy.

Servicing Your device

You Received (But Did Not Purchase) Your device From Your Service Provider

If you received your eero device from a service provider (such as a telecommunications or internet or broadband provider) (your "Provider") as part of a Provider service and you have questions or problems that you cannot resolve using your Provider's online help resources, please contact your Provider at their address, website or phone number for service and returns. You can find their contact information in the Settings-Help section of the eero mobile application.

You Purchased Your device (Including From Your Provider)

If you purchased your device from a Provider, you should first contact that Provider at the address, website or phone number where you purchased or ordered your device (also referred to as a "Product") for service and returns under the following Limited Warranty.

Limited Warranty (en-CA)

eero LLC ("eero") warrants to the original purchaser of an eero device ("Product") from Amazon.com, eero.com, or an authorized reseller of eero that the Product shall be free from defects in materials and workmanship under normal use for a period of one (1) year from the date of retail purchase by the original purchaser from an authorized reseller (a) for new, unopened Products, or (b) for eero-approved factory refurbished Products (as applicable, the "Warranty Period").

1. Remedies

If a hardware defect arises and a valid claim is received by eero within the Warranty Period, eero will exchange the defective original Product ("Original Product") with a new or refurbished replacement Product that is the same version or a later version of the Product ("Replacement Product"). If eero, in its sole discretion, determines it is not reasonable to replace the defective Product, eero may refund to you the purchase price paid for the Original Product. In the event of a defect, to the extent permitted by law, these are your sole and exclusive remedies. This Limited Warranty is only valid in the jurisdictions where the Products are sold by Amazon.com, eero itself, or through an authorized reseller or agent, and is valid to the extent permitted by the applicable laws of such jurisdictions. Any Replacement Product will be warranted for the remainder of the original Warranty Period or thirty (30) days, whichever is longer, or for any additional period of time that may be applicable in your jurisdiction.

2. How to obtain Limited Warranty service

"To obtain warranty service, you must contact our customer service team via the contact information listed on our website at eero.com or via email addressed to support@eero.com and obtain a Return Merchandise Authorization (RMA) from our customer service team. eero, in its reasonable discretion, may choose to ship your Replacement Product(s) before receiving your Original Product back from you, and you must return your Original Product(s) to eero within 30 days after the delivery date of your replacement Product(s). You will not be charged for the replacement Product(s) as long as (i) you return the Original Product(s) to us prior to or within 30 days after the delivery date of your Replacement Product order, and (ii) the problem you reported with the Original Product(s) proves to be covered by the terms of this Limited Warranty.

If eero does not receive the Original Product(s) within 30 days after the delivery date of your Replacement Product order, or if eero determines that the problem with your Original Product(s) is not covered by this Limited Warranty, eero will charge the costs of shipping the Replacement Product(s), the costs of any prepaid delivery labels previously emailed to you, and the then-current standard price for the applicable Replacement Product(s) to your credit card or the

original form of payment used at the time that you placed your original order. If eero does not have access to your prior payment information, eero will send you an invoice for the amounts due.

All Original Product(s) must be returned to the address specified by eero in either their original packaging or packaging providing an equal degree of protection, together with proof of purchase. To ensure successful delivery, you are required to return Original Product(s) using the prepaid return delivery label emailed to you by eero. It is your responsibility to retain a copy of the delivery label with the applicable tracking number issued by an agent of the carrier as proof that possession of the returned Original Product delivery was transferred to the carrier. By sending the Original Product(s) to eero, you agree to transfer ownership of the Original Product(s) to eero.

If your claim is valid based on this Limited Warranty, eero shall bear the shipping costs associated with return of the Original Product and delivery of the Replacement Product to you. Any Product that is returned to eero without a valid warranty claim or without an RMA may be rejected, returned to you at your cost (subject to prepayment) or kept for 30 days for your pick-up and then disposed of in eero's sole discretion.

3. Exclusions

This Limited Warranty does not apply to a Product or part of a Product that has been altered or modified (e.g., to alter functionality or capability) by anyone who is not an authorized representative of eero or that is used outside the permitted or intended uses described by eero, with a power supply other than (a) the eero power supply (USB-C) or, (b) for those eero Products specified in writing as capable of being powered via a power over ethernet (PoE) source, a standards-compliant, non-defective PoE PSE ((a) or (b) as applicable, a "Compliant Power Supply"), or with an eero mobile application that has been altered or modified by anyone who is not an authorized representative of eero. In addition, this Limited Warranty does not apply to: (a) damage caused by use of the Product with commercially available non-eero products that have been altered or modified by you or a third party other than the manufacturer of such Product; (b) damage caused by accident, abuse, misuse, spillage of food or liquid, or other external causes; (c) damage caused by operating the Product outside the permitted or intended uses described by eero in its mobile application or in the help section of the eero website or with improper voltage or a power supply other than a Compliant Power Supply; (d) damage caused by service performed by anyone who is not an authorized representative of eero; or (e) damage caused by alteration or modification of the eero mobile application. This Limited Warranty is void if a Product is returned with removed, damaged or tampered labels or any alterations (including the unauthorized removal of any component or external cover).

4. Limitations

This Limited Warranty only applies to the Product(s) manufactured by or for eero that can be identified by the "eero" trademark, trade name, or logo affixed to it. The Limited Warranty does not apply to any (a) eero products and services other than the Product or (b) software, even if

packaged or sold with the Product or embedded in the Product. See eero.com/legal/tos for details of your rights with respect to its use. eero does not warrant that the operations of the Product will be uninterrupted or error-free. eero is not responsible for damages arising from failure to follow instructions relating to the Product's use.

No eero reseller, agent or employee is authorized to make any modification, extension, or addition to this Limited Warranty. If any term is held to be illegal or unenforceable, the legality or enforceability of the remaining terms shall not be affected or impaired.

5. Implied warranties and conditions

EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ALL IMPLIED WARRANTIES AND CONDITIONS (INCLUDING WARRANTIES AND CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS LIMITED WARRANTY. SOME JURISDICTIONS DO NOT ALLOW LIMITATIONS ON THE DURATION OF AN IMPLIED WARRANTY OR CONDITION, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE.

6. Limitation of damages

EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, EERO SHALL NOT BE LIABLE FOR ANY INCIDENTAL, INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES, OR ANY LOSS OF PROFITS, REVENUE, OR DATA, RESULTING FROM ANY BREACH OF EXPRESS OR IMPLIED WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY, EVEN IF EERO HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND REGARDLESS OF THE FORM OF ACTION WHETHER IN CONTRACT, TORT (INCLUDING NEGLIGENCE), OR ANY OTHER LEGAL OR EQUITABLE THEORY. IN SOME JURISDICTIONS, THE FOREGOING LIMITATION DOES NOT APPLY TO DEATH OR PERSONAL INJURY CLAIMS, OR ANY STATUTORY LIABILITY FOR INTENTIONAL AND GROSS NEGLIGENT ACTS AND/OR OMISSIONS, SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. THIS "LIMITATION OF DAMAGES" SECTION MAY NOT APPLY TO CUSTOMERS IN THE EUROPEAN UNION.

7. National statutory rights

Consumers in some jurisdictions may have legal rights under applicable national legislation governing the sale of consumer goods, including, without limitation, EU national laws implementing EC Directive 2019/771. These rights are not affected by the warranties in this Limited Warranty.

8. Warranty Provider

If you purchased your device from eero.com, Amazon.com or from authorized resellers located in the United States, or from Amazon.ca or from authorized resellers located in Canada then this warranty is provided by eero LLC, 660 Third Street, 4th Floor, San Francisco, CA 94107 USA

Safety and Compliance (fr-CA)

INFORMATIONS IMPORTANTES SUR LE PRODUIT

[TRIANGLE WITH !]

INFORMATIONS SUR LA SECURITE



LE MANQUEMENT A CES CONSIGNES DE SECURITE POURRAIT ETRE A L'ORIGINE D'UN INCENDIE, D'UNE ELECTROCUTION OU D'AUTRES BLESSURES OU DOMMAGES.

Ne pas exposer votre appareil ni l'adaptateur secteur à des liquides. Si votre appareil ou l'adaptateur secteur est mouillé, débrancher soigneusement tous les câbles sans vous mouiller les mains et attendre que l'appareil et l'adaptateur secteur soient complètement secs avant de les rebrancher. Ne pas essayer de sécher votre appareil ni l'adaptateur secteur avec une source de chaleur externe, comme un micro-ondes ou un sèche-cheveux. Si l'appareil ou l'adaptateur secteur est endommagé, cesser immédiatement de l'utiliser. N'utiliser que les accessoires fournis avec l'appareil pour alimenter votre appareil.

Les petites pièces contenues dans l'appareil et ses accessoires peuvent présenter un risque d'étouffement pour les enfants en bas âge.

Votre appareil peut chauffer lors d'une utilisation normale. Pour réduire les effets d'un tel réchauffement, placer votre appareil sur une surface résistante à la chaleur.

Pour brancher votre appareil, n'utilisez que l'adaptateur secteur fourni. Branchez-le à une source d'alimentation facilement accessible, située à proximité de l'équipement auquel vous souhaitez le relier.

Installez votre adaptateur d'alimentation ou votre source d'alimentation dans un endroit facilement accessible près de l'équipement qui sera branché ou alimenté par la source d'alimentation.

Tenez les objets et les liquides à l'écart des events. L'entrée d'objets et de liquides dans les orifices d'aération peut endommager l'appareil, le reinitialiser ou son mauvais fonctionnement.

Product Specs (en-CA)

SPECIFICATIONS DU PRODUIT

Nom de l'appareil : eero Router

Numero de modele : V010001

Caracteristiques electriques: 100-240V AC, 50/60Hz

Temperature de fonctionnement: 32°-104°F (0°-40°C)

Temperature d'entreposage: -13°-140°F (-25°-60°C)

Humidite pour le fonctionnement : de 0 % a 90 %, sans condensation

Altitude pour le fonctionnement: <3 000 m (<9 800 pi)

POUR LES CLIENTS CANADIENS

Conformite Innovation Sciences et Developpement Economique Canada (ISDE)

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Renseignements relatifs à l'exposition à l'énergie des radiofréquences

Cet équipement est conforme aux limites d'exposition IC CNR-102 prévues pour des environnements non contrôlés.

Privileged and Confidential

Les appareils fonctionnant dans la bande de 5150 à 5250 MHz sont réservés uniquement à une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.

Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

CAN ICES-003 (B)/NMB-003(8)

- (1) Utilisation limitée à l'intérieur seulement;
- (2) Utilisation interdite à bord de plateformes de forage pétrolier, de voitures, de trains, de bateaux et d'avions, sauf à bord d'un gros avion volant à plus de 10,000 pieds d'altitude.

Dans certaines régions, la mise au rebut de certains appareils électroniques est réglementée. Veuillez éliminer ou recycler votre appareil conformément aux lois et réglementations locales. De plus amples informations sur la sécurité, la conformité et le recyclage de votre appareil, et d'autres renseignements importants sont disponibles à l'adresse eero.com/legal/compliance

Conditions de Service et Avis de Confidentialité

Votre utilisation de votre réseau eero est soumise aux conditions de service d'eero décrites sur www.eero.com/legal/tos. Vous pouvez consulter l'avis de confidentialité d'eero sur www.eero.com/legal/privacy.

ENTRETIEN DE VOTRE APPAREIL

Vous avez Reçu (Mais N'avez Pas Acheté) Votre Appareil auprès de votre Fournisseur de Services

Si vous avez reçu votre Appareil eero d'un fournisseur de services (tel qu'un Fournisseur de services de télécommunications ou d'accès à Internet) (votre « fournisseur ») dans le cadre des services offerts par ce Fournisseur et que vous avez des questions ou des problèmes que vous ne pouvez pas résoudre en utilisant les ressources d'aide en ligne de votre Fournisseur, veuillez contacter votre Fournisseur via son adresse postale, son site Web ou son numéro de téléphone pour obtenir de l'assistance et des informations sur les retours. Vous pouvez trouver leurs coordonnées dans la section Paramètres-Aide de l'application mobile eero.

Vous Avez Achete Votre Appareil (y compris aupres de votre Fournisseur)

Si vous avez achete votre Appareil aupres d'un Fournisseur, vous devez d'abord contacter ce Fournisseur via l'adresse postale, le site Web ou le numero de telephone ou vous avez achete ou commande votre Appareil (egalement appele « produit ») pour obtenir de l'assistance et des informations sur les retours dans le cadre de la Garantie Limitee suivante.

Limited Warranty (fr-CA)

GARANTIE LIMITEE

eero LLC (« eero ») garantit à l'acheteur initial d'un appareil eero (« Produit ») sur Amazon.com, eero.com ou aupres d'un revendeur agree eero, que le Produit sera exempt de defauts de materiaux et de fabrication dans des conditions normales d'utilisation pendant une periode de un (1) an à compter de la date d'achat au detail par l'acheteur initial aupres d'un revendeur agree (a) pour les Produits neufs et non ouverts, ou (b) pour les Produits remis à neut en usine certifies approuves par eero (le cas echeant, la « Periode de garantie »). Si vous etes un consommateur, la presente Garantie limitee vient s'ajouter à vos droits de consommateur et ne remet pas en cause lesdits droits.

1. Recours

Si un defaut materiel survient et qu'une reclamation valable est reue par eero pendant la Periode de garantie, eero remplacera le Produit d'origine detectueux (le « Produit d'origine ») par un Produit de remplacement neut ou remis à neut, dont la version sera identique ou ulterieure à celle du Produit (« Produit de remplacement »). Si eero, à sa seule discretion, determine qu'il n'est pas raisonnable de remplacer le Produit detectueux, eero pourra vous rembourser le prix d'achat paye pour le Produit d'origine. En cas de defaut, dans la mesure permise par la loi, il s'agit de votre recours unique et exclusif. La presente Garantie limitee est valable uniquement dans les pays ou les Produits sont vendus par Amazon.com, eero lui-meme ou par l'intermediaire d'un revendeur ou d'un agent agree, et est valable dans la mesure permise par les lois en vigueur desdits pays. Tout Produit de remplacement sera garanti pour la duree restante de la Periode de garantie initiale ou trente (30) jours, la duree la plus longue etant retenue, ou pendant la periode supplementaire pouvant etre prevue par la legislation en vigueur dans votre pays.

2. Comment beneficier du service de garantie

Pour beneficier du service de garantie, vous devez communiquer avec notre equipe de service client à l'aide des coordonnees indiquees sur notre site Web à l'adresse eero.com ou par courriel à l'adresse support@eero.com afin d'obtenir une autorisation de retour de marchandise (ARM). eero, à son entiere discretion, peut choisir d'expedier votre ou vos Produits de remplacement avant de

recevoir votre Produit d'origine, et vous devez renvoyer votre ou vos Produits d'origine à eero dans les 30 jours suivant la date d'expédition de votre ou de vos Produits de remplacement. Le ou les Produits de remplacement ne vous seront pas facturés à condition (i) que vous nous renvoyiez le ou les Produits d'origine avant ou dans les 30 jours suivant la date d'expédition de votre demande de Produit de remplacement, (ii) que le problème que vous avez signalé concernant le ou les Produits d'origine soit couvert par les modalités de la présente Garantie limitée.

Si eero ne reçoit pas le ou les Produits d'origine dans les 30 jours suivant la date d'expédition de votre demande de Produit de remplacement, ou si eero détermine que le problème lié à votre ou vos Produits d'origine n'est pas couvert par la présente Garantie limitée, eero imputera les frais d'expédition du ou des Produits de remplacement, les coûts des étiquettes d'expédition prépayées qui vous ont été envoyées au préalable par courriel, ainsi que le prix standard alors en vigueur pour le ou les Produits de remplacement concernés à votre carte de crédit ou au mode de paiement initial utilisé lors de votre commande initiale. Si eero n'a pas accès à vos renseignements de paiement antérieur, eero vous enverra une facture des montants dus.

Tous les Produits d'origine doivent être renvoyés à l'adresse indiquée par eero dans leur emballage d'origine ou dans un emballage assurant un degré de protection équivalent, accompagnés d'une preuve d'achat. Pour un envoi réussi, vous devez renvoyer le ou les Produits d'origine à l'aide de l'étiquette de retour prépayée qui vous a été envoyée par courriel par eero. Il est de votre responsabilité de conserver un exemplaire de l'étiquette d'expédition avec le numéro de suivi attribué par un mandataire du transporteur comme preuve que la possession du Produit d'origine renvoyé a été transférée au transporteur. En envoyant le ou les Produits d'origine à eero, vous acceptez de transférer la propriété du ou des Produits d'origine à eero.

Si votre réclamation est valable en vertu de la présente Garantie limitée, eero assumera les frais d'expédition liés au renvoi du Produit d'origine et à l'expédition du Produit de remplacement. Tout Produit renvoyé à eero sans réclamation valable au titre de la garantie ou sans ARM peut être rejeté, vous être renvoyé à vos frais (sous réserve de prépaiement) ou conservé pendant 30 jours pour que vous puissiez le récupérer, puis mis au rebut à la seule discrétion de eero.

3. Exclusions

La présente Garantie limitée ne s'applique pas à un Produit ou à une partie d'un Produit qui a été modifié (par exemple, pour modifier les fonctionnalités ou les capacités) par une personne autre qu'un représentant autorisé de eero ou qui est utilisé de manière non conforme aux utilisations autorisées ou prévues décrites par eero, avec une alimentation autre que l'alimentation eero ou avec une application mobile eero modifiée par toute personne qui n'est pas un représentant autorisé de eero. En outre, la présente Garantie limitée ne s'applique pas aux : (a) dommages causés par l'utilisation du Produit avec des produits autres que des produits eero disponibles dans le commerce, qui ont été modifiés par vous-même ou par un tiers autre que le fabricant dudit

produit; (b) dommages causes par un accident, une mauvaise utilisation, une utilisation abusive, un deversement d'aliments ou de liquide ou par d'autres causes externes; (c) dommages causes par une utilisation du Produit non conforme aux utilisations autorisees ou prevues decrites par eero dans son application mobile ou dans la section Aide du site Web d'eero, ou avec une tension incorrecte ou une alimentation autre que l'alimentation eero; (d) dommages causes par une reparation effectuee par une personne qui n'est pas un representant autorise de eero; ou (e) dommages causes par une modification de l'application mobile eero. La presente Garantie limitee est nulle si un Produit est renvoye sans son etiquette, si son etiquette a ete endommagee ou alteree ou encore si le Produit a lui-meme ete altere (y compris le retrait non autorise de tout composant ou couvercle externe).

4. Limitations

La presente Garantie limitee s'applique uniquement aux Produits fabriques par ou pour le compte de eero, portant la marque, le nom commercial ou le logo « eero ». La Garantie limitee ne s'applique pas (a) aux produits et services eero autres que le Produit ou (b) aux logiciels, meme si ceux-ci sont emballes ou vendus avec le Produit ou integres au Produit. Visitez eero.com/legal/tos jointes a l'application mobile eero pour obtenir de plus amples renseignements sur vos droits en ce qui concerne son utilisation. eero ne garantit pas que le fonctionnement du Produit sera ininterrompu ou exempt d'erreur. eero n'est pas responsable des dommages resultant du non-respect des instructions relatives a l'utilisation du Produit.

Aucun revendeur, agent ou employe de eero n'est autorise a modifier, etendre ou completer la presente Garantie limitee. Si une modalite est jugee illegale ou inapplicable, la legalite ou l'applicabilite des autres modalites ne sera pas alteree ou compromise.

5. Garanties et conditions implicites

SAUF DANS LA MESURE INTERDITE PAR LA LEGISLATION EN VIGUEUR, LA DUREE DE TOUTES LES GARANTIES ET CONDITIONS IMPLICITES (Y COMPRIS LES GARANTIES ET LES CONDITIONS DE QUALITE MARCHANDE ET D'ADEQUATION A UN USAGE PARTICULIER) SERA LIMITEE A LA DUREE DE LA PRESENTE GARANTIE LIMITEE. CERTAINS PAYS NE PERMETTENT PAS DE LIMITER LA DUREE D'UNE GARANTIE OU CONDITION IMPLICITE. IL EST DONC POSSIBLE QUE LA LIMITATION CI-DESSUS NE VOUS CONCERNE PAS. LA PRESENTE GARANTIE VOUS CONFERE DES DROITS SPECIFIQUES RECONNUS PAR LA LOI ET VOUS POUVEZ EGALEMENT DISPOSER D'AUTRES DROITS QUI PEUVENT DIFFERER D'UN ETAT A L'AUTRE.

6. Limitation de responsabilite

SAUF DANS LA MESURE INTERDITE PAR LA LEGISLATION EN VIGUEUR, EERO NE SAURAIT ETRE TENU RESPONSABLE DE TOUT DOMMAGE ACCESSOIRE, INDIRECT, SPECIAL OU CONSECUTIF, OU DE TOUTE PERTE DE BENEFICES, DE REVENUS OU DE DONNEES, RESULTANT DE TOUTE VIOLATION D'UNE GARANTIE OU D'UNE CONDITION EXPRESSE OU IMPLICITE OU EN VERTU DE TOUTE AUTRE THEORIE JURIDIQUE, MEME SI EERO A ETE INFORME DE LA POSSIBILITE DE TELS DOMMAGES ET

QUELLE QUE SOIT LA FORME D'ACTION, QU'ELLE SOIT CONTRACTUELLE, DELICTUELLE (Y COMPRIS LA NEGLIGENCE) OU EN VERTU DE TOUTE AUTRE THEORIE JURIDIQUE OU FONDÉE SUR L'EQUITE. DANS CERTAINS PAYS, LA LIMITATION PRECEDENTE NE S'APPLIQUE PAS AUX RECLAMATIONS EN RAISON DU DECES OU D'UNE BLESSURE, OU **A** TOUTE RESPONSABILITE IMPOSEE PAR LA LOI POUR DES ACTES VOLONTAIRES ET DE NEGLIGENCE GRAVE OU OMISSIONS ET PAR CONSEQUENT, L'EXCLUSION OU LA LIMITATION CI-DESSUS PEUT NE PAS VOUS CONCERNER. CERTAINS PAYS N'AUTORISENT PAS L'EXCLUSION OU LA LIMITATION DE DOMMAGES SPECIAUX, INDIRECTS, ACCESSOIRES OU CONSECUTIFS, ET PAR CONSEQUENT, L'EXCLUSION OU LA LIMITATION CI-DESSUS PEUT NE PAS VOUS CONCERNER. LA PRESENTE SECTION « LIMITATION DE RESPONSABILITE » PEUT NE PAS S'APPLIQUER AUX CONSOMMATEURS DE L'UNION EUROPEENNE.

7. Droits nationaux accordés par la loi

Dans certains pays, les consommateurs peuvent avoir des droits reconnus par la loi dans le cadre de la législation nationale en vigueur régissant la vente des biens de consommation, notamment les lois nationales de l'UE transposant la directive 2019/771 CE. Les garanties stipulées dans la présente Garantie limitée ne portent pas préjudice auxdits droits.

8. Fournisseur de la garantie

Si vous avez acheté votre appareil sur eero.com, Amazon.com ou auprès de revendeurs autorisés situés aux États-Unis, ou auprès d'Amazon.ca ou auprès de revendeurs autorisés situés au Canada, cette garantie est fournie par eero LLC, 660 Third Street, 4th Floor, San Francisco, CA 94107 USA

E-labeling Instruction

Regulatory information can be found in the eero app by selecting your eero then Device Information.

FCC ID	
2AEM4-711917312	
IC ID	
20631-711917312	
CAN	
CAN ICES-003(B) / NMB-003(B)	
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:	
(1) This device may not cause harmful interference.	