How to Operate

Convenient to set your new combination

1. Set the default code 0-0-0 and pull up the shackle.

2. Turn the shackle 90° to the code setting gap.

3. Push the shackle down until the tiny pin is entirely inside the gap.

4. Keep it in place and rotate it 90° to the code line.

5. Scroll the number to set your code.

6. Turn back the shackle until it pops up.