

Key Operation

Blend Mode	Press the power button once to start a 30-second blend cycle. Press it again to stop.
Pulse Mode	To enter Pulse Mode, double-click the power button. Blue lights will flash 3 times while Pulse Mode is active. Press and hold the power button to pulse. Pulse Mode will automatically end after 5 seconds of inactivity.
Battery Level Display	Battery level will display after one cycle blending.

Malfunction Analysis and Troubleshooting

Malfunction	Analysis	Troubleshooting
All indicator lights light up in red, unable to start.	Ran out of battery.	Charge it for 4 to 5 hours to make sure that it gets a full charge.
All indicator lights flicker in red and blue alternately, unable to start.	The jar is not tightened to the base.	Tighten the jar and base, make sure the magnet is aligned with the power button.
Stops working after 5 seconds.	Blender is empty.	Add ingredients into blender to start blending.
Stops working, all indicator lights flicker in red for 5 seconds.	Ingredient is too thick /motor overload protection.	Add some liquid or cut ingredients into smaller pieces or shift into Pulse Mode, then restart it.
Leakage.	The seal is not placed properly; jar/cap is cross-threaded.	Check seals; check thread alignment when screwing on jar/cap.

Bottlerocketblenders@gmail.com

Like & Follow On: [Facebook.com/BottleRocketBlenders](https://www.facebook.com/BottleRocketBlenders)

Shop, Share & Review On: [Amazon.com/Shops/Bottlerocketblenders](https://www.amazon.com/Shops/Bottlerocketblenders)



Cautions

- DO NOT** remove the lid or add something rigid in your blender when it is blending.
- DO NOT** submerge the base into water to prevent electrical components from damaging and make sure it is turned off before cleaning. **DO NOT** disinfect your blender in microwave or hot water above 80°C.
- DO NOT** put your blender in freezer.
- DO NOT** clean your blender with any kind of metallic spiral ball to prevent parts from scratching or damaging.
- DO NOT** clean your blender with a dishwasher machine.
- DO NOT** charge your blender when it is wet.
- DO NOT** repair or disassemble it by yourself otherwise your warranty will be void. If malfunction occurred, kindly contact us.

NOTE :

Product is suitable for USB Type-C cable. Suitable for power bank charging as well.

When not been used for a long time, charge it fully first to keep battery in high voltage state in order to prevent damage.



Food
Contact
Compliance



Keep
Away
From Fire



Non-
microwavable



Fragile


Your First Blend

Make sure your blender is fully charged by checking whether all indicator lights are on before your first blend. Tighten the body and base until the magnet is aligned with the power button. Press power button twice to start blending and remember to clean it immediately after use.



Step 1

Cut ingredients into small pieces before adding into the blender to fill up about 60% of the jar capacity.



Step 2

Add some drinkable liquid until it reaches 80% of jar capacity.



Step 3

Tighten the lid and tilt the blender to make sure ingredients are not stuck under the blades.



Step 4

Blend Mode: Press power button to start blending. Slightly tilt back and forth while blending if desired.

Pulse Mode: Double-click power button to enter into pulse mode. Press and hold the power button to pulse. Pulse mode will automatically end after 5 seconds of inactivity.



Check Battery Level

75%-100%	4 blue lights on
50%-74%	3 blue lights on
25%-49%	2 blue lights on
1%-24%	1 blue light on

!!!WARNING!!!
KEEP OUT OF
REACH
OF CHILDREN

PORTABLE BLENDER

Imported Enviromental-friendly Materials
CE, ROHS, FCC Approval

Nutrition Is The Mission!™

Model :	BRv2
Jar Capacity :	500ml
Jar Material :	PCTG Food Grade
Base Material :	ABS
Blade Material :	304 Stainless Steel
Blending Voltage :	7.4V
Charging Voltage / Current :	5V / 1A
Battery Type / Capacity :	18650 / 2000mAh*2
Motor Speed :	18000rpm
Charging Time :	About 3 to 5 hours
Single Blend Time :	30 seconds

Warranty

12-month Warranty for quality -related issues. Please feel free to contact us via email if product received is damaged or defective. We will strive to resolve all issues raised within 24 hours.